



STARTERKIT

SK-HC08 Series ZK-HC08 Series

Starter Kits for
Freescale HC08 Family

User's Manual



*Development Tools
for the EmbeddedWorld*





SK-HC08 Series ZK-HC08 Series

Starter Kits for Freescale HC08 Family

User's Manual

Revision 1.0



*Development Tools
for the EmbeddedWorld*

Copyright © 2005 SofTec Microsystems®
DC00885



We want your feedback!

SofTec Microsystems is always on the look-out for new ways to improve its Products and Services. For this reason feedback, comments, suggestions or criticisms, however small, are always welcome.

SofTec Microsystems

E-mail (general information): info@softecmicro.com

E-mail (marketing department): marketing@softecmicro.com

E-mail (technical support): support@softecmicro.com

Web: <http://www.softecmicro.com>

Important

SofTec Microsystems reserves the right to make improvements to the SK-HC08 and ZK-HC08 Series Starter Kits, their documentation and software routines, without notice. Information in this manual is intended to be accurate and reliable. However, SofTec Microsystems assumes no responsibility for its use; nor for any infringements of rights of third parties which may result from its use.

SOFTEC MICROSYSTEMS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.

Trademarks

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc.

Metrowerks and CodeWarrior are trademarks or registered trademarks of Metrowerks Corp.

Metrowerks is a wholly-owned subsidiary of Freescale Semiconductor.

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation.

PC is a registered trademark of International Business Machines Corporation.

Other products and company names listed are trademarks or trade names of their respective companies.

Contents

0 Before Starting 5

- 0.1 Important Notice to Users 5
- 0.2 Required Skills 5

1 Overview 7

- 1.1 Main Features 7
- 1.2 Monitor ROM (MON08) 8
- 1.3 CodeWarrior Development Studio Special Edition 8
- 1.4 Recommended Reading 9
- 1.5 Software Upgrades 10
- 1.6 Getting Technical Support 10

2 Hardware Features 11

- 2.1 Standard Features 11
 - 2.1.1 *MCU Section 11*
 - 2.1.2 *Power Supply Section 12*
 - 2.1.3 *USB to MON08 Interface 12*
 - 2.1.4 *MON08 Connectors 12*
 - 2.1.5 *Reset Section 13*
 - 2.1.6 *Inputs Section 13*
 - 2.1.7 *Outputs Section 13*
 - 2.1.8 *Prototype Area 13*

3 Getting Started 15

- 3.1 Package Contents 15
- 3.2 Operating Mode: Standalone Mode 15
- 3.3 Operating Mode: Host Mode 16
 - 3.3.1 *Technical Overview 16*
 - 3.3.2 *Host Control via the Built-In USB to MON08 Interface 17*
 - 3.3.3 *Host Control via the "MON08" Connector 17*

3.3.4 *Host Control via the “EMON08” Connector* 18

3.4 Host System Requirements 18

3.5 Installing the Software 19

3.5.1 *Installing CodeWarrior Development Studio* 19

3.5.2 *Installing SofTec Microsystems Additional Components* 19

3.6 Installing the Hardware 20

3.7 Application Tutorial 23

4 Debugging Features 29

4.1 Creating Your Own Application 29

4.1.1 *Using the Project Wizard to Create Your Application Skeleton* 29

4.1.2 *Starting your First Debugging Session* 29

4.2 GDI Target Interface Notes 30

4.3 Limitations 32

4.4 Trimming Feature 33

4.5 Notes and Tips 34

4.5.1 *Stop Command Handling* 34

Reading Peripheral Status 34

4.5.2 *Breakpoints and Swi Instruction* 34

4.5.3 *Interrupt Execution during Steps* 35

4.5.4 *Peripheral Status during Steps* 35

4.5.5 *Hardware Breakpoints and Software Breakpoints* 35

4.6 DataBlaze Programming Utility 35

5 Troubleshooting 37

5.1 Common Problems and Solutions 37

5.1.1 *USB Driver Problems* 37

5.1.2 *Communication Errors when Using a MON08 Tool* 38

5.1.3 *Communication Can't Be Established with the Board (Via the Integrated USB to MON08 Interface)* 38

5.2 Getting Technical Support 39

0 Before Starting

0.1 Important Notice to Users

While every effort has been made to ensure the accuracy of all information in this document, SofTec Microsystems assumes no liability to any party for any loss or damage caused by errors or omissions or by statements of any kind in this document, its updates, supplements, or special editions, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause.

0.2 Required Skills

In order to beneficially use the Starter Kit, you should be acquainted with certain skills, ranging from hardware to software design. In particular, you should possess knowledge of the following:

- Microcontroller systems;
- HC08 architecture knowledge;
- Programming knowledge (Assembly and C).



1 Overview

1

1.1 Main Features

The SK-HC08 and ZK-HC08 Series Starter Kits are full-featured, ready-to-use evaluation boards for the Freescale HC08 family. The Starter Kits have been designed for the evaluation and the debugging of user applications.

The Starter Kits take advantage of CodeWarrior Development Studio (which groups an Editor, Assembler, C Compiler and Debugger) and the Freescale MON08 interface, which allows the download and debug of the user application into the microcontroller's FLASH memory.

Together with CodeWarrior, the Starter Kits provide you with everything you need to write, compile, download, in-circuit emulate and debug user code. Full-speed program execution allows you to perform hardware and software testing in real time. The Starter Kits are connected to the host PC through a USB interface. A prototyping area allows you to wire your own small application.



Note: on ZK Series, a ZIF (Zero Insertion Force) socket is provided which allows easy microcontroller insertion/extraction.

The Starter Kits offer you the following benefits:

- Real-time code execution;
- In-circuit debugging/programming;
- In-system programming and debugging through a MON08-compatible interface;
- Demo area with push-buttons, potentiometer, DIP-switches and user LEDs;
- Where available: RS-232 ports, CAN transceivers, LIN transceivers and other target-specific peripheral;
- Flexible oscillator configuration;

- Prototyping area;
- CodeWarrior for HC(S)08 Development Studio, Special Edition, with editor, assembler, C compiler and debugger.



Note: *this user's manual explains methods and procedures common to all of the SK-HC08 and ZK-HC08 Series Starter Kits. For a detailed list of the hardware features of your specific Starter Kit, please refer to the Starter Kit's specific user's manual, available in PDF format on the SofTec Microsystems' "System Software" CD-ROM.*

1.2 Monitor ROM (MON08)

All MCUs in the HC08 family contain a monitor ROM which enables in-circuit programming of on-chip non-volatile memory and debug capabilities.

The Starter Kits feature a USB to MON08 circuitry which allows the host PC to communicate with the target microcontroller's monitor ROM (and therefore in-circuit program and debug the target application) through a standard USB cable.

Contrariwise to traditional in-circuit emulation (where the target application is executed and emulated inside the emulator), the Starter Kits use the very same target microcontroller to carry on in-circuit execution. This means that all microcontroller's peripherals (timers, A/D converters, I/O pins, etc.) are not reconstructed or simulated by an external device, but are the very same target microcontroller's peripherals. Moreover, the Starter Kits' debugging approach ensures that the target microcontroller's electrical characteristics (pull-ups, low-voltage operations, I/O thresholds, etc.) are 100% guaranteed.

1.3 CodeWarrior Development Studio Special Edition

The Starter Kits come with CodeWarrior Development Studio, Special Edition.

CodeWarrior Development Studio is a powerful and easy-to-use tool suite designed to increase your software development productivity. It provides unrivalled features such as Processor Expert application design tool, full chip simulation, data visualization and project manager with templates to help you concentrate on the added value of your application.

The comprehensive, highly visual CodeWarrior Development Studio enables you to build and deploy HC08 systems quickly and easily. This tool suite provides the capabilities required by every engineer in the development cycle, from board bring-up to firmware development to final application development.

Without a license key, the product will run in a 1 KB code-size limited demonstration mode.

To break the 1 KB limit, you have two options:

1. Contact Metrowerks to request an unlimited period, free license key to increase the code size limit to 16 KB;
2. Contact Metrowerks to request a 30-day limited, free license key to run the compiler without limitations.

This documentation covers the basic setup and operation of CodeWarrior Development Studio, but does not cover all of its functions. For further information, please refer to the CodeWarrior online help and online documentation provided.

1.4 Recommended Reading

This documentation describes how to use the Starter Kits and how to set up basic debugging sessions with CodeWarrior. Additional information can be found in the following documents:

- **Microcontroller Datasheets;**
- **Starter Kit's Specific User's Manual;**
- **Starter Kit's Specific Schematic.**

Additionally, we suggest to read Freescale Application Notes and Engineering Bulletins available on the Freescale website

(www.freescale.com) for updated documentation about the microcontroller that you are using.

1

1.5 Software Upgrades

The latest version of the Starter Kits' system software is always available free of charge from our website: <http://www.softecmicro.com>.

When installing the Starter Kits' system software you have the option to electronically register the product. If you register the product, you will be automatically notified by e-mail every time a new version of the system software is available.

1.6 Getting Technical Support

Technical assistance is provided to all customers. For technical assistance, documentation and information about products and services, please refer to your local SofTec Microsystems partner.

SofTec Microsystems offers its customers a technical support service at support@softecmicro.com. Before getting in contact with us, we advise you to check that you are working with the latest version of the Starter Kits' system software (upgrades are available free of charge at <http://www.softecmicro.com>).

2 Hardware Features

2

2.1 Standard Features

Every SK-HC08 and ZK-HC08 Series Starter Kit features a common set of functions, listed below.

- MCU section
- Power supply section
- USB to MON08 interface
- MON08 connectors
- Reset section
- Inputs section
- Outputs section
- Prototype area

Additionally, each Starter Kit may feature special additional functions.



Note: *for a detailed list of the hardware features of your specific Starter Kit, please refer to the Starter Kit's specific user's manual, available in PDF format in the SofTec Microsystems' "System Software" CD-ROM.*

The standard functions are explained in the following sections.

2.1.1 MCU Section

This section contains the following components:

- The microcontroller (installed on a ZIF socket on ZK-HC08 series);

- Header connectors to access the I/O pins of the microcontroller;
- An oscillator area to configure the clock source of the microcontroller;
- Jumpers for setting other microcontroller's functions (A/D converter, PLL, etc.)

2.1.2 Power Supply Section

The Power Supply section takes a 12 V DC voltage and, thanks to the built-in power supply, provides a regulated voltage for the rest of the board.

2.1.3 USB to MON08 Interface

The USB to MON08 interface is a circuitry that electrically and logically translates MON08-like commands sent by the host PC through the USB cable to the MON08 interface of the microcontroller.



Note: *to bypass the built-in USB to MON08 interface when using an external in-circuit debugger (via one of the provided MON08 connectors), please remove all of the “**ENA**” jumpers in the “**USB TO MON08 INTERFACE**” section.*

2.1.4 MON08 Connectors

Even though the SK-HC08 and ZK-HC08 Series Starter Kits feature a built-in USB to MON08 interface, two additional, separate MON08 connectors are present which allow an external in-circuit debugger to be used. The EMON08 (Enhanced MON08) is used by in-circuit debugging tools such as the Freescale ICS system or the SofTec Microsystems inDART-HC08; other tools, instead, use the MON08 connector.

2.1.5 Reset Section

This section groups a reset push-button and a reset circuitry to generate a suitable reset signal for the microcontroller and for the peripherals connected to it.

2.1.6 Inputs Section

All of the SK-HC08 and ZK-HC08 Series Starter Kits feature an input area with various input controls like a potentiometer, DIP-switches and push-buttons. Some Starter Kits may feature additional functions.

2

2.1.7 Outputs Section

This section features high-efficiency (low-current) LEDs connected to the microcontroller. Some Starter Kits may feature additional functions.

2.1.8 Prototype Area

The prototype section features both a standard, thru-hole area (for mounting traditional components) and a SMD area (for soldering SMD components).



3 Getting Started

3.1 Package Contents

The Starter Kit includes the following items:

- A full-featured evaluation board;
- An AC adapter;
- A USB cable;
- The SofTec Microsystems “**System Software**” CD-ROM;
- The CodeWarrior Development Studio Special Edition CD-ROM;
- A QuickStart Tutorial poster;
- A registration card;
- This user's manual.

3

3.2 Operating Mode: Standalone Mode

The Starter Kit can work in two ways: Standalone mode and Host mode.

In Standalone mode, no PC connection is required. The microcontroller is factory programmed with a sample application which reads the potentiometer value and displays the results on the output area.

To work in standalone mode:

- All jumpers in the “**USB TO MON08 INTERFACE**” section must be removed;
- All of the “**EMON08**” jumpers in the “**MON08 CONNECTORS**” section must be correctly inserted;
- You must verify that no MON08-based in-circuit emulator/ programmer is connected to the “**MON08**” connector.

To run the built-in example:

1. Verify that all jumpers are in their default position. See the “*Summary of Jumper and Connector Settings*” chapter on the Starter Kit’s specific user’s manual.
2. Power up the Starter Kit. The power connector accepts a 12 V DC wall plug-in power supply with a 2.1 mm pin and sleeve plug with positive in the center and sleeve as ground. The green “**POWER**” LED on the board should turn on.
3. By rotating the potentiometer, you affect the results of the A/D conversion, and the value of each conversion is displayed on the output area.

3.3 Operating Mode: Host Mode

In Host mode the program execution is controlled by the host PC. You can use the PC to debug the application by, for example, executing the program step by step and watching how the microcontroller registers vary, using CodeWarrior Development Studio provided.

In Host mode the Starter Kit can be controlled via the built-in USB to MON08 interface or in conjunction with a MON08-based debugger/programmer.

3.3.1 Technical Overview

All of the HC08 family devices feature a monitor code resident in ROM which, through a serial communication line, allows the programming and the in-circuit debugging of the user application. The monitor code is executed in “monitor mode”; the user application is executed in “user mode”. To enter the monitor mode some microcontroller lines must be properly driven (for further details please refer to the microcontroller’s data sheet).

The Starter Kit’s “**USB TO MON08 INTERFACE**” section groups the circuitry needed to generate the required signals to enter the monitor mode and to communicate with the host PC’s USB port. In particular, to enter the monitor mode, the “**USB TO MON08 INTERFACE**” circuitry:

- Generates a high-level voltage signal (VTST) on the IRQ pin of the microcontroller;

- Generates a high-level voltage and an appropriate reset signal on the RST pin of the microcontroller;
- Drives some pins of the microcontroller to specific levels;
- Drives the microcontroller's VDD on and off, with specific timing, in order to enter the monitor mode;
- Handles a single-wire, bi-directional serial communication line on a specific pin of the microcontroller.

3.3.2 Host Control via the Built-In USB to MON08 Interface

To debug the target application using the built-in USB to MON08 interface:

3

- Make sure that all of the jumpers in the “**USB TO MON08 INTERFACE**” section are inserted;
- Make sure that nothing is connected to the “**MON08**” connector;
- Make sure that all of the “**EMON08**” connector jumpers are inserted (see the “*Summary of Jumper and Connector Settings*” chapter on the Starter Kit's specific user's manual);
- Power the board through the power plug;
- Connect the host PC to the board through the provided USB cable.

This manual explains how to debug the application using the built-in USB to MON08 interface. Please refer to your development tool's user's manual if you need to control the Starter Kit via the “**MON08**” connector.

3.3.3 Host Control via the “MON08” Connector

To debug the target application using an external in-circuit debugger/programmer via the “**MON08**” connector:

- Make sure that all of the jumpers in the “**USB TO MON08 INTERFACE**” section are removed;
- Make sure that all of the “**EMON08**” connector jumpers are inserted (see the “*Summary of Jumper and Connector Settings*” chapter on the Starter Kit's specific user's manual);

- Make sure that your debugger/programmer is compatible with the “**MON08**” connector;
- Connect the external in-circuit debugger/programmer to the “**MON08**” connector;
- Power the board through the power plug.

3.3.4 Host Control via the “EMON08” Connector

To debug the target application using an external in-circuit debugger/programmer via the “**EMON08**” connector:

- Make sure that all of the jumpers in the “**USB TO MON08 INTERFACE**” section are removed;
- Check that nothing is connected to the “**MON08**” connector;
- Make sure that your debugger/programmer is compatible with the “**EMON08**” connector;
- Remove all of the jumpers in the “**EMON08**” connector;
- Connect the external in-circuit debugger/programmer to the “**EMON08**” connector;
- If your external in-circuit debugger/programmer provides automatic target power control, you can take advantage of the “**VDD CTRL**” connector and let the external in-circuit debugger/programmer control the target board’s power as necessary;
- Power the board through the power plug.

3.4 Host System Requirements

The Starter Kit is controlled by CodeWarrior Development Studio. The following hardware and software are required to run the CodeWarrior user interface together with the Starter Kit:

1. A 200 MHz (or higher) PC compatible system running Windows 98, Windows 2000 or Windows XP;
2. 128 MB of available system RAM plus 500 MB of available hard disk space;

3. A USB port;
4. CD-ROM drive for installation.

3.5 Installing the Software



Note: *before connecting the Starter Kit to the PC, it is recommended that you install all of the required software first (see below), so that the appropriate USB driver will be automatically found by Windows when you connect the Starter Kit.*

3

The Starter Kit requires that both CodeWarrior Development Studio Special Edition and SofTec Microsystems Additional Components be installed in the host PC.



Note: *CodeWarrior Development Studio for HC(S)08 must be installed first.*

3.5.1 Installing CodeWarrior Development Studio

To install the CodeWarrior Development Studio Special Edition, insert the CodeWarrior CD-ROM into your computer's CD-ROM drive. A startup window will automatically appear. Follow the on-screen instructions.

3.5.2 Installing SofTec Microsystems Additional Components

The SofTec Microsystems Additional Components install all of the other required components to your hard drive. These components include:

- The Starter Kit's USB driver;
- The software plug-in for CodeWarrior;
- DataBlaze programming utility;

- Examples;
- Starter Kit's specific user's manual;
- Starter Kit's specific schematic;
- Additional documentation.

To install the SofTec Microsystems Additional Components, insert the SofTec Microsystems **“System Software”** CD-ROM into your computer's CD-ROM drive. A startup window will automatically appear. Choose **“Install Instrument Software”** from the main menu. A list of available software will appear. Click on the **“Additional Components”** option. Follow the on-screen instructions.



Note: *to install the Additional Components on Windows 2000 or Windows XP, you must log in as Administrator.*

3.6 Installing the Hardware


The Starter Kit is connected through a USB port to a host PC. Connection steps are listed below in the recommended flow order:

1. Install all the required system software as described in the previous section.
2. Power up the Starter Kit. The power connector accepts a 12 V DC, wall plug-in power supply with a 2.1 mm pin and sleeve plug with positive in the center and sleeve as ground. The green **“POWER”** LED on the board should turn on.
3. Insert one end of the USB cable into a free USB port on the host PC.
4. Insert the other end of the USB cable into the USB connector on the Starter Kit board.
5. The first time the Starter Kit is connected to the PC, Windows recognizes the instrument and starts the **“Found New Hardware Wizard”** procedure, asking you to specify the driver to use for the instrument. On Windows XP (SP2) the following dialog box will appear, asking you to search for a suitable driver on the web.



Select the **“No, not this time”** option and click the **“Next >”** button.

6. The following dialog box will appear.



Click the **“Next >”** button.

7. Depending on your Windows settings, the following warning may appear.

3



Note: *this warning is related to the fact that the USB driver used by the Starter Kit is not digitally signed by Microsoft, and Windows considers it to be potentially malfunctioning or dangerous for the system. However, you can safely ignore the warning, since every kind of compatibility/security test has been carried out by SofTec Microsystems.*

Click the “**Continue Anyway**” button.

8. Windows will install the driver files to your system. At the end of the installation, the following dialog box will appear.



Click the **“Finish”** button to exit from the **“Found New Hardware Wizard”** procedure.


9. The Starter Kit's USB driver is now installed on your system.

3.7 Application Tutorial


This section will provide a step-by-step guide on how to launch your project and get started with the CodeWarrior user interface.

1. Ensure that the Starter Kit is connected to the PC (via the USB cable) and that the board is powered.
2. Make sure that all of the Starter Kit's jumpers are set to their factory position (see the *“Summary of Jumper and Connector Settings”* section in the Starter Kit's specific manual).
3. Start CodeWarrior Development Studio by selecting **“Start > Programs > SofTec Microsystems > SK and ZK-HC08 Series > CodeWarrior Development Studio”**. CodeWarrior Development Studio will open.
4. From the main menu, choose **“File > Open”**. Select the **“Demo.mcp”** workspace file that is located under the **“\Program Files\SofTec Microsystems\SK and ZK-HC08 Series\CodeWarrior Examples \[Your Starter Kit Code]\[Your Target Microcontroller]Demo”** directory. Click **“Open”**. The following window will appear.

3




5. The C code of this example is contained in the “**main.c**” file. Double click on it to open it. The following window will appear.



- From the main menu, choose **“Project > Debug”**. This will compile the source code, generate an executable file and download it to the Starter Kit board.
- A new debugger environment will open.

3



8. From the main menu, choose **“Run > Start/Continue”**. The program will be executed in real-time. By rotating the potentiometer on the Starter Kit board, you affect the results of the A/D conversion, and the result of each conversion is displayed on the Starter Kit’s output section.
9. From the main menu, choose **“Run > Halt”**. The program execution will stop. The next instruction to be executed is highlighted in the *Source* window.
10. From the main menu, choose **“Run > Single Step”**. The instruction highlighted in the *Source* window will be executed, and the program execution will be stopped immediately after.
11. From the main menu, choose **“Run > Start/Continue”**. The application will restart from where it was previously stopped.

Congratulations! You have successfully completed this tutorial! You can continue to experiment with the CodeWarrior user interface and discover by yourself its potentialities. For an in-depth guide of all of the user interface



features, select “**Help > CodeWarrior Help**” from the CodeWarrior Development Studio’s main menu.



4 Debugging Features

4.1 Creating Your Own Application


4.1.1 Using the Project Wizard to Create Your Application Skeleton

CodeWarrior Development Studio helps you get started with your own application by including a project wizard specific for HC08-based SofTec Microsystems boards. To create a new project:

1. From the main menu, select “**File > New**”.
2. A dialog box will appear. Select “**HC(S)08 New Project Wizard**”.
3. Follow the Project Wizard steps, making sure you select the correct microcontroller derivative you are working with and that the “**SofTec Microsystems**” target connection is used.

4.1.2 Starting your First Debugging Session

The first time you enter a debugging session (by selecting “**Project > Debug**” from the CodeWarrior’s main menu) the *MCU Configuration* dialog box will open, asking you to select the debugging hardware connected to the PC and the target microcontroller you are working with.



First, ensure that the “**HW code**” parameter is set to your Starter Kit code, then set the “**Device code**” parameter to the specific target microcontroller you are working with. Additional communication parameters can be specified by clicking the “**Communication Settings**” button (if the button is enabled).


4

4.2 GDI Target Interface Notes

The Starter Kit’s built-in USB to MON08 interface is based on the SofTec Microsystems’ inDART debugging engine. CodeWarrior is interfaced to the inDART engine through a so-called “GDI Target Interface”.


If your project has been targeted to an emulator/simulator other than a SK-HC08 or ZK-HC08 Series Starter Kit and you wish to use this Starter Kit as the debugger for your project, please do the following:

1. From the CodeWarrior debugger interface, select “**Component > Set Target**” and choose “**HC08**” as processor and “**GDI Target Interface**” as target interface.




2. A dialog box will appear asking you to locate the GDI DLL file needed to interface with the Starter Kit. Select the **"inDART-HC08.dll"** file located in the **"\Program Files\Metrowerks\CodeWarrior CW08\prog\"** directory (the Starter Kit is based on the SofTec Microsystems' inDART debugging engine).

4



3. The *MCU Configuration* dialog box will appear allowing you to select the Starter Kit board as the hardware debugger. You must also specify the target microcontroller you are working with.



4. On the CodeWarrior debugger interface a new menu (“**inDART-HC08**”) will be created. From this menu, select “**Load**” and locate the file your project is based on.

4

4.3 Limitations

Since the debugger is based on the on-chip debugging features of the HC08 family of microcontrollers, some hardware and software limitations apply. The main ones are listed below; for the complete list of limitations please refer to the microcontroller’s data sheet.

- The pin dedicated to the host communication is reserved—in particular, the corresponding bit in the Data Direction Register must not be changed (must be left to input);
- The Break Module peripheral is reserved, and only one hardware breakpoint is available—however, you can insert a “**swi**” instruction into your code to generate a software breakpoint;
- The “**swi**” instruction is reserved and can only be used to generate a software breakpoint;
- Step commands which involve the execution of two or more Assembly instructions waste one hardware breakpoint—therefore, if one breakpoint was already set by the user, the step command cannot be executed;
- The “**Halt**” debugging command (in the CodeWarrior IDE) will not work unless the IRQ interrupt is properly handled;

- 13 bytes of stack are wasted by the on-chip monitor—therefore the addresses from SP-13 to SP are reserved;
- Registers which affect the target microcontroller's clock speed must not be changed during debugging sessions.

4.4 Trimming Feature

Some microcontrollers in the HC08 family feature an internal, trimmable oscillator designed to be used without additional external components (no crystals, resonators, or passive components are required), thus reducing production costs and eliminating the need for dedicated clock circuitry microcontroller pins.

Some devices (e.g. MC68HC908QT/QY) are factory pre-programmed with a default trimming value in a dedicated FLASH location (specified in the datasheet). However, due to the different real-world conditions of the user's system, it is always suggested to recalibrate the internal oscillator to reflect the actual working conditions.

The *Trimming Settings* dialog box allows you to enable/disable the trimming feature. If enabled, it is possible to specify whether to save the calculated trimmed value in the default location (the location suggested either by Freescale or SofTec Microsystems, restorable at any moment via the “**Restore**” button) or into a different location (specified by the “**Flash Trimming Location**” parameter). The calculation of the trimmed value and its writing to the specified address are carried out transparently when programming the device (or during download when debugging).

If you don't want to reserve a FLASH location for the calibration, but use it as “normal” memory instead, it is possible to disable the trimming feature and therefore free the trimming FLASH location for application purposes.

To open the *Trimming Settings* dialog box choose “**inDART-HC08 > MCU Configuration > Communication Settings > Trimming Settings**” from the CodeWarrior main menu, after entering a debugging session.

4.5 Notes and Tips

4.5.1 Stop Command Handling

The “**Halt**” debugging command will not work unless the IRQ interrupt is properly handled. In particular, the following precautions must be taken in the application’s source code.

1. Global interrupts must be enabled (use the “**cli**” instruction);
2. The IRQ interrupt must be enabled;
3. The IRQ interrupt vector must be handled;
4. The IRQ handling routine must include the following code:

```

irq_isr: bil irq_isr      ; Waits for the IRQ signal to go high
swi                      ; Jumps to monitor code
rti
  
```

5. Under these conditions, the TGT_IRQ# line is reserved; when it is driven low, a “**Halt**” debugging command is automatically recognized.

Reading Peripheral Status

Care must be taken when reading some peripheral’s status/data registers, since a reading operation may cause the clearing of flags. This may happen when the *Memory* window or the *Data* window is open, since these windows read microcontroller’s resources during refresh operations.

4.5.2 Breakpoints and Swi Instruction

The SWI Assembly instruction forces the target microcontroller to enter the Monitor mode, stopping program execution. CodeWarrior recognizes this event as a breakpoint and updates the contents of registers, memory, etc. Successive commands (Start/Continue, Single Step, etc.) will continue the execution of the program from the next instruction. The HC08’s on-chip debug module only handles one hardware breakpoint. However, you can

force the program execution to stop at other specific locations by inserting the “**swi**” Assembly instruction on your source code.

4.5.3 Interrupt Execution during Steps

When issuing stepping instructions (Single Step, Step Over, etc.) when there are pending interrupts, the debugger will not step inside the interrupt handling routine—instead, the whole interrupt handling routine will be executed. An exception is when you single step on an Assembly instruction which branches to itself: in this case, interrupts which may occur will not be handled.

4.5.4 Peripheral Status during Steps

When single stepping on an Assembly instruction which branches to itself, peripheral status is frozen.

4

4.5.5 Hardware Breakpoints and Software Breakpoints

A “hardware” breakpoint is set by taking advantage of the microcontroller’s integrated break peripheral. A hardware breakpoint doesn’t waste system resources, you can set/remove them at any time, but the number of available hardware breakpoints is limited (to one in the case of HC08 family).

A “software” breakpoint, on the other hand, does not take advantage of the microcontroller’s integrated break peripheral.

To set a software breakpoint in a FLASH location, you have to insert the “**swi**” Assembly instruction into your application’s source code, recompile the code and restart a debug session. The program execution will stop as soon as the “**swi**” instruction is fetched.

4.6 DataBlaze Programming Utility

A full-featured programming utility (DataBlaze) is also provided with the Starter Kit. To start the DataBlaze utility select “**Start > Programs > SofTec Microsystems > SK and ZK-HC08 Series > DataBlaze Programmer**”.

DataBlaze offers the following advanced features:



Programming Features

- Code/data memory editing;
- Blank check/erase/program/verify/read operations;
- Project handling;
- One-button, multiple-operations programming (“Auto” feature);
- Serial numbering.

4

The screenshot displays the DataBlaze Programmer software interface. The main window shows a memory dump with addresses from 0450 to 0590 and data values, many of which are 'FF' or 'XX'. An 'Auto' dialog box is open in the center, listing programming steps with checkboxes: 'Mass Erase Code' (checked), 'Blank Check Code' (checked), 'Program Code' (checked), 'Verify Code' (unchecked), 'Mass Erase Data' (unchecked), 'Blank Check Data' (unchecked), 'Program Data' (unchecked), and 'Verify Data' (unchecked). The 'Start' and 'Exit' buttons are visible in the dialog. On the right side, a panel shows device information: Driver: Softec MON08, HC08 Programmer v. 1.12.5; Device: Freescale MC68HC908A260A; Code Memory: Device Range 0450h - FFFh, Buffer Range 0450h - FFFh, Checksum 749Ah; Data Memory: 0600h - FF7Ch; Option Bytes: Not Available. The status bar at the bottom indicates 'Ready', 'Freescale - MC68HC908A260A', '2K-HC08A1-A', and 'HC08 FLASH MCLs (FLASH=60k;x8)'.

5 Troubleshooting

5.1 Common Problems and Solutions

This section reports solutions to some common problems that may arise during general use.

5.1.1 USB Driver Problems

If you connected the Starter Kit board to the PC before installing the CodeWarrior user interface and the SofTec Microsystems Additional Components, the Starter Kit USB driver may not have been correctly installed on your system. Unplugging and replugging the USB cable is of no use, since Windows has marked the device as “disabled”. As a consequence, CodeWarrior cannot communicate with the Starter Kit board. To restore the USB driver (provided both CodeWarrior and SofTec Microsystems Additional components have been installed), perform the following steps under Windows XP:

1. Make Sure the Starter Kit is powered on.
2. Connect the Starter Kit to the PC (via USB).
3. Open the Control Panel (“**Start > Settings > Control Panel**”).
4. Open the “**System**” options.
5. Select the “**Hardware**” tab.
6. Click the “**Device Manager**” button.
7. The “**uDART In-Circuit Debugger**” device will be shown with an exclamation mark next to it. Double click on this device.
8. In the “**General**” tab, click the “**Reinstall Driver**” button. Follow the on-screen instructions.

5.1.2 Communication Errors when Using a MON08 Tool

When using an external in-circuit debugger/programmer, the built-in USB to MON08 interface must be bypassed. To bypass the built-in USB to MON08 interface, please remove all of its **“ENA”** jumpers.

For more information on how to set up the **“MON08”** and **“EMON08”** connectors, see the *“Operating Mode: Host Mode”* section of this manual on page 16.

5.1.3 Communication Can't Be Established with the Board (Via the Integrated USB to MON08 Interface)

1. Make sure the Starter Kit is connected to the PC and powered on.
2. Make sure that all of the **“ENA”** jumpers in the **“USB TO MON08 INTERFACE”** section are inserted;
3. Make sure that nothing is connected to the **“MON08”** connector;
4. Make sure that all of the **“EMON08”** connector jumpers are inserted (see the *“Summary of Jumper and Connector Settings”* chapter on the Starter Kit's specific user's manual);
5. Make sure you are working with the correct hardware model. To view/change the hardware model in use, choose **“inDART-HC08 > MCU Configuration”** from the CodeWarrior debugger's main menu.
6. If the **“inDART-HC08”** menu is not present in the CodeWarrior debugger's main menu, this is because the target has not been recognized by CodeWarrior (“No link to Target” appears in the status bar). In this case, from the **“GDI”** menu, choose **“MCU Configuration”** and verify that the hardware code is set correctly.
7. Make sure the target microcontroller is working. Programming and debugging rely on a MON08 communication between the USB to MON08 interface and the target microcontroller. This means that, in order to work correctly, the target microcontroller must be running. In particular:
 - On ZK-HC08 Series Starter Kits, make sure that the target microcontroller is correctly inserted in the ZIF socket;
 - On ZK-HC08 Series Starter Kits which feature a **“VDD SEL”** jumper (in the **“POWER SUPPLY”** section), make sure that this

- jumper selects the appropriate voltage for the specific microcontroller you are working with;
 - The oscillator circuitry must be working according to the microcontroller specifications.
8. For other problems, please refer to your Starter Kit's specific user's manual.

5.2 Getting Technical Support

Technical assistance is provided free to all customers. For technical assistance, documentation and information about products and services, please refer to your local SofTec Microsystems partner.

SofTec Microsystems offers its customers a free technical support service at *support@softecmicro.com*. Before getting in contact with us, we advise you to check that you are working with the latest version of the Starter Kit system software (upgrades are available free of charge at *http://www.softecmicro.com*). Additional resources can be found on our HC(S)08 online discussion forum.





