

1 Overview

This document guides you through the processes of downloading and running this release package. It only explains how to download and run the default release image with default configuration. For details on using the release package, see the *Android™ User's Guide (AUG)* included in this release package.

2 Hardware Requirements

The hardware requirements for using this release package are as follows:

Supported system-on-chips (SoCs):

- i.MX 8M Mini
- i.MX 8M Quad
- i.MX 8QuadMax (Silicon Revision B0)
- i.MX 8QuadXPlus (Silicon Revision B0)

Supported boards:

- EVK board and Platform
- MEK board and Platform

3 Working with the i.MX 8M Mini EVK Board

3.1 Board hardware

The figure below shows the different components of the i.MX 8M Mini EVK LPDDR4 board.

Contents

1 Overview	1
2 Hardware Requirements	1
3 Working with the i.MX 8M Mini EVK Board	1
4 Working with the i.MX 8M Quad EVK Board	9
5 Working with the i.MX 8QuadMax MEK Board	18
6 Working with the i.MX 8QuadXPlus MEK Board	24
7 Revision History	30






Figure 1. i.MX 8M Mini EVK LPDDR4 board

The figures below show the different components of the i.MX 8M Mini EVK board.




Figure 2. i.MX 8M Mini EVK DDR4 board




Figure 3. i.MX 8M Mini EVK with audio board



Figure 4. i.MX 8M Mini SAS cable with DSI-to-HDMI adapter



Figure 5. i.MX MIPI panel



Figure 6. i.MX MIPI camera

NOTE

- To test the MIPI-DSI to HDMI display, use the i.MX mini SAS cable to connect the DSI-to-HDMI adapter to the "HDMI DSI" port.
- To test the MIPI panel display, connect the i.MX MIPI panel to the "HDMI DSI" port.
- To test the camera, connect the i.MX CSI MIPI Camera to the "Camera" port.
- The QCOM 1PJ Wi-Fi/Bluetooth module is used on the i.MX 8M Mini EVK LPDDR4 Board.
- The BCM 1MW Wi-Fi/Bluetooth module is used on the i.MX 8M Mini EVK DDR4 Board.
- "i.MX 8M Mini EVK REV B/C" indicates the revision of the base board.

3.2 Board images

To test prebuilt images with the LPDDR4 board, use android-10.0.0_1.0.0_image_8mmevk.tar.gz.

To test prebuilt images with the DDR4 board, use android-10.0.0_1.0.0_image_8mmevkddr4.tar.gz.

The table below describes the location in the board partitions of the software images in android-10.0.0_1.0.0_image_8mmevk.tar.gz.

Table 1. Board images

Image name	Download target
spl-imx8mm-dual.bin	33 KB offset of MMC for a board with LPDDR4 on it.
spl-imx8mm-trusty-dual.bin	33 KB offset of MMC for a board with LPDDR4 on it.
bootloader-imx8mm-dual.img	bootloader_a and bootloader_b partitions.
bootloader-imx8mm-trusty-dual.img	bootloader_a and bootloader_b partitions.
u-boot-imx8mm.imx	33 KB offset of MMC for a board with LPDDR4 on it.
u-boot-imx8mm-trusty.imx	33 KB offset of MMC for a board with LPDDR4 on it.
u-boot-imx8mm-trusty-secure-unlock.imx	33 KB offset of MMC for a board with LPDDR4 on it.
u-boot-imx8mm-evk-UUU.imx	The bootloader used by UUU for i.MX 8M Mini board with LPDDR4 on it. It will not be flashed to MMC.
imx8mm_mcu_demo.img	5120 KB offset of MMC.
partition-table.img	0 offset of MMC. It is used for single bootloader condition and the target storage device should be larger than 13 GB.
partition-table-dual.img	0 offset of MMC. It is used for dual bootloader condition and the target storage device should be larger than 13 GB.
partition-table-28GB.img	0 offset of MMC. It is used for single bootloader condition and the target storage device should be larger than 28 GB.
partition-table-28GB-dual.img	0 offset of MMC. It is used for dual bootloader condition and the target storage device should be larger than 28 GB.
boot.img	boot_a and boot_b partitions.
boot-debug.img	boot_a and boot_b partitions when doing VTS test with GSI system image.
vbmeta-imx8mm.img	vbmeta_a and vbmeta_b partitions to support LPDDR4 and MIPI-to-HDMI output and DSD playback.

Table continues on the next page...

Table 1. Board images (continued)

vbmeta-imx8mm-m4.img	vbmeta_a and vbmeta_b partitions to support LPDDR4, MIPI-to-HDMI output and audio playback based on m4 freeRTOS.
vbmeta-imx8mm-mipi-panel.img	vbmeta_a and vbmeta_b partitions to support LPDDR4 and MIPI panel output.
system.img	system_a and system_b partitions.
vendor.img	vendor_a and vendor_b partitions.
product.img	product_a and product_b partitions.
dtbo-imx8mm.img	dtbo_a and dtbo_b partitions to support LPDDR4 and MIPI-to-HDMI output and DSD(Direct Stream Digital) playback.
dtbo-imx8mm-m4.img	dtbo_a and dtbo_b partitions to support LPDDR4, MIPI-to-HDMI output and audio playback based on m4 freeRTOS.
dtbo-imx8mm-mipi-panel.img	dtbo_a and dtbo_b partitions to support LPDDR4 and MIPI panel output.
rpmb_key_test.bin	Prebuilt test RPMB key, which can be used to set the RPMB key as fixed 32 bytes 0x00.
testkey_public_rsa4096.bin	Prebuilt AVB public key, which is extracted from the default AVB private key.

3.3 Flashing board images

The board image files can be flashed into the target board using Universal Update Utility (UUU).

For the UUU binary file, download it from github: [uuu release page on github](#).

To achieve more flexibility, two script files are provided to invoke UUU to automatically flash all Android images.

- uuu_imx_android_flash.sh for Linux OS
- uuu_imx_android_flash.bat for Windows OS

For this release, these two scripts are validated on UUU 1.3.102 version. Download corresponding version from github:

- For Linux OS, download the file named "uuu".
- For Windows OS, download the file named "uuu.exe".

Because the two script files will directly invoke UUU, make sure that UUU is in a path contained by the system environment variable of "PATH".

Perform the following steps to download the board images:

1. Download the UUU binary file from github as described before. Install UUU into a directory contained by the system environment variable of "PATH".
2. Make the board enter serial download mode.
 - For Rev. B boards, change the first two bits of board's sw1101 to 10 (from 1-2 bit) to enter serial download mode.
 - For Rev. C boards, change the first four bits of board's sw1101 to 1010 (from 1-4 bit) to enter serial download mode.
3. Power on the board. Use the USB cable on the board OTG port to connect your PC with the board.
4. Decompress release_package/android-10.0.0_1.0.0_image_8mmevk.tar.gz for LPDDR4 board or release_package/android-10.0.0_1.0.0_image_8mmevkddr4.tar.gz for DDR4 board. The package contains the image files and uuu_imx_android_flash tool.
5. Execute the uuu_imx_android_flash tool to flash images.

The `uuu_imx_android_flash` tool can be executed with options to get help information and specify the images to be flashed. For i.MX 8M Mini board, related options are described as follows.

Table 2. Options for `uuu_imx_android_flash` tool

Option	Description
-h	Displays help information of this tool.
-f soc_name	Specifies SoC information. For i.MX 8M Mini EVK, it should be "imx8mm". This option is mandatory .
-a	Only flashes slot a. If this option and "-b" option are not used, a and b slot are both flashed.
-b	Only flashes slot b. If this option and "-a" option are not used, slots a and b are both flashed.
-c card_size	Specifies which partition table image file to flash. For i.MX 8M Mini EVK, it can be followed with "28". If this option is not used, default "partition-table.img"/"partition-table-dual.img" is flashed.
-m	Flashes the MCU image. If this option is not used, the MCU image is not flashed.
-u uboot_feature	Flashes U-Boot or spl&bootloader image with "uboot_feature" in their names. For i.MX 8M Mini EVK LPDDR4, it can be "dual", "trusty-dual", "trusty-secure-unlock", and "trusty". If this option is not used, the default "u-boot-imx8mm.img" is flashed. For i.MX 8M Mini EVK DDR4, it should be "ddr4".
-d dtb_feature	Flashes dtbo and vbmeta images with "dtb_feature" in their names. For i.MX 8M Mini EVK LPDDR4, it can be "m4", "mipi-panel". For i.MX 8M Mini EVK DDR4, do not use this option. If this option is not used, default "dtbo-imx8mm.img" and "vbmeta-imx8mm.img" are flashed.
-e	Erases user data after images are flashed.
-D directory	Specifies the directory in which there are the images to be flashed. If this option is not used, images in the current working directory will be flashed.
-t target_dev	Specifies the target device. For i.MX 8M Mini EVK, it can be "emmc" and "sd". If this option is not used, images will be flashed to emmc.
-daemon	Run UUU in daemon mode. This option is used to flash multiple boards of the same type.
-i	If the script is executed with this option, no images will be flashed. The script just load U-Boot to RAM and execute to fastboot mode. This option is used for development.
-dryrun	Only generate a UUU script but not execute UUU with this script.

Obviously, "-m" and "-d m4" should be used together.

- On Linux system, open the shell terminal. For example, you can execute a command as follows:

```
> sudo ./uuu_imx_android_flash.sh -f imx8mm -a -e -u trusty
```

- On Windows system, open the command line interface in administrator mode. The corresponding command is as follows:

```
> .\uuu_imx_android_flash.bat -f imx8mm -a -e -u trusty
```

When the command above is executed, `u-boot-imx8mm-trusty.img` with other default images will be flashed into eMMC slot a for i.MX 8M Mini EVK.

NOTE

- "-u" followed with a parameter and containing "trusty" cannot be used together with "-t sd", because Trusty OS cannot boot from SD card.
- To flash SD card, execute the tool with "-t sd". To flash eMMC, it does not need to use -t option.
- If your SD card is 16 GB or uses onboard eMMC as the boot device, it does not need to use -c option.
- If your SD card is 32 GB, execute the tool with "-c 28".
- To test features on i.MX8M Mini EVK LPDDR4 board:
 - To test Trusty OS, execute the tool with "-u trusty".
 - To test dual bootloader, execute the tool with "-u dual".
 - To test Trusty OS and dual bootloader both enabled condition, execute the tool with "-u trusty-dual".
 - To test the demonstration implementation of secure unlock, execute the tool with "-u trusty-secure-unlock". For secure unlock details, see the *i.MX Android Security User's Guide (ASUG)*.
 - To test MIPI-DSI to HDMI output, it does not need to use -d option.
 - To test MIPI panel output, execute the tool with "-d mipi-panel".
 - To test support MIPI-to-HDMI output and audio playback based on Cortex-M4 FreeRTOS, execute the tool with "-m" and "-d m4".
- To test features on i.MX 8M Mini EVK DDR4 board:
 - Execute the tool with "-u ddr4".
- uuu_imx_android_flash.bat generates a temporary file under the current working directory. Make sure you have Write permission under the current working directory.
- If uuu_imx_android_flash.bat is used to flash images on a remote server through samba, you need to map the remote resource to the local environment first. Take the following command as an example:

```
> net use z: \\192.168.1.1\daily_images
```

"z" in the command represents an available drive letter. It can be other available drive letter.

6. Wait for the uuu_imx_android_flash execution to complete. If there is not any error, you will get information on the command window indicating that images are already flashed.
7. Power off the board.
8. Change boot device as eMMC or SD card.

For Rev. B boards:

- Change sw1101 to 01110010 and change sw1102 to 00101010 if you want to boot from eMMC.
- Change sw1101 to 01000110 and change sw1102 to 00110100 if you want to boot from SD card.

For Rev. C boards:

- Change sw1101 to 0110110010 and change sw1102 to 0001101000 if you want to boot from SD card.

3.4 Booting

After downloading the images, reboot the board using the power on/off switch.

3.4.1 Booting with Single MIPI-to-HDMI or MIPI panel display

In the U-Boot prompt, set the U-Boot environment variables as follows:

- i.MX 8M Mini EVK LPDDR4 Board:

```
U-Boot > setenv bootargs console=ttyMX1,115200 earlycon=ec_imx6q,0x30890000,115200 init=/init
androidboot.console=ttyMX1 androidboot.hardware=freescale cma=800M@0x400M-0xb80M
androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

- i.MX 8M Mini EVK DDR4 Board:

```
U-Boot > setenv bootargs console=ttyMX1,115200 earlycon=ec_imx6q,0x30890000,115200 init=/init
androidboot.console=ttyMX1 androidboot.hardware=freescale cma=800M@0x400M-0xb80M
androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

3.4.2 Booting with Single MIPI-to-HDMI display and audio playback based on Cortex-M4 FreeRTOS

In the U-Boot prompt, set the U-Boot environment variables as follows:

- i.MX 8M Mini EVK LPDDR4 Board:

```
U-Boot > setenv bootargs console=ttyMX1,115200 earlycon=ec_imx6q,0x30890000,115200 init=/init
androidboot.console=ttyMX1 androidboot.hardware=freescale cma=800M@0x400M-0xb80M
androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > setenv bootcmd "bootmcu && boota"
U-Boot > saveenv
```

NOTE

To use other dtbo images, do not add "bootmcu" to "bootcmd". The following command can recover bootcmd:

```
U-Boot > setenv bootcmd "boota"
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

3.5 Board reboot

After you have completed download and setup, reboot the board and wait for the Android platform to boot up.

4 Working with the i.MX 8M Quad EVK Board

4.1 Board hardware

The figures below show the different components of the i.MX 8M Quad EVK board.





Figure 7. i.MX 8M Quad EVK board



Audio Output

Audio Input

Figure 8. i.MX 8M Quad EVK with audio board



Figure 9. i.MX mini SAS cable with DSI-to-HDMI adapter



Figure 10. i.MX MIPI panel



Figure 11. i.MX MIPI camera

NOTE

- To test the MIPI-DSI to HDMI display, use the i.MX mini SAS cable to connect the DSI-to-HDMI adapter to the "HDMI DSI" port.
- To test the MIPI panel display, connect the i.MX MIPI panel to the "HDMI DSI" port.
- To test the camera, connect the i.MX CSI MIPI Camera to the "Camera" port.
- The BCM 1CX Wi-Fi/Bluetooth module is used on the i.MX 8MQuad Rev. A Board.

4.2 Board images

The table below describes the location in the board partitions of the software images in `android-10.0.0_1.0.0_image_8mqevk.tar.gz`.

Table 3. Board images

Image name	Download target
spl-imx8mq-dual.bin	33 KB offset of MMC.
spl-imx8mq-trusty-dual.bin	33 KB offset of MMC.
bootloader-imx8mq-dual.img	bootloader_a and bootloader_b partitions.
bootloader-imx8mq-trusty-dual.img	bootloader_a and bootloader_b partitions.
u-boot-imx8mq.imx	33 KB offset of MMC.
u-boot-imx8mq-trusty.imx	33 KB offset of MMC.
u-boot-imx8mq-trusty-secure-unlock.imx	33 KB offset of MMC.
u-boot-imx8mq-evk-uuu.imx	Bootloader used by UUU for i.MX 8M Quad board, which is not flashed to MMC..
partition-table.img	0 offset of MMC. It is used for single bootloader condition and the target storage device should be larger than 13 GB.
partition-table-dual.img	0 offset of MMC. It is used for dual-bootloader condition and the target storage device should be larger than 13 GB.
partition-table-28GB.img	0 offset of MMC. It is used for single bootloader condition and the target storage device should be larger than 28 GB.
partition-table-28GB-dual.img	0 offset of MMC. It is used for dual-bootloader condition and the target storage device should be larger than 28 GB.
boot.img	boot_a and boot_b partitions.
boot-debug.img	boot_a and boot_b partitions when doing VTS test with GSI system image.
vbmeta-imx8mq.img	vbmeta_a and vbmeta_b partitions to support i.MX 8M Quad Rev. A board HDMI output and DSD playback.
vbmeta-imx8mq-mipi.img	vbmeta_a and vbmeta_b partitions to support i.MX 8M Quad Rev. A board MIPI-to-HDMI output.
vbmeta-imx8mq-dual.img	vbmeta_a and vbmeta_b partitions to support i.MX 8M Quad Rev. A board HDMI and MIPI-to-HDMI dual output.
vbmeta-imx8mq-mipi-panel.img	vbmeta_a and vbmeta_b partitions to support i.MX 8M Quad Rev. A board MIPI panel output.
system.img	system_a and system_b partitions.
vendor.img	vendor_a and vendor_b partitions.
product.img	product_a and product_b partitions.
dtbo-imx8mq.img	dtbo_a and dtbo_b partitions to support i.MX 8M Quad Rev. A board HDMI output and DSD playback.
dtbo-imx8mq-mipi.img	dtbo_a and dtbo_b partitions to support i.MX 8M Quad Rev. A board MIPI-to-HDMI output.
dtbo-imx8mq-dual.img	dtbo_a and dtbo_b partitions to support i.MX 8M Quad Rev. A board HDMI and MIPI-to-HDMI dual output.
dtbo-imx8mq-mipi-panel.img	dtbo_a and dtbo_b partitions to support i.MX 8M Quad Rev. A board MIPI panel output.

Table continues on the next page...

Table 3. Board images (continued)

rpmb_key_test.bin	Prebuilt test RPMB key, which can be used to set the RPMB key to fixed 32 bytes 0x00.
testkey_public_rsa4096.bin	Prebuilt AVB public key, which is extracted from the default AVB private key.

4.3 Flashing board images

The board image files can be flashed into the target board using Universal Update Utility (UUU).

For the UUU binary file, download it from github: [uuu release page on github](#).

To achieve more flexibility, two script files are provided to invoke UUU to automatically flash all Android images.

- uuu_imx_android_flash.sh for Linux OS
- uuu_imx_android_flash.bat for Windows OS

For this release, these two scripts are validated on UUU 1.3.102 version. Download corresponding version from github:

- For Linux OS, download the file named "uuu".
- For Windows OS, download the file named "uuu.exe".

Because the two script files will directly invoke UUU, make sure that UUU is in a path contained by the system environment variable of "PATH".

Perform the following steps to download the board images:

1. Download the UUU binary file from github as described before. Install UUU into a directory contained by the system environment variable of "PATH".
2. Make the board enter serial download mode.
Change the board's sw802 (boot mode) to 01 (from 1-2 bit) to enter serial download mode.
3. Power on the board. Use the USB cable on the board USB 3.0 port to connect your PC with the board.

NOTE

- There are three USB ports on the i.MX 8M Quad EVK board: USB-to-UART, USB 3.0 host, and USB 3.0 OTG. The USB-to-UART can be referenced as the debug UART in the hardware image above. The debug UART can be used to watch the log of the hardware boot processing.
- The SD card must be plugged in after the board is powered on.

4. Decompress release_package/android-10.0.0_1.0.0_image_8mqevk.tar.gz, which contains the image files and uuu_imx_android_flash tool.
5. Execute the uuu_imx_android_flash tool to flash images.

The uuu_imx_android_flash tool can be executed with options to get help information and specify the images to be flashed. For i.MX 8M Quad board, related options are described as follows

Table 4. Options for uuu_imx_android_flash tool

Option	Description
-h	Displays help information of this tool.
-f soc_name	Specifies SoC information. For i.MX 8M Quad EVK, it should be "imx8mq". This option is mandatory .
-a	Only flashes slot a. If this option and "-b" option are not used, slots a and b are both flashed.

Table continues on the next page...

Table 4. Options for uuu_imx_android_flash tool (continued)

-b	Only flashes slot b. If this option and "-a" option are not used, slots a and b are both flashed.
-c card_size	Specifies which partition table image file to flash. For i.MX 8M Quad EVK, it can be followed with "28". If this option is not used, default "partition-table.img"/"partition-table-dual.img" is flashed.
-u uboot_feature	Flashes U-Boot or spl&bootloader image with "uboot_feature" in their names. For i.MX 8M Quad EVK, it can be "dual", "trusty-dual", "trusty-secure-unlock", and "trusty". If this option is not used, default "u-boot-imx8mq.img" is flashed.
-d dtb_feature	Flashes dtbo and vbmeta images with "dtb_feature" in their names. For i.MX 8M Quad EVK, it can be "dual", "mipi-panel", "mipi". If this option is not used, default "dtbo-imx8mq.img" and "vbmeta-imx8mq.img" are flashed.
-e	Erases user data after images are flashed.
-D directory	Specifies the directory in which there are the images to be flashed. If this option is not used, images in current working directory will be flashed.
-t target_dev	Specifies the target device. For i.MX 8M Quad EVK, it can be "emmc" and "sd". If this option is not used, images are flashed to eMMC.
-daemon	Runs UUU in daemon mode. This option is used to flash multiple boards of the same type.
-i	If the script is executed with this option, no images are flashed. The script just loads U-Boot to RAM and executes to fastboot mode. This option is used for development.
-dryrun	Only generates a UUU script but not executes UUU with this script.

- On Linux system, open the shell terminal. For example, you can execute a command as follows:

```
> sudo ./uuu_imx_android_flash.sh -f imx8mq -a -e -u trusty
```

- On Windows system, open the command line interface in administrator mode. The corresponding command is as follows:

```
> .\uuu_imx_android_flash.bat -f imx8mq -a -e -u trusty
```

When the command above is executed, u-boot-imx8mq-trusty.img with other default images are flashed into the eMMC slot a for i.MX 8M Quad EVK.

NOTE

- "-u" followed with a parameter and containing "trusty" cannot be used together with "-t sd", because Trusty OS cannot boot from SD card.
- To flash the SD card, execute the tool with "-t sd". To flash eMMC, it does not need to use -t option.
- If your SD card is 16 GB or the on-board eMMC is used as the boot device, it does not need to use -c option.
- If your SD card is 32 GB, execute the tool with "-c 28".
- To test Trusty OS, execute the tool with "-u trusty".
- To test dual bootloader, execute the tool with "-u dual".
- To test Trusty OS and dual-bootloader both in enabled condition, execute the tool with "-u trusty-dual".
- To test the demonstration implementation of secure unlock, execute the tool with "-u trusty-secure-unlock". For secure unlock details, see the *i.MX Android Security User's Guide* (ASUG).
- To test feature on i.MX 8M Quad EVK Rev. A board:
 - To test HDMI output, it does not need to use -d option.
 - To test MIPI-to-HDMI output, execute the tool with "-d mipi".
 - To test MIPI panel output, execute the tool with "-d mipi-panel".
 - To test HDMI and MIPI-to-HDMI dual output, execute the tool with "-d dual".
- uuu_imx_android_flash.bat generates a temporary file under the current working directory. Make sure you have Write permission under the current working directory.
- If uuu_imx_android_flash.bat is used to flash images on a remote server through samba, you need to map the remote resource to the local environment first. Take the following command as an example:

```
> net use z: \\192.168.1.1\daily_images
```

"z" in the command represents an available drive letter. It can be other available drive letter.

6. Wait for the uuu_imx_android_flash execution to complete. If there is not any error, you will get information on the command window indicating that images are already flashed.
7. Power off the board.
8. Change boot device as eMMC or SD card. Change the board's sw802 (boot mode) to 10 (from 1-2 bit) to leave serial download mode.
 - Change SW801 to switch the board back to 1100 (SD boot mode).
 - Change SW801 to switch the board back to 0010 (eMMC boot mode).

4.4 Booting

After downloading the images, boot the board by connecting it to the power supply.

4.4.1 Booting with single display: HDMI display

In the U-Boot prompt, set the U-Boot environment variables as follows:

- i.MX 8M Quad EVK Rev. A Board:

```
U-Boot > setenv bootargs console=ttymxc0,115200 earlycon=ec_imx6q,0x30860000,115200 init=/init
androidboot.gui_resolution=1080p androidboot.console=ttymxc0 androidboot.hardware=freescale
cma=1280M androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.fbTileSupport=enable androidboot.wificountrycode=CN
androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

4.4.2 Booting with single display: MIPI-to-HDMI display

In the U-Boot prompt, set the U-Boot environment variables as follows:

- i.MX 8M Quad EVK Rev. A Board:

```
U-Boot > setenv bootargs console=ttyMXC0,115200 earlycon=ec_imx6q,0x30860000,115200 init=/init
androidboot.lcd_density=160 androidboot.console=ttyMXC0 androidboot.hardware=freescale cma=1280M
androidboot.primary_display=mxsfb-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.displaymode=720p androidboot.wificountrycode=CN
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

4.4.3 Booting with dual displays: HDMI and MIPI-to-HDMI displays

In the U-Boot prompt, set the U-Boot environment variables as follows:

- i.MX 8M Quad EVK Rev. A Board:

```
U-Boot > setenv bootargs console=ttyMXC0,115200 earlycon=ec_imx6q,0x30860000,115200 init=/init
androidboot.gui_resolution=1080p androidboot.console=ttyMXC0 androidboot.hardware=freescale
cma=1280M androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

4.4.4 Booting with single display: MIPI panel

In the U-Boot prompt, set the U-Boot environment variables as follows:

- i.MX 8M Quad EVK Rev. A Board:

```
U-Boot > setenv bootargs console=ttyMXC0,115200 earlycon=ec_imx6q,0x30860000,115200 init=/init
androidboot.console=ttyMXC0 androidboot.hardware=freescale cma=1280M
androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

4.5 Board reboot

After you have completed download and setup, reboot the board and wait for the Android platform to boot up.

5 Working with the i.MX 8QuadMax MEK Board

5.1 Board hardware

The figures below show the different components of the i.MX 8QuadMax MEK board.




Figure 12. i.MX 8QuadMax MEK board



Figure 13. i.MX mini SAS cable with DSI-to-HDMI adapter



Figure 14. i.MX mini SAS cable with LVDS-to-HDMI adapter



Figure 15. i.MX MIPI panel



Figure 16. i.MX MIPI camera

NOTE

- To test the MIPI-DSI to HDMI display, use the i.MX mini SAS cable to connect the DSI-to-HDMI adapter to the "HDMI DSI" port.
- To test the LVDS-to-HDMI display, use the i.MX mini SAS cable to connect the LVDS-to-HDMI adapter to the "LVDS0/LVDS1" port.
- To test the camera, connect two i.MX MIPI cameras to the "MIPI Camera0" and "MIPI Camera1" ports.
- To test the MIPI panel display, connect the i.MX MIPI panel to the "MIPI DSI" port.
- To test single camera, connect i.MX MIPI Camera to the "MIPI Camera0" or "MIPI Camera1" port.
- To test dual cameras, use the the i.MX mini SAS cable to connect both "LVDS0" and "LVDS1" ports with the LVDS-to-HDMI adapter.

5.2 Board images

The table below describes the location in the board partitions of the software images in android-10.0.0_1.0.0_image_8qmek.tar.gz.

Table 5. Board images

Image name	Download target
u-boot-imx8qm.imx	0 KB offset of eMMC and 32 KB offset of SD card.
u-boot-imx8qm-trusty.imx	0 KB offset of eMMC.
u-boot-imx8qm-trusty-secure-unlock.imx	0 KB offset of eMMC.
u-boot-imx8qm-mek-uuu.imx	Bootloader used by UUU for i.MX 8QuadMax MEK board. It is not flashed to MMC.
partition-table.img	Programs to first 17 KB, and then back up to last 17 KB of the boot storage. GPT image for boot storage larger than 13 GB.
partition-table-28GB.img	Programs to first 17 KB, and then back up to last 17 KB of the boot storage. GPT image for boot storage larger than 28 GB.
boot.img	boot_a and boot_b partitions.
boot-debug.img	boot_a and boot_b partitions when doing VTS test with GSI system image.
vbmeta-imx8qm.img	vbmeta_a and vbmeta_b partitions to support LVDS-to-HDMI/MIPI-to-HDMI display.
vbmeta-imx8qm-hdmi.img	vbmeta_a and vbmeta_b partitions to support physical HDMI display.
vbmeta-imx8qm-mipi-panel.img	vbmeta_a and vbmeta_b partitions to support MIPI panel display.
system.img	system_a and system_b partitions.
vendor.img	vendor_a and vendor_b partitions.

Table continues on the next page...

Table 5. Board images (continued)

product.img	product_a and product_b partitions.
dtbo-imx8qm.img	dtbo_a and dtbo_b partitions to support LVDS-to-HDMI/MIPI-to-HDMI display.
dtbo-imx8qm-hdmi.img	dtbo_a and dtbo_b partitions to support physical HDMI display.
dtbo-imx8qm-mipi-panel.img	dtbo_a and dtbo_b partitions to support MIPI panel display.
rpmb_key_test.bin	Prebuilt test RPMB key. It can be used to set the RPMB key to fixed 32 bytes 0x00.
testkey_public_rsa4096.bin	Prebuilt AVB public key, which is extracted from the default AVB private key.

5.3 Flashing board images

The board image files can be flashed into the target board using Universal Update Utility (UUU).

For the UUU binary file, download it from github: [uuu release page on github](#).

To achieve more flexibility, two script files are provided to invoke UUU to automatically flash all Android images.

- uuu_imx_android_flash.sh for Linux OS
- uuu_imx_android_flash.bat for Windows OS

For this release, these two scripts are validated on UUU 1.3.102 version. Download corresponding version from github:

- For Linux OS, download the file named "uuu".
- For Windows OS, download the file named "uuu.exe".

Because the two script files will directly invoke UUU, make sure that UUU is in a path contained by the system environment variable of "PATH".

Perform the following steps to download the board images:

1. Download the UUU binary file from github as described before. Install UUU into a directory contained by the system environment variable of "PATH".
2. Make the board enter serial download mode.
Change the board's SW2 (boot mode) to 001000 (from 1-6 bit) to enter serial download mode.
3. Power on the board. Use the USB cable on the board USB 3.0 port to connect your PC with the board.

NOTE

- There are three USB ports on the i.MX 8QuadMax MEK board: USB-to-UART, USB 2.0, and USB 3.0.
- The USB-to-UART port can be referenced as debug UART, which can be used to watch the log of the hardware boot processing.
- USB 2.0 is USB Host and USB 3.0 is USB OTG.

4. Decompress release_package/android-10.0.0_1.0.0_image_8qmek.tar.gz, which contains the image files and uuu_imx_android_flash tool.
5. Execute the uuu_imx_android_flash tool to flash images.

The uuu_imx_android_flash tool can be executed with options to get help information and specify the images to be flashed. For i.MX 8QuadMax board, related options are described as follows

Table 6. Options for uuu_imx_android_flash tool

Option	Description
-h	Displays help information of this tool.
-f soc_name	Specifies SoC information. For i.MX 8QuadMax MEK, it should be "imx8qm". This option is mandatory .
-a	Only flashes slot a. If this option and "-b" option are not used, slots a and b are both flashed.
-b	Only flashes slot b. If this option and "-a" option are not used, slots a and b are both flashed.
-c card_size	Specifies which partition table image file to flash. For i.MX 8QuadMax, it can be followed with "28". If this option is not used, default "partition-table.img" is flashed.
-u uboot_feature	Flashes U-Boot or spl&bootloader image with "uboot_feature" in their names. For i.MX 8QuadMax MEK, it can be "trusty-secure-unlock" and "trusty". If this option is not used, default "u-boot-imx8qm.img" is flashed.
-d dtb_feature	Flashes dtbo and vbmeta images with "dtb_feature" in their names. For i.MX 8QuadMax MEK, it can be "hdmi" and "mipi-panel". If this option is not used, default "dtbo-imx8qm.img" and "vbmeta-imx8qm.img" are flashed.
-e	Erases user data after images are flashed.
-D directory	Specifies the directory in which there are the images to be flashed. If this option is not used, images in current working directory will be flashed.
-t target_dev	Specifies the target device. For i.MX 8QuadMax, it can be "emmc" and "sd". If this option is not used, images are flashed to eMMC.
-daemon	Runs UUU in daemon mode. This option is used to flash multiple boards of the same type.
-i	If the script is executed with this option, no images are flashed. The script just loads U-Boot to RAM and executes to fastboot mode. This option is used for development.
-dryrun	Only generates a UUU script but not executes UUU with this script.

- On Linux system, open the shell terminal. For example, you can execute a command as follows:

```
> sudo ./uuu_imx_android_flash.sh -f imx8qm -a -e -u trusty
```

- On Windows system, open the command line interface in administrator mode. The corresponding command is as follows:

```
> .\uuu_imx_android_flash.bat -f imx8qm -a -e -u trusty
```

When the command above is executed, u-boot-imx8qm-trusty.img with other default images are flashed into eMMC slot a for i.MX 8QuadMax MEK.

NOTE

- "-u" followed with a parameter and containing "trusty" cannot be used together with "-t sd", because Trusty OS cannot boot from SD card.
- To flash the SD card, execute the tool with "-t sd". To flash eMMC, it does not need to use -t option.
- If your SD card is 16 GB or the on-board eMMC is used as the boot device, it does not need to use -c option.
- If your SD card is 32 GB, execute the tool with "-c 28".
- To test Trusty OS, execute the tool with "-u trusty".
- To test the demonstration implementation of secure unlock, execute the tool with "-u trusty-secure-unlock". For secure unlock details, see the *i.MX Android Security User's Guide (ASUG)*.
- To test LVDS-to-HDMI/MIPI-to-HDMI display, it does not need to use -d option.
- To test MIPI panel output, execute the tool with "-d mipi-panel".
- To test physical HDMI display, execute the tool with "-d hdmi".
- uuu_imx_android_flash.bat generates a temporary file under the current working directory. Make sure you have Write permission under the current working directory.
- If uuu_imx_android_flash.bat is used to flash images on a remote server through samba, you need to map the remote resource to the local environment first. Take the following command as an example:

```
> net use z: \\192.168.1.1\daily_images
```

"z" in the command represents an available drive letter. It can be other available drive letter.

6. Wait for the uuu_imx_android_flash execution to complete. If there is not any error, you will get information on the command window indicating that images are already flashed.
7. Power off the board.
8. Change boot device as eMMC or SD card.
 - Change SW2 to switch the board back to 000100 (from 1-6 bit) to enter eMMC boot mode.
 - Change SW2 to switch the board back to 001100 (from 1-6 bit) to enter SD boot mode.

5.4 Booting

After downloading the images, boot the board by connecting it to the power supply.

5.4.1 Booting with LVDS-to-HDMI/MIPI-to-HDMI display

In the U-Boot prompt, set the U-Boot environment variables as follows:

```
U-Boot > setenv bootargs console=ttyLP0,115200 earlycon=lpuart32,0x5a060000,115200 init=/init
androidboot.console=ttyLP0 androidboot.hardware=freescale androidboot.fbTileSupport=enable
cma=800M@0x960M-0xe00M androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

5.4.2 Booting with physical HDMI display

In the U-Boot prompt, set the U-Boot environment variables as follows:

```
U-Boot > setenv bootargs console=ttyLP0,115200 earlycon=lpuart32,0x5a060000,115200 init=/init
androidboot.console=ttyLP0 androidboot.hardware=freescale androidboot.fbTileSupport=enable
cma=1184M@0x960M-0xe00M androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

5.4.3 Booting with dual LVDS-to-HDMI display

In the U-Boot prompt, set the U-Boot environment variables as follows:

```
U-Boot > setenv bootargs console=ttyLP0,115200 earlycon=lpuart32,0x5a060000,115200 init=/init
androidboot.console=ttyLP0 androidboot.hardware=freescale cma=800M@0x960M-0xe00M
androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware transparent_hugepage=never
androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs. Boot environment variables are as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

5.5 Board reboot

After you have completed download and setup, reboot the board and wait for the Android platform to boot up.

6 Working with the i.MX 8QuadXPlus MEK Board

6.1 Board hardware

The figures below show the different components of the i.MX 8QuadXPlus MEK board.




Figure 17. i.MX 8QuadXPlus MEK board



Figure 18. i.MX mini SAS cable with DSI-to-HDMI adapter



Figure 19. i.MX mini SAS cable with LVDS-to-HDMI adapter



Figure 20. i.MX MIPI camera

NOTE

- To test the MIPI-DSI to HDMI display, use the i.MX mini SAS cable to connect the DSI to HDMI adapter to the "MIPI DSI" port.
- To test the LVDS-to-HDMI display, use the i.MX mini SAS cable to connect the LVDS-to-HDMI adapter to the "LVDS0/LVDS1" port.
- To test a single camera, connect the i.MX MIPI Camera to the "MIPI Camera" port or connect OV5640 Camera to the "CSI Camera" port.
- To test dual camera, use the i.MX mini SAS cable to connect both "LVDS0" and "LVDS1" ports with the LVDS-to-HDMI adapter.

6.2 Board images

The table below describes the location in the board partitions of the software images in android-10.0.0_1.0.0_image_8qmek.tar.gz.

Table 7. Board images

Image name	Download target
u-boot-imx8qxp.img	32 KB offset of MMC.
u-boot-imx8qxp-trusty.img	32 KB offset of MMC.
u-boot-imx8qxp-trusty-secure-unlock.img	32 KB offset of MMC.
u-boot-imx8qxp-mek-uuu.img	Bootloader used by UUU for i.MX 8QuadXPlus MEK board. It is not flashed to MMC.
partition-table.img	Programed to first 17 KB, and then back up to last 17 KB of the boot storage. GPT image for boot storage larger than 13 GB.
partition-table-28GB.img	Program to first 17 KB, and then back up to last 17 KB of the boot storage. GPT image for boot storage larger than 32 GB.
boot.img	boot_a and boot_b partitions.
boot-debug.img	boot_a and boot_b partitions when doing VTS test with GSI system image.
vbmeta-imx8qxp.img	vbmeta_a and vbmeta_b partitions to support single LVDS-to-HDMI/MIPI-to-HDMI or dual LVDS-to-HDMI display with dual cameras support.
system.img	system_a and system_b partitions.
vendor.img	vendor_a and vendor_b partitions.
product.img	product_a and product_b partitions.
dtbo-imx8qxp.img	dtbo_a and dtbo_b partitions to support single LVDS-to-HDMI/MIPI-to-HDMI or dual LVDS-to-HDMI displays with dual cameras support.

Table continues on the next page...

Table 7. Board images (continued)

rpmb_key_test.bin	Prebuilt test RPMB key. It can be used to set the RPMB key to fixed 32 bytes 0x00.
testkey_public_rsa4096.bin	Prebuilt AVB public key, which is extracted from the default AVB private key.

6.3 Flashing board images

The board image files can be flashed into the target board using Universal Update Utility (UUU).

For the UUU binary file, download it from github: [uuu release page on github](#).

To achieve more flexibility, two script files are provided to invoke UUU to automatically flash all Android images.

- uuu_imx_android_flash.sh for Linux OS
- uuu_imx_android_flash.bat for Windows OS

For this release, these two scripts are validated on UUU 1.3.102 version. Download corresponding version from github:

- For Linux OS, download the file named "uuu".
- For Windows OS, download the file named "uuu.exe".

Because the two script files will directly invoke UUU, make sure that UUU is in a path contained by the system environment variable of "PATH".

Perform the following steps to download the board images:

1. Download the UUU binary file from github as described before. Install UUU into a directory contained by the system environment variable of "PATH".
2. Make the board enter serial download mode.
Change the board's SW2 (boot mode) to 1000 (from 1-4 bit) to enter serial download mode.
3. Power on the board. Use the USB cable on the board USB 3.0 Type-C port to connect your PC with the board.

NOTE

- There are three USB ports on the 8QuadXPlus MEK board: USB-to-UART, USB 2.0, and USB 3.0.
- The USB-to-UART port can be referenced as debug UART, which can be used to watch the log of the hardware boot processing.
- USB 2.0 is USB Host and USB 3.0 is USB OTG.

4. Decompress release_package/android-10.0.0_1.0.0_image_8qmek.tar.gz, which contains the image files and uuu_imx_android_flash tool.
5. Execute the uuu_imx_android_flash tool to flash images.

The uuu_imx_android_flash tool can be executed with options to get help information and specify the images to be flashed. For 8QuadXPlus board, related options are described as follows

Table 8. Options for uuu_imx_android_flash tool

Option	Description
-h	Displays help information of this tool.
-f soc_name	Specifies SoC information. For i.MX 8QuadXPlus MEK, it should be "imx8qxp". This option is mandatory .
-a	Only flashes slot a. If this option and "-b" option are not used, slots a and b are both flashed.
-b	Only flashes slot b. If this option and "-a" option are not used, slots a and b are both flashed.

Table continues on the next page...

Table 8. Options for uuu_imx_android_flash tool (continued)

Option	Description
-c card_size	Specifies which partition table image file to flash. For i.MX 8QuadXPlus MEK, it can be followed with "28". If this option is not used, default "partition-table.img" is flashed.
-u uboot_feature	Flashes U-Boot or spl&bootloader image with "uboot_feature" in their names. For i.MX 8QuadXPlus MEK, it can be "trusty-secure-unlock" and "trusty". If this option is not used, default "u-boot-imx8qxp.img" is flashed.
-e	Erases user data after images are flashed.
-D directory	Specifies the directory in which there are the images to be flashed. If this option is not used, images in current working directory will be flashed.
-t target_dev	Specifies the target device. For i.MX 8QuadXPlus MEK, it can be "emmc" and "sd". If this option is not used, images are flashed to eMMC.
-daemon	Runs UUU in daemon mode. This option is used to flash multiple boards of the same type.
-i	If the script is executed with this option, no images are flashed. The script just loads U-Boot to RAM and executes to fastboot mode. This option is used for development.
-dryrun	Only generates a UUU script but not executes UUU with this script.

- On Linux system, open the shell terminal. For example, you can execute a command as follows:

```
> sudo ./uuu_imx_android_flash.sh -f imx8qxp -a -e -u trusty
```

- On Windows system, open the command line interface in administrator mode. The corresponding command is as follows:

```
> .\uuu_imx_android_flash.bat -f imx8qxp -a -e -u trusty
```

When the command above is executed, u-boot-imx8qxp-trusty.img with other default images are flashed into eMMC slot a for i.MX 8QuadXPlus MEK.

NOTE

- "-u" followed with a parameter and containing "trusty" cannot be used together with "-t sd", because Trusty OS cannot boot from SD card.
- To flash the SD card, execute the tool with "-t sd". To flash eMMC, it does not need to use -t option.
- If your SD card is 16 GB or the on-board eMMC is used as the boot device, it does not need to use -c option.
- If your SD card is 32 GB, execute the tool with "-c 28".
- To test Trusty OS, execute the tool with "-u trusty".
- To test the demonstration implementation of secure unlock, execute the tool with "-u trusty-secure-unlock". For secure unlock details, see the *i.MX Android Security User's Guide (ASUG)*.
- uuu_imx_android_flash.bat generates a temporary file under the current working directory. Make sure you have Write permission under the current working directory.
- If uuu_imx_android_flash.bat is used to flash images on a remote server through samba, you need to map the remote resource to the local environment first. Take the following command as an example:

```
> net use z: \\192.168.1.1\daily_images
```

"z" in the command represents an available drive letter. It can be other available drive letter.

6. Wait for the `uuu_imx_android_flash` execution to complete. If there is not any error, you will get information on the command window indicating that images are already flashed.
7. Power off the board.
8. Change boot device as eMMC or SD card.
 - Change SW2 to switch the board back to 0100 (from 1-4 bit) to enter eMMC boot mode.
 - Change SW2 to switch the board back to 1100 (from 1-4 bit) to enter SD boot mode..

6.4 Booting

After downloading the images, boot the board by connecting it to the power supply.

6.4.1 Booting with single LVDS-to-HDMI/MIPI-to-HDMI or dual LVDS-to-HDMI displays

In the U-Boot prompt, set the U-Boot environment variables as follows:

```
U-Boot > setenv bootargs console=ttyLP0,115200 earlycon=lpuart32,0x5a060000,115200 init=/init
androidboot.console=ttyLP0 androidboot.hardware=freescale androidboot.fbTileSupport=enable
cma=800M@0x960M-0xe00M androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware
transparent_hugepage=never androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

6.4.2 Booting with dual LVDS-to-HDMI display

In the U-Boot prompt, set the U-Boot environment variables as follows:

```
U-Boot > setenv bootargs console=ttyLP0,115200 earlycon=lpuart32,0x5a060000,115200 init=/init
androidboot.console=ttyLP0 androidboot.hardware=freescale cma=800M@0x960M-0xe00M
androidboot.primary_display=imx-drm firmware_class.path=/vendor/firmware transparent_hugepage=never
androidboot.wificountrycode=CN androidboot.lcd_density=213
U-Boot > saveenv
```

To disable selinux for userdebug/eng build mode images, "androidboot.selinux=permissive" needs to be appended to the U-Boot's bootargs. Boot environment variables are as follows:

```
U-Boot > setenv append_bootargs androidboot.selinux=permissive
U-Boot > saveenv
```

6.5 Board reboot

After you have completed download and setup, reboot the board and wait for the Android platform to boot up.

7 Revision History

Table 9. Revision history

Revision number	Date	Substantive changes
P9.0.0_1.0.0-beta	11/2018	Initial release
P9.0.0_1.0.0-ga	01/2019	i.MX 8M, i.MX 8QuadMax, i.MX 8QuadXPlus GA release.
P9.0.0_2.0.0-ga	04/2019	i.MX 8M, i.MX 8QuadMax, i.MX 8QuadXPlus GA release.
P9.0.0_2.0.0-ga	08/2019	Updated the location of the SCFW porting kit.
android-10.0.0_1.0.0	02/2020	i.MX 8M Mini, i.MX 8M Quad, i.MX 8QuadMax, and i.MX 8QuadXPlus GA release.
android-10.0.0_1.0.0	03/2020	Deleted the Android 10 image.

How To Reach Us

Home Page:

nxp.com

Web Support:

nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

While NXP has implemented advanced security features, all products may be subject to unidentified vulnerabilities. Customers are responsible for the design and operation of their applications and products to reduce the effect of these vulnerabilities on customer's applications and products, and NXP accepts no liability for any vulnerability that is discovered. Customers should implement appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, UMEMS, EdgeScale, EdgeLock, eIQ, and Immersive3D are trademarks of NXP B.V. All other product or service names are the property of their respective owners. AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamIQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro, µVision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© NXP B.V. 2018-2020.

All rights reserved.

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

Date of release: 30 March 2020

Document identifier: AQSUG

