



Quick Start Guide FRDM-TOUCH

FREEDOM DEVELOPMENT PLATFORM



GET TO KNOW THE FRDM-TOUCH BOARD



Figure 1: FRDM-TOUCH Callouts




Figure 2: FRDM-TOUCH Pin-Out

HOW TO GET STARTED

1. Connect the FRDM-TOUCH board to a Freedom development board (e.g., FRDM-KE15Z). Power on the Freedom board by connecting the USB cable to your PC.
2. The FRDM-KE15Z comes pre-programmed with a demo which leverages the on-board RGB LED. When you touch the keys on FRDM-TOUCH board, the RGB LED is turned on. When you touch the slider, the blue LED will gradually illuminate based on the distance your finger moved on the touch slider..
3. Explore other out-of-box demos and download software and tools on www.nxp.com/FRDM-TOUCH.
4. Enjoy your design freedom with the FRDM-TOUCH.



SUPPORT

Visit www.nxp.com/support for a list of phone numbers within your region.

WARRANTY

Visit www.nxp.com/warranty for complete warranty information.



Get Started

Download installation software and documentation under “**Jump Start Your Design**” at www.nxp.com/FRDM-TOUCH.

www.nxp.com/FRDM-TOUCH

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2016 NXP B.V.

Document Number: FRDMTOUCHQSG REV 0
Agile Number: 926-29143 REV A