

AN494

An HC11-Controlled Multiband RDS Radio

By Peter Topping
Motorola, Ltd.
East Kilbride, Scotland

This application note describes the software and hardware features of the microcontroller (MCU) of a synthesized multiband radio which includes RDS (radio data system) decoding (FM, band II). It uses an MC68HC(7)11 MCU whose program can be on-chip or contained in an external EPROM (erasable programmable read-only memory). ROM versions are available.

Both LCD (liquid crystal display) and VFD (vacuum fluorescent display) 16-character dot matrix display modules can be used to display RDS and tuning information. Traffic messages, initiated by the reception of EON (enhanced other networks) data (group 14B) or TA = TP = 1 (traffic announcement = traffic program = 1) on the current frequency, are handled. The station carrying the TA is tuned for the duration of the message, followed by a return to the original frequency. A tuning knob employing an incremental encoder is supported.

Introduction

Figure 1 shows a block diagram of the application. The controller hardware and software are described in detail here. The other hardware is not covered to the same depth, because that varies between different implementations, the intention being to describe a controller which could

Application Note

be added to an existing radio or to one which includes only one or two of the possible bands.

Separate FM and AM PLLs (phase-locked loop) are shown. This is not essential, but it reduces the amount of band switching necessary and simplifies hardware fault finding. The illustrated configuration corresponds to that used by the author for software development and debugging.




Figure 1. Main Block Diagram

The MCU used is the MC68HC(7)11. The MC68HC711K4 (K4) [and similar chips such as the MC68HC711P2 (P2) and MC68HC711PH8 (PH8)] can be used in expanded mode, but this application has been included in the ROM of an E32 and a PH8.

To use the ROMed parts in this application, the first three bytes of EEPROM (electrically erasable programmable ROM) should contain an extended jump to the appropriate start address. The E32 (ZC403311) requires \$7E, \$90, and \$00 at addresses \$B600, \$B601, and \$B602, while the PH8 (ZC428200 or ZC428202) requires \$7E, \$40, and \$00 at

addresses \$0D00, \$0D01, and \$0D02. This can be done using either PCbug11 or the BUFFALO (bit users fast friendly aid to logical operation) monitor (see reference 5). The E32 version uses all the input/output (I/O) and can, therefore, be used only in single-chip mode. The circuit diagram of the HC11E controller is shown in **Figure 3** and the circuit diagram of the K4/PH8 in **Figure 4**. The K4/PH8 version shows the additional hardware (within the dotted line) used to develop and debug the software on a K4 using PCbug11. This implementation uses two of the K4's chip selects to enable external memories allowing debug to be done with the code in RAM and the PCbug11 talker in an EPROM. This arrangement requires a further four I/O (input/output) lines, leaving 30 for use in the application. The description of the application, and the listed software, corresponds to the E32 ROMed version (ZC403311). Later sections list the port allocation and functional differences which apply to the PH8 ROMed versions (ZC428200 and ZC428202).

Forty programs (10 on FM, 10 on MW and 20 on SW) can be stored using the HC11E's on-chip EEPROM (the PH8 has 20 additional SW (shortwave) programs). Each contains frequency, an 8-character name [PS (program service) name on a station with RDS] and, on FM only, PI (program identification) code and a TA inhibit bit. For stations with no RDS (for example, all AM stations), the saved name can be manually entered. Programs saved with no name use their frequency instead. The SW banks are selected by an I/O line (two for the PH8). When the MCU is reset, or any of the band or memory select inputs are changed, the last used program in the selected band is tuned. This feature does not require that the MCU is permanently powered up, as this information is also stored in non-volatile EEPROM.

The keyboard uses an MC14028 decoder to minimize the number of I/O lines used. Either LCD or VFD 16-digit dot matrix displays can be used. The VFD display driver supported is the MSC7128, and the LCD driver the HD44780. This driver on its own provides a 16-way multiplexed LCD. In conjunction with an HD44100, it can facilitate an 8-way multiplexed higher contrast display. The input level on a port pin selects the appropriate type of multiplexing to match the display in use. To minimize the I/O activity, only one display is driven, the choice between LCD and VFD again being determined by an I/O line.

MC145170 and MC145157 PLLs are supported, using the same data and clock lines as the VFD driver, along with dedicated chip selects. The MC145157 requires an external prescaler for frequencies above 20 MHz, but the MC145170 has an on-chip 160-MHz capability.

A tuning knob can be included by using an incremental encoder. This can utilize either IRQ or XIRQ. As IRQ is used for the RDS clock, XIRQ is most appropriate for the tuning function. The possibility of using IRQ (see information described later) has been included to facilitate debug with PCbug11, which can employ XIRQ for its communication with the PC. Edges detected on the encoder execute the PS edit and alarm setup functions of the +/- (plus/minus) keys, depending on the direction of rotation. This provides a quick and convenient method of editing the PS name and changing the alarm time. A difference in function between the encoder and the +/- keys applies in normal mode. The program number is not affected by the tuning knob. In this mode, when the +/- keys control the program number, the tuning knob increments or decrements the frequency.

Two I/O lines are used to select the band. These lines are regularly monitored; if they change, the radio is retuned to the last used station in the selected band. **Table 1** shows the bands which are available.

- Band 2 is intended for single-conversion (low IF, intermediate frequency) MW or SW radios. The large step size of 9 or 10 kHz is suitable for MW rather than SW, but the small step size of 1 kHz is suitable for either SW or MW.
- Band 3 is for dual-conversion (10.7-MHz first IF) SW designs. The FM IF offset is selected as + or -, according to the level on port A, bit 2 (high: LO high; low: LO low).
- Bands 0 and 1 both are intended for VHF/FM, the difference between them being in the use of the M68HC11's IRQ pin. It is possible to use IRQ interrupts for both RDS and the tuning knob, as the two functions are not required simultaneously. To facilitate this, the band-select inputs affect the function performed when an edge is detected in the IRQ pin. When band 0 is selected, an RDS bit is read, but in any other band the incremental encoder function is performed. This enables automatic selection of function if bit 0

on port A is taken high when movement is detected from the shaft encoder. This facility can be disabled (RDS function only) by holding bit 3 of port A low. This should be done if XIRQ is being used for the tuning knob. As XIRQ is level-sensitive, some additional components are required to interface it with the incremental encoder. **Figure 2** shows a simple circuit which can be used for this purpose.

Table 1. Available Bands

Band	PA1	PA0	IF Offset	Step	Memory	Use	Prescaler MC145157 Only
0	0	0	+/-10,700	50, 10	10	VHF	10
1	0	1	+/-10,700	50, 10	10	VHF	10
2	1	0	455	9 (or 10), 1	10	MW/SW	—
3	1	1	10,700	5	20/40	SW	5




Figure 2. Incremental Encoder Interface Circuit

Application Note




Figure 3. MC68HC11E32 Circuit




Figure 4. MC68HC11K4 and PH8 Circuit

Frequency Synthesis

Synthesis of the local oscillator (LO) in a superheterodyne radio provides many advantages over mechanical tuning. The main benefits are:

- Tuning accuracy
- Stability
- Storing of often-used frequencies.

The accuracy and stability result from the fact that the LO is phase-locked to a crystal oscillator. In conjunction with RDS, frequency synthesis provides the additional facility of allowing the radio to retune itself to a traffic announcement or news bulletin. A synthesizer can be retrofitted to most radios by replacing the tuning capacitor with a varicap diode. The voltage biasing the varicap is supplied by the synthesizer and also can be used to provide RF (radio frequency) tuning. Alternatively, manual preselector or no RF tuning can be employed.

Motorola's MC145157 and MC145170 synthesizers are two of a series offering a variety of options including serial or parallel interfacing and single or dual modulus prescaling. The MC145157 requires a prescaler for frequencies above 20 MHz but the MC145170 can handle input frequencies up to 160 MHz. The MC145157 has been included to retain compatibility with hardware developed for use with the MC68HC05B4 synthesizer described in ANE416 (reference 1).

Figure 5 shows the block diagram of the MC145170. It uses the Motorola bitgrabber system, whereby the number of bits sent determines the register which is written to. There is, therefore, no need for the control bit which is required by the MC145157.




Figure 5. MC145170 Block Diagram

The reference counter divides the 8-MHz crystal oscillator (10 MHz for the MC145157) down to the reference frequency (in this case, 1 kHz for the MC145157 and 10 kHz for the MC145170) at which the comparison is made with the (also divided down) local oscillator. The filtered output of the phase comparator supplies the tuning voltage to the local oscillator. The numbers chosen as the divide ratios determine the frequency at which this oscillator stabilizes. The equation that follows shows the relationship between the various frequencies where P is the LO prescaler (MC145157 only). The received frequency can be changed by altering the LO divide ratio. The MCU takes care of the decimal-to-binary conversion, IF offset, and the other arithmetic required.

$$\text{LO frequency} = \text{RF} + \text{IF} = P \times [(\text{Xtal frequency}) / (\text{ref. divide ratio})] \times \text{LO divide ratio}$$

The MC145157 is specified to operate up to 20 MHz, so prescaling is required on FM and SW (10.7-MHz IF). For this SW band, divide-by-5

Application Note

prescaling is used; for FM, divide-by-10 is used. This increases the minimum step size to 10 kHz of FM, which is ideal for this band, and to 5 kHz on SW, which is suitable for almost all broadcast stations. The MC145170 does not require any prescaling even on the FM band and can use this to advantage by allowing the use of a higher reference frequency, making the low-pass filter design less critical.

An important part of any PLL is the loop filter. The filter in **Figure 6** is an active filter using the double-ended phase detector outputs from the MC145170 feeding a CA3460 operational amplifier. This dual op-amp allows the simple double-ended low-pass filter to be followed by a second order Sallen and Key filter. An active filter has the added advantage of increasing the available voltage swing beyond the supply rail of the MC145170/MC145157.

Freescale Semiconductor, Inc.




Figure 6. MC145170 Circuit

The combination of active filter and double-ended phase detector outputs makes it simple to select the correct relationship between voltage and frequency. Usually, the fixed side of the varicap diode is grounded, so increased voltage increases the frequency of the oscillator; in some oscillator designs, the fixed side may be taken to the supply rail, and increasing the voltage will decrease the frequency. With the filter design shown here, the choice can be made simply by swapping the phase detector outputs from the PLLs.

Radio Data System

The radio data system (RDS) adds a digital data capability to the FM VHF transmissions on band II (87.5 to 108 MHz). The specification is defined in CENELEC EN 50067 (formerly EBU Technical Document 3244, see reference 2). An MC68HC05E0 implementation of RDS is described in AN460, (reference 5). It monitors the RDS activity on the MPX signal of a VHF radio but is not able to tune the radio and, therefore, cannot, use AF (alternative frequencies) or EON data. This application can tune the radio and uses EON data to retune the radio when a traffic announcement is taking place on another frequency. An announcement is initiated by a packet 14B and the radio retunes if TAs are enabled. At the end of the TA, the original station is re-tuned. TAs are not active in standby mode (standby line high).

To transmit the data, a subcarrier is added at 57 kHz. This subcarrier is amplitude-modulated with the shaped bi-phase coded data signal. The subcarrier itself is suppressed to avoid data modulated cross-talk in phase-locked-loop stereo decoders and to maintain compatibility with the German ARI system which uses the same subcarrier frequency. Information is sent in groups of four 26-bit blocks. Each group of 104 bits is one of several types containing different information. It is up to the broadcaster to decide which features are transmitted as long as the specified format is adhered to and PI, PTY, and TP are included. Each group contains a different subset of the RDS features; a list of all currently defined features is shown in [Table 2](#).

The retrieval of data is carried out by demodulation hardware, which generates clock and data signals that can be used by the MCU. Suitable devices which can perform this function include SAA6579, SAA7579T (plus an external filter), TDA7330, LA2231, and RDS hybrids.

Table 2. RDS Features

Feature	Information
PI	Program identification
PTY	Program type
PS	Program service name
RT	Radiotext
CT	Clock time and date
AF	Alternative frequencies
TA	Traffic announcement
TP	Traffic program
MS	Music/speech switch
DI	Decoder identification
PIN	Program item number
EON	Enhanced other networks
TDC	Transparent data channel
INH	In-house data

This application supports PI, PTY, PS, RT, CT, TP, TA, MS, DI, PIN, and EON. These features facilitate permanent display of the 8-digit station name (PS) and time (CT), and, on request, can display program type (PTY), radiotext data (RT), and the status of the other RDS information (see [Table 5](#)).

EON data can be displayed and used to switch to traffic announcements, but the retuning features associated with AF are not supported, as they are appropriate only for a radio intended for use in a vehicle. In a car radio, AF data would be used to tune the radio to the strongest signal carrying the selected service. PI is a 2-byte number which identifies the

country, coverage area, and service. It can be used by the control MCU but is not normally intended for display. A change in PI code causes the initialization of all RDS data as it indicates that the radio has been retuned. This application facilitates the display of the current PI code.

PTY is a 5-bit number which indicates the current program type. At present, 16 of these types are defined. Examples include "no programme type," "Current affairs," and "Pop music," although the actual syntax which is displayed is determined by the software of the controlling MCU. In this example, PTY can be displayed on request; **Table 3** shows the display used for each PTY code.

PS is the 8-character name of the station and is permanently displayed (except in standby mode). In the absence of RDS (for example, AM bands), the name can be entered manually. If none is entered, then the frequency is used as the station name when the program is stored in EEPROM.

Radiotext (RT) constitutes a string of up to 64 characters which give additional information regarding the service or program currently being transmitted. In this application, RT is displayed on request on the 16-digit dot matrix displays, using scrolling. The data often contains extra spaces to center the text on a 2 x 32 character display. As these are not appropriate for a 16-character scrolling display, the software reduces all sequences of two or more spaces to a single space.

CT (clock time and date) data is transmitted every minute on the minute and provides a very accurate clock, traceable to national standards. The (modified Julian) date and local time variation are also transmitted. Time is permanently displayed. In standby mode (see information later), the date is displayed instead of the PS name. The MJD number, which is the form in which the date is received, can also be displayed. The MCU converts this number into day-of-week, day-of-month, month and year.

AF would be used by a car radio to retune to the strongest signal carrying the selected service. AF data, along with TDC (transparent data channel) and INH (in-house data), is not used in this application.

TA and TP are flags. TP is set if the transmitter normally carries traffic information and TA is set if a traffic announcement is in progress. The

Application Note

combination — TA = 1 and TP = 0 — is used to indicate that EON data is being used to supply information on other networks, including traffic announcements. A port line (port A, bit 5) is asserted (low) when TA = TP = 1. This can be used to demute or switch from another source (for instance, cassette when a TA occurs).

Table 3. PTY Types

PTY	Display
0	no program type
1	News
2	Current affairs
3	Information
4	Sport
5	Education
6	Drama
7	Culture
8	Science
9	Varied
10	Pop music
11	Rock music
12	Easy listening
13	Light classics
14	Serious classics
15	Other music
16–31	no program type

M/S is a single bit indicating either music or speech and is intended to be used to make a tone or volume adjustment to a radio’s audio stage. The M/S bit is displayed on request. A port line (port A, bit 6) is asserted (low) when M/S = 1. This can be used to control external hardware.

Decoder information (DI) constitutes four bits indicating the type of transmission (mono, stereo, binaural, etc.). Currently, it is not in use in the United Kingdom, but it can be displayed as a number between 1 and 15.

Program item number (PIN) is used to identify the program currently being broadcast. The format is a 2-byte number which includes the scheduled time and date (day of month) of the start of the program. PIN can be displayed as four hexadecimal digits or fully decoded to day of month and time.

EON (enhanced other networks) replaces the older ON format. If type 14 groups are used to provide EON data, then type 3 groups (ON) will not be used. Type 14A groups are used to send information about other networks. The PS name and principal frequency of up to 16 other networks can be displayed. Type 14B groups are used to switch to traffic announcements; they include the PI code of the station carrying the announcement. This PI code is searched for in NVM, and the required station is tuned if it is stored in NVM. This method allows the user to select which TAs are allowed (they will not occur if the station is not in NVM or if its TA inhibit bit is set) and avoids attempts to jump to an announcement which is not relevant or not receivable with sufficient signal strength to be useful.

Keyboard

The keyboard has 23 keys. [Table 4](#) shows the layout and [Table 5](#) contains a summary of key functions against mode.


Table 4. Keyboard Layout

	PE0	PE1	PE2	PE3
Q6	RDS	Traffic	MW step	TA test
Q5	Time colon	Sleep	—	+
Q4	7	8	9	Alarm
Q3	4	5	6	Store
Q2	1	2	3	
Q1	0	Manual	Clear/Step	On/Off

Application Note


The following functions are available.

On/Off



This key is intended as an on/off control for the radio. It sets a port line low for on and high for standby and can be used to control the power supply to the radio. Its status affects the behavior of other keys as described later in this application note.

Sleep




When pressed, the 1-hour sleep timer starts, leaving the standby line low (radio on) until the sleep time has elapsed. At this time, the line is switched to the standby mode (high). In the normal display mode, the sleep timer running causes the decimal point to appear on the display modules' first character. The sleep timer can be cancelled by pressing ON/OFF. The sleep time can be reduced in increments of five minutes by repressing or holding down the SLEEP key.

Alarm



The alarm key selects the alarm display mode and toggles the alarm armed status. When the alarm is not armed, the legend ALARM-OFF is displayed. When it is armed, the alarm time is shown and adjustment of the alarm setup can be done by selecting the field (5/7 day, hours, or minutes) with the STORE/SET key. The selected field (hours or minutes) flashes and can be adjusted with the +/- keys or the tuning knob. The alarm setup display returns to normal three seconds after the last adjustment. If the radio is in standby mode and the alarm is set, the alarm time is displayed instead of the date. The radio will come fully on (standby line low) at the alarm time. After a 500-ms delay to allow power supplies to stabilize, the program which was tuned when the radio was last used is retuned. When set to the 5-day alarm, the alarm will not occur on Saturdays and Sundays.

*Plus (+)
and Minus (-)*



Pressing + or -, while in normal mode, increments or decrements the program number. The program number wraps round at 0 and 9. The mute line is set high before retuning and returned low 100 ms after the new frequency has been sent to the PLL. Changing the tuned program using the +/- keys (or the 0-9 keys) disables PS name clearing if RDS information is absent or contains multiple errors.

In PS-edit mode (see entry that follows), the + and – keys are used to change the character at the cursor position. This function is duplicated on the tuning knob incremental encoder. In the alarm setup mode, the + and – keys are used to change the alarm time as described earlier. The field which is currently selected for adjustment (using the STORE key) flashes. This function is duplicated on the tuning knob also.

In manual mode, these keys increment and decrement the current frequency in steps of 10 kHz or 50 kHz (FM) as selected by the CLEAR/STEP key. The default is 10 kHz. On the SW band, 1-kHz (455 kHz IF only) or 5-kHz steps are available; on the MW/LW band, 1- or 9-kHz steps are available. In the U.S.A., 10 kHz is appropriate instead of 9 kHz; this can be selected with a special key (see entry that follows). This function is duplicated on the tuning knob both in this mode and in normal mode. Use of the +/- keys (or the incremental encoder) to adjust the frequency enables PS name clearing if RDS information is absent or contains multiple errors. In normal mode, on the AM bands, use of the tuning knob displays the frequency in the PS name field, facilitating simultaneous display of frequency and time.

Store/Set



In normal modes (not manual or alarm), the store key selects the PS-edit mode in which the first character of the displayed PS-name flashes and can be changed by the + and – keys or the tuning knob. Subsequent presses of STORE move to the next character. A space is shown as a hyphen (-). This mode returns to the normal display mode 10 seconds after the last key press. This mode can be used to give a name to a station with no RDS PS name (all AM stations or an FM station with no RDS or with RDS or unusable quality). See the entry that follows for the method of saving this name in EEPROM. Entry of a PS name in this way requires that PS name clearing is disabled. This is achieved by changing the program number (by using the +/- or 0–9 keys). Fine tuning enables PS name clearing (see +/- key description). Direct frequency entry does not affect the PS name clearing status.

In the alarm setup mode, STORE selects what will be changed when the + or – keys or the tuning knob are used (5/7 day, hours, or minutes). Hours or minutes flash when they are selected.

Application Note

In manual mode, STORE enters a special manual store mode in which the 9–0 keys save, rather than recall, a program. After pressing STORE, the program number flashes to indicate this change of function. Alternatively, a second press of STORE saves the current tuning information into the current program number. The current frequency, PI code (FM), PS name, and TA inhibit flag (FM) are saved in EEPROM. The TA inhibit status can be changed using the TRAFFIC key (see entry that follows). If the PS edit mode has been used, then manual store mode should be used to save the entered PS name.


Manual



Select manual entry of frequency; a second press returns to normal mode if the tuned frequency has not been changed. If it has been changed, the second press retunes to the new frequency and an additional press is required to return to the normal mode. In manual mode, frequency is displayed instead of the time; the + and – keys or the tuning knob enable incrementing and decrementing of the current frequency. Direct entry of frequency can be made using 0–9 keys. In this mode, the STORE key enters the manual store mode in which the program number flashes, allowing storing of the tuned program and PS name into the current, or a different, program number. A second press of STORE saves the current frequency, PS name, PI code, and TA inhibit bit (FM) in EEPROM.

In manual mode, the TRAFFIC (TA) key controls the TA inhibit bit, which can be stored with each program. If the current station has its TP flag high, the least significant digit of the frequency will alternate with a decimal point. Pressing TP toggles the NVM inhibit bit. When inhibited, the decimal point between the MHz and kHz becomes a "-". A subsequent press of STORE saves this bit in NVM along with the frequency, PI code, and PS name.

0 to 9



These keys are used both for direct frequency entry and for recalling the 40 available programs. In all modes, except standby and manual, when a 0–9 key is pressed, the selected program is tuned. Changing the tuned program using the 0–9 keys (or the +/- keys) disables PS name clearing if RDS information is absent or contains multiple errors. In manual mode, these keys are used for the direct entry of frequency. After entering the required frequency, pressing MANUAL retunes to the new frequency.

The mute line is set high before retuning and returned low 100 ms after the new frequency has been sent to the PLL. In manual store mode, the program number flashes and the 0–9 keys save the tuned program into the selected program number in EEPROM.

RDS



The first press displays scrolling RT data. Subsequent presses display PTY code, PI code, TA and TP, PIN code (two formats), MJD, MS and DI, last TA PI code, the reason for returning from last TA and EON (up to 16 networks with their principal frequency). See [Table 5](#) for the display formats. The RDS key is operational in all modes except standby.

Traffic



Enable/disable traffic switching. When disabled, this is indicated by a decimal point in the 11th character of the dot matrix displays. Default at power-up is enabled. The TRAFFIC key works in all modes except standby. During manual mode and manual store mode, it toggles the TA inhibit status, which can subsequently be saved in NVM.

Clear/Step



Toggles between 10-kHz and 50-kHz steps on the FM band or between 1 and 9 kHz (or 10 kHz) on the MW band. There is no indication on the dot matrix displays. In manual mode, the displayed frequency is cleared to facilitate the entry of a new frequency. If the clear is followed by use of the + or – keys or the tuning knob, the original frequency is retained, allowing a change of step size only. In PS edit mode, the clear key clears the current PS name.

TA Test



Pressing TA test simulates the arrival of a group 14B. The PI code of the other network is embedded in the code (C5B1, Radio Clyde in the ROMed version).

Time Colon



This key enables or disables the flashing colon in the time display. This can be used to prevent unnecessary I/O activity thus reducing RFI. Disabling the colon prevents 1-Hz updating, as the display modules are only updated if the data to be displayed has changed.

Application Note
MW Step

MW STEP

This optional key selects 9- or 10-kHz steps on MW. Nine kHz is appropriate in Europe and 10 kHz in the United States. The default is 9 kHz, and the key need not be implemented if 10 kHz will never be required.

Table 5. Key Function by Mode

	On/Off	Sleep	Alarm	+/-	Store	Manual	TP	RDS	0-9	Clear
Standby (OFF)	mode normal (ON)	mode sleep (ON)	mode alarm	—	—	—	—	—	—	—
Normal (ON)	mode standby (ON)	“	“	+/- prog.	mode PS-edit	mode manual	toggle traffic enable flag	display RT	tune prog.	toggle step 10/50 kHz
PS edit	“	“	“	+/- ASCII	next char.	“	“	PTY PI	“	“
A off	“	“	mode alarm on	+/- prog.	—	“	“	TA TP PIN hex	“	“
L on	“	“	mode alarm off	5/7 day toggle	mode setup	“	“	PIN dec MJD	“	“
A R	“	“		+/- hour/min	hour/min toggle	“	“	M/S DI TA ret.	“	“
M setup	“	“	mode alarm	+/- freq.	mode store	mode normal	toggle traffic enable NV bit	TA PI EON (16)	input freq.	“
M A N U A L store	“	“	“	“	save prog.	“		“	save prog.	& clear freq.

Freescale Semiconductor, Inc.

Circuit

The circuit is in two distinct parts. The circuit for the MC145170 synthesizer is shown in [Figure 6](#). The synthesizer board is the only part of the synthesizer controller which actually needs to be in (or close to) the radio. A local oscillator signal to supply the synthesizer should be taken from a low-impedance point so that the oscillator is not significantly loaded. Pulling of the oscillator frequency is not a problem as the PLL circuitry will compensate, but loading the tuned circuit itself is not recommended unless a high-impedance buffer is included. This prevents affecting the tuning range or the "Q" of the oscillator.

The MC145157 requires a divide-by-10 prescaler for FM and divide-by-5 for band 3. The MC145170 does not require prescaling. The standard LP1186 FM tuner does not have an LO take-off but a signal can be taken, without other modification, from the emitter of the oscillator BF195 (near the center of the PCB).

The Mullard LP1186 is unusual in having its local oscillator low. More recent tuners, for instance, the Larsholt 7254/55, almost always have their local oscillator above the tuned frequency. This selection can be made using port A, bit 2.

A 16-digit LCD (parallel) or VFD (serial) dot-matrix display module can be driven. The two display modules show the same data (within the limitations of their character ROMs). The VFD display driver supported is the MSC7128 and the LCD driver, the HD44780. On its own, this driver can be used to provide a 16-way multiplexed display, but an 8-way multiplexed higher contrast display is possible if the module also incorporates an HD44100. In an application which drives an LCD module (for instance, a ROMed PH8) and the module is not connected, a 10-k pulldown resistor should be added to bit 7 of port A. This prevents the software hanging up waiting for the busy line to go low.

[Figure 3](#) and [Figure 4](#) show the circuit diagrams of the controllers. [Figure 3](#) gives the pin numbers for the 52-pin PLCC HC11E with the numbers for the 56-pin SDIP (if different) in brackets. With the E32, the display in use can be selected by the level on port E, bit 7 (high for LCD and low for VFD) and the LCD multiplexing by port A, bit 7 (high for

divide-by-16, low for divide-by-8). The SW bank is selected by the level on port E, bit 6.

Figure 4 shows pin numbers for the 84-pin PLCC K4, with the differences for the PH8 in brackets. Debug on the K4 using PCbug11 (reference 5) requires some additional hardware (within the dotted line) and port D bits 0 and 1 (SCI), port G bits 1 and 7 (XA14 and R/W), and port H bits 5 and 7 (CSGP1 and CSPROG), leaving 30 input/output (I/O) lines for use in the application. The display selections are not available on the PH8 ROMed versions, but there are four SW banks of 10 program memories; they are selected by port E, bits 6 and 7.

Since different demodulator devices can be used, the circuitry for the demodulator is not shown. The clock from the demodulator interrupts the microprocessor on each positive edge. At this time, a data bit is available and is read on bit 5 of port E.

Software

An assembled listing of part of the HC11E32 ROMed version (ZC403311) of the application is included. The software is in three modules and was assembled and linked using the Introl re-locatable assembler and linker. The first module is listed. It contains all the main control routines, including the main loop and keyboard scanning, and the function to be performed by each key.

The second module contains the RDS and display functions, while the third module is the 4-function, 9-digit integer BCD arithmetic required for the MJD date calculations.

The second and third modules are described and listed in AN495 (reference 4). EB419/D (reference 5) describes and lists additional debug code contained in the ROMed parts.

The code which is executed only on startup (power-on or reset) begins at the label START on the third page of the first module's listing, while the main loop starts at the label IDLE on the next page. The idle loop is quite long, as many functions and checks have to be carried out.

These include:

- Pacing the loop using the main timer
- Checking to see if the display needs updating or if a transient display has timed out
- Checking if alarm is armed and, if so, comparing its time with the current time
- Sleep timer operation
- Traffic announcement timing and return
- Keyboard scanning and selected function execution
- Incremental encoder execution
- Checking for changes in the band and memory selection inputs
- Timing band changes
- Updating TA = TP = 1 and M/S outputs

The keyboard subroutine (KBD) is executed at 64 Hz from the idle loop and checks to see if a key is pressed. If the same key is pressed on three consecutive tries, its function is performed. The remainder of the first module constitutes the subroutines performed by each key and the arithmetic and serial activity required to tune the synthesizers. The batch files used for linking the modules are shown as comments at the end of the listing, along with the pseudo-vectors required by PCbug11 during debug.

The displays are only updated when there is a change in the displayed data. At 8 Hz, a check is made to see if any characters have changed; if there has been a change, the display update routine is executed. This is done to minimize interference caused by communication with the displays. The colon between the hours and minutes of the time display changes at 1 Hz. This can be disabled (colon permanently displayed) by using the time colon key. The display routine (MOD) is executed in the idle loop if the flag bit 3 of STAT2 is set. It is set every 125 ms by timer B interrupts. If flag bit 4 of STAT2 is set, the display is initialized, indicating no valid RDS data. The dot-matrix modules are then updated, if necessary, with new data. Each time, before anything is written to the LCD module, the subroutine WAIT is used; this checks that the controller

Application Note

in the module is not busy. The different display formats are selected by checking the various flags and the relevant routine executed. The normal display permanently shows PS name and time. As the locations in RAM used for hours and minutes contain binary numbers, they are converted to BCD before being written to the relevant bytes in DISP. Once all 16 bytes in DISP have been loaded, loops are used to send the data to the display modules. The standby display (alarm not enabled) shows date and time. After a power-up, the display "Mon 0 inv 0:00" indicates that the date and time are invalid. The date and time will be correct once a valid RDS CT group has been received.

The VFD routine sends the same data as is shown on the LCD module to the serial VFD module. The display driver used has a different character set from the standard ASCII set used by the LCD module. The table VTAB is used to convert ASCII data into the required character in the VFD module. The small table INITF is used to send the required initialization bytes to the VFD module. This module does not require a busy check but does require a delay between successive bytes. This is satisfied by the wait loop within the serial output loop VF DL. The LCD and VFD routines are in the second software module (see reference 4).

Table 6. Display Formats

Display Mode		Format
Standby Off	Alarm off	Thu 12 May 21:35
	Alarm off, no CT	Mon 0 inv 0:00
	Alarm on	0659 alarm 21:35
Normal On	With RDS PS name	4 BBC 4 FM 21:40
	Without RDS	5 ----- 21:40
	Auto name	6 -- 9410 21:40
	Tuning knob (AM)	6 -- 9415 21:40
Alarm	Alarm off	Alarm - OFF
	Alarm on/setup	5-day alarm 0659
Sleep		Sleep 60 minutes

Table 6. Display Formats (Continued)

Display Mode		Format
RDS	RT	Kaleidoscope. . . .
	PTY	Culture
	PI	PI code - C204
	TA & TP	TP - 0 TA - 1
	PIN (hex)	PIN no. - 655E
	PIN (decoded)	12th at 21:30
	MJD	MJ day - 49484
	MS & DI	M/S M DI 01
	last TA 1.	last TA PI C514
	2.	TA rtrn: EON PI
	EON (16)	BBC 3 FM 92.10
		BBC Gael 103.70
		BBC Nwcl 96.00
	BBC Scot 94.30	
	BBC Scot 92.50	
	BBC Scot 94.70	
	BBC Scot 93.50	
	Classic 101.70	
	BBC Eng 107.90	
	BBC 1 FM 99.50	
	BBC 2 FM 89.90	

Manual	6 Classic 101.70	

Traffic Announcements

The radio can respond to EON-initiated traffic announcements if they are enabled by the TRAFFIC (TA) key. This status is indicated by a decimal point at the 11th character on the dot-matrix displays. A switch to a TA on another frequency will only occur if the station has previously been stored in NVM; the EON data which can be displayed using the RDS key is not used for TA switching. The PI code of the last TA (or attempted TA) can be displayed by pressing the RDS key eight times. A further press displays one of the TA return/inhibit messages shown here. TAs which are the result of TA = TP = 1 on the current frequency do not update the last TA PI or TA return/inhibit messages.

When a 14B group is received, the following occurs:

- Check traffic flag; if enabled, proceed; otherwise, set TA rtn/inhb message to:
TA inhb: flag — Traffic key inhibit flag (d.p. at the 11th character position)
- Search for TA PI code in NVM; if found, proceed; otherwise, set TA rtn/inhb message to:
TA inhb: EON PI — The PI code given in 14B is not in the NVM.
- Check station TA inhibit flag in NVM; if clear, proceed; otherwise, set TA rtn/inhb message to:
TA inhb: NVM — User inhibit of station using bit stored in NVM
- Retune to frequency stored in NVM against EON PI code. The PS name display changes to show the PS name of the service carrying the traffic announcement and the time display is replaced by the new frequency. If the service has its TP flag high, then the 10s of kHz digit will flash as in the manual mode display. After one second, check TP flag at the new frequency. If high, then proceed; otherwise, return to original frequency and set TA rtn/inhb message to:
TA rtn: TP low — TP station does not have TP bit high.
- Check PI code at new frequency. If correct (same as 14B EON TA PI code), then proceed; otherwise, retune to original frequency and set TA rtn/inhb message to:
TA rtn: PI code — PI code of TP station was not as expected.
- After an additional two seconds, start to monitor the TA flag; if high, remain on current frequency, if low, return to original frequency and set TA rtn/inhb message to:
TA rtn: TA low — TA flag of TP station low. This is the normal return method.
- If, during a TA, the radio is manually retuned, the TA rtn/inhb message is set to:
TA rtn: manual — User-initiated manual return

Table 7. MCU I/O

K4 and PH8	Function	E32
Port A bits 0–7	LCD module data bus	Port C bits 0–7
Port B bits 0–7	High-order addresses (K4)	N/A —
Port C bits 0–7	Data bus (K4)	N/A —
Port D bits 0–1 2–4 5	Debug (PCbug11 or BUFFALO) Keyboard rows (via 14028 encoder) Standby (high:standby, low:on)	Port D bits 0–1 2–4 5
Port E bits 0–3 4 5 6 7	Keyboard columns Shaft direction (XIRQ) RDS data in or shaft direction (IRQ) Short-wave memory select 1 Short-wave memory select 2 (PH8 only)	Port E bits 0–3 4 5 6 N/A —
Port F bits 0–7	Low-order addresses	N/A —
Port G bits 0 1 2–4 5–6 7	Mute XA14 (K4 only) LCD control lines (RS, R/W, and clock) Band select R/W (K4)	Port A bit 4 N/A — Port B bits 5–7 Port A bits 0–1 N/A —
Port H bits 0–1 2 3 4 5 6 7	Serial clock/data for VFD and PLLs VFD chip enable (PH8: +/- 10.7 MHz) Port E, bit 5 input control MC145170 PLL chip enable CSGP1 (K4 only) MC145157 PLL chip enable CSPROG (K4 only)	Port B bits 0–1 Port B bit 2 Port A bit 3 Port B bit 4 N/A — Port B bit 3 N/A —
N/A	FM IF select (+/- 10.7 MHz)	Port A bit 2
N/A	TA = TP = 1	Port A bit 5
N/A	M/S = 1	Port A bit 6
N/A	LCD multiplex select (8/16)	Port A bit 7
N/A	Display module (LCD/VFD) select	Port E bit 7

Setup and Testing

An effective method of fault finding a PLL circuit is to initially do the tuning with a potentiometer, leaving the output of the filter disconnected from the VCO. As the radio is tuned through the frequency setup in the synthesizer, the filter output should switch from one extreme to the other. Until this test passes, it is not useful to close the loop, as it is difficult to distinguish the cause of a problem from its effects.

Check operation of the MC34064 LVI circuit. As the supply voltage is lowered, it should pull the reset pin low. This should occur between 4.70 and 4.50 volts. Adjust trimmer on the EXTAL pin of the M68HC711 for accurate timekeeping in the absence of RDS CT information. (Radio should be detuned or tuned to a station known not to provide RDS.) The trimmer on pin 2 of the PLL chip (MC145157 or MC145170) should be adjusted to provide an accurate reference frequency. This adjustment can be made simply to tuning to a strong broadcast of known frequency and adjusting for optimum reception or symmetric adjacent-channel response.

PH8 ROMed Application

The ROMed PH8s (ZC428200 and ZC428202) differ from the described E32 version of this application as follows:

1. 40 short-wave programs can be stored instead of 20. These are accessed by the use of a second memory-select line (port E, bit 7).
2. There is no display selection; both LCD and VFD signals are generated. If an LCD module is not connected, a pulldown on port A, bit 7 should be included (see [Figure 4](#)).
3. LCD multiplexing is fixed at divide-by-8.
4. Traffic announcement (retune to TA frequency) is not fully implemented in the ZC428200.

5. Time colon FLASH defeat key is not implemented; the display modules are always updated at 8 Hz.
6. TA = TP = 1 and M/S outputs are not implemented.
7. 10-kHz MW steps are not available (no 9/10 key).
8. +/-10.7-MHz IF selection (FM) is carried out on port H, bit 2 which is read after reset but before it is set up as an output. A pullup or pulldown resistor will determine the IF selection (pullup for LO high and pulldown for LO low) without affecting the pin's subsequent function as an output (VFD chip enable).
9. The 500-ms delay at switch-on between the standby line moving and the PLLs being retuned is not implemented.
10. The sleep d.p. flashes during operation of the sleep timer.

References

1. *A Radio Synthesizer Using the MC68HC05B4*, Motorola document order number ANE416/D
2. CENELEC EN 50067, *Specifications of the Radio Data System (RDS)*, formerly EBU technical document 3244
3. *An RDS Decoder Using the MC68HC05E0*, Motorola document order number AN460/D
4. *RDS Decoding for an HC11 Controlled Radio*, Motorola document order number AN495/D
5. *ROMed HC11E32 and HC11PH8 Including BUFFALO Monitor and PCbug 11 Talker*, Motorola document order number EB419/D

Application Note

Code Listing

```

*****
*
*          MC68HC11E32 RDS multiband radio.
*
*          Used with RDSE.S11, FNCE.S11 & RDRAME.S11.
*
*          P. Topping          3rd April '94
*****

          IMPORT          SDATA,TINTB,INITD,MOD,CLOCK,MJDAT,WAIT,CLREON,CBCD, PROC, TFCC

          EXPORT          DCON2,NEW,CLTR,SHAFT

          LIB              RDRAME.S11

PORTA      EQU            $00          PORT A ADDRESS
PORTB      EQU            $04          " B "
PORTC      EQU            $03          " C "
PORTD      EQU            $08          " D "
PORTE      EQU            $0A          " E "
PORTCD     EQU            $07          PORT C DATA DIRECTION REG.
PORTDD     EQU            $09          " D " " " " "
TMSK2      EQU            $24
PACTL      EQU            $26
OPTION     EQU            $39
INIT       EQU            $3D

RBO        EQU            $1000        REGISTER BLOCK OFFSET
PPROG      EQU            $3B          EEPROM CONTROL REGISTER
ND         EQU            9            No. DIGITS

SECTION.S .RAM1,COMM

BMJD       RMB            3            BINARY MJD
Q          RMB            9            WORKING NUMBER 1 - RDS
TMQ        RMB            9            SCRATCH
R          RMB            9            WORKING NUMBER 2 - RDS
TMP        RMB            9            MULT. OVER. OR DIV. REMAINDER
R          RMB            9            WORKING NUMBER 3 - RDS
MJD        RMB            9            MODIFIED JULIAN DAY NUMBER
YR         RMB            9            YEAR
MNTH       RMB            2            MONTH
DOM        RMB            2            DATE
DOW        RMB            1            DAY OF WEEK

*****
*
*          RAM allocation, RDS & radio.
*
*****

DIST       RMB            1            TRANSIENT DISPLAY, TIMEOUT,COUNTER
SLEPT      RMB            1            SLEEP TIMER MINUTES COUNTER
RDSTO      RMB            1            RDS TIMEOUT COUNTER
PSNP       RMB            1            PS DISPLAY POINTER
DAT        RMB            4            SERIAL DATA BUFFER
TMPGRP     RMB            8            TEMPORARY GROUP DATA
GROUP      RMB            8            COMPLETE GROUP DATA
PTY        RMB            1            PROGRAM-TYPE CODE (CURRENT)
PTYCMP     RMB            1            PROGRAM TYPE CODE (PTY SCAN)
PI         RMB            2            PROGRAM IDENTIFICATION CODE
PION       RMB            2            PROGRAM IDENTIFICATION CODE (EON)
PIN        RMB            2            PROGRAM ITEM NUMBER
LEV        RMB            1            VALID BLOCK LEVEL
BIT        RMB            1            BIT LEVEL
ITMP1      RMB            1            TEMP BYTE FOR USE IN IRQ
SYN        RMB            2            SYNDROME

```

Freescale Semiconductor, Inc.

```

CONF      RMB      1      SYNDROME CONFIDENCE
TH32     RMB      1      TICS (SECONDS/32)
TH8      RMB      1      EIGHTHS OF SECONDS
SEC      RMB      1      SECONDS
MIN      RMB      1      MINUTES
OUR      RMB      1      HOURS
AMIN     RMB      1      ALARM MINUTES
AOUR     RMB      1      ALARM HOURS
DISP1    RMB      1      RT DISPLAY POINTER #1
DISP2    RMB      1      RT DISPLAY POINTER #2
        6
RQ       RMB      6      WORKING BCD NUMBER 1 RADIO
RP       RMB      6      "      "      "      2      "
RR       RMB      2      "      "      "      3      "
W1       RMB      2      W
W2       RMB      2      O
W3       RMB      2      R
W4       RMB      2      K
W5       RMB      2      I
W6       RMB      2      N
W7       RMB      2      G
KEY      RMB      1      CODE OF PRESSED KEY
KOUNT    RMB      1      KEYBOARD COUNTER
DIG2     RMB      1      2nd DIGIT TIMEOUT COUNTER
CARRY    RMB      1      BCD CARRY
COUNT   RMB      1      LOOP COUNTER
NUM1     RMB      2      1ST No. POINTER (ADD & SUBTRACT)
NUM2     RMB      2      2ND No. POINTER (ADD & SUBTRACT)
LED      RMB      1      STATION NUMBER
SMEM     RMB      2      CURRENT FREQUENCY
REARET   RMB      1      LAST TA REASON FOR RETURN
RTDIS    RMB      1      RDS DISPLAY TYPE
DI       RMB      1      DECODER IDENTIFICATION
SCHAN    RMB      1      SCAN CHANNEL
*****
*
*          Flags, & pages 1-2.
*
*****

STAT      RMB      1      0: MODE 1: STATION, 0: FREQ
*
*          1: STEP 1: 50KHz, 0: 10KHz
*          2: CLRQ 1: CLEAR IF NO. KEYED
*          3: TIMER MS BIT TOGGLE (64 Hz)
*          4: RDS DATA CLEARING ENABLE
*          5: KEY FUNCTION PERFORMED
*          6: KEY REPEATING
*          7: NOT JUST POWERED UP
STAT2     RMB      1      0: VALID SYNDROME
*          1: VALID GROUP
*          2: RT DISPLAY
*          3: UPDATE DISPLAY
*          4: CLEAR DISPLAY
*          5: SPACE FLAG
*          6: NOT ON PROGRAM (AM)
*          7: TA RETUNE DONE
STAT3     RMB      1      0: NOT ON PROGRAM (FM)
*          1: TEXTA/TEXTB BIT (RT)
*          2: TA FLAG
*          3: TP FLAG
*          4: SHAFT DIRECTION
*          5: SHAFT ROTATION
*          6: UPDATE DATE
*          7: SHAFT INTERRUPTS
STAT4     RMB      1      0: DISPLAY (OR TA SWITCH) TRANSIENT
*          1: SLEEP TIMER RUNNING
*          2: TRAFFIC ENABLED
*          3: ALARM DISPLAY
*          4: ALARM ARMED
*          5: ALARM SET-UP
*          6: ALARM HOURS (SET-UP)
*          7: VALID GROUP 14B RECEIVED
STAT5     RMB      1      0: BAND CHANGE TIMEOUT
*          1: RDS DISPLAYS
*          2: SLEEP DISPLAY
*          3: M/S 0: M, 1: S

```

Application Note

```

*
*
*
*
4: RETUNE FLAG (FREQUENCY MODE)
5: TA INHIBIT FLAG (NVM)
6: STORE MODE
7: WEEKDAY ONLY ALARM

STAT6   RMB      1      BAND/BANK (,MW STEP, COLON, ,A1,A0,,E6)
BCTO    RMB      1      BAND CHANGE TIMEOUT
SCNT    RMB      1      SHAFT DETENT COUNTER

SECTION .RAM2,COMM
EON     RMB      256
SECTION .RAM3,COMM
DISP    RMB      16      EON DATA (16 NETWORKS)
DISPP   RMB      16      LCD MODULE BUFFER
PSN     RMB      8        CURRENT LCD MODULE CONTENTS
RT      RMB      69      RADIOTEXT
SECTION .ROM1
STRST   JMP      START   RESET VECTOR
TMRB    JMP      TINTB    RTI
IRQ     JMP      SDATA    IRQ

*****
*
*   Reset routine - set-up ports etc.
*
*****

START   LDAA     #$01      REGISTERS AT $1000
        STAA     INIT      ENABLE EEPROM WRITE (NOT CONFIG)
        LDAA     #$10
        STAA     $1035

        LDAA     #$30      IRQ EDGE SENSITIVE
        STAA     $1039
        LDAA     #$03      32Hz RTI (8.388MHz XTAL)
        STAA     $1026      PORTA, BITS 3 & 7 INPUTS
        LDAA     #$40      ENABLE REAL TIME INTERRUPTS
        STAA     $1024
        LDAA     #$00      DWOM = 0, PORTD PUSH-PULL
        STAA     $1028

        LDS      #$02FF    INITIALISE STACK POINTER

        LDY      #$1000    0,1: BAND INPUTS (FM, FM, MW, SW), 2: FM IF
        LDAA     #$10      3: IRQ CONTROL, 4: MUTE, 5: TA=TP=1
        STAA     PORTA,Y   6: M/S=1, 7: 8/16 LCD MUX

H2L     LDAA     #$00      0,1: SERIAL CLOCK/DATA, 5,6,7: LCD CONTROL
        STAA     PORTB,Y   2,3,4: LATCH SIGNALS (VFD, 5157 & 5170)

        CLR      PORTC,Y   0-7: LCD PARALLEL BUS
        LDAA     #$FF
        STAA     PORTCD,Y

        CLR      PORTD,Y   0,1: SCI (DEBUG)
        LDAA     #$3C      2-4: KEYBOARD OUTPUTS
        STAA     PORTDD,Y  5: STANDBY

*       PORTE     0-3: KEYBOARD INPUTS, 4: SHAFT INPUT (XIRQ)
*       "         5: RDS/SHAFT INPUT, 6: SW BANK, 7: LCD/VFD

*****
*
*   INITIALISE LCD AND RAM.
*
*****

        JSR      DBOUNC    WAIT 15ms
        LDAA     #$30
        JSR      CLOCK     INITIALISE LCD
        JSR      DBOUNC    WAIT 15ms
        LDAA     #$30
        JSR      CLOCK     INITIALISE LCD

        LDX      #BMJD     INITIALISE PAGE 0 RAM
CLOOP   CLR      0,X

```

Freescale Semiconductor, Inc.


```

INX
CPX          #SCNT+1          MORE ?
BNE          CLOOP
BSET        STAT4,$04          ENABLE TRAFFIC SWITCHING - DEFAULT ?
BSET        STAT,$01          STATION MODE

LDAA        #$30
JSR         CLOCK              INITIALISE LCD
JSR         WAIT
LDAA        #$30              /8 DISPLAY
BRCLR      PORTA,Y,$80,M8
LDAA        #$38              /16 DISPLAY
M8          JSR         CLOCK    LATCH IT
JSR         WAIT
LDAA        #$08              SWITCH DISPLAY OFF
JSR         CLOCK    LATCH IT
JSR         WAIT
LDAA        #$01              CLEAR DISPLAY
JSR         CLOCK    LATCH IT
JSR         INITD             INITIALISE RDS DATA & DISPLAY
JSR         CLREON           AND EON DATA

*          Initialise interrupt JMPs

JRT1        EQU          $00EB          E32 BUFFALO RAM JUMP TABLE
JIRQ        EQU          $00EE          " " " " "
JXIRQ       EQU          $00F1          " " " " "

LDAA        #$7E
STAA        JRTI
STAA        JIRQ
STAA        JXIRQ
LDD         #TINTB
STD         JRTI+1            RTI
LDD         #SDATA
STD         JIRQ+1           IRQ
LDD         #SHAFTX
STD         JXIRQ+1          XIRQ

LDAA        #$00
TAP         ENABLE IRQ & XIRQ

*****
*          *
*          Idle loop.          *
*          *
*****

IDLE        LDY          #$1000
BRSET      STAT,$08,TBH
BRSET      $0E,Y,$80,*
BSET      STAT,$08
BRA        NO2D
TBH        BRCLR      $0E,Y,$80,*
BCLR      STAT,$80

NO2D        BRCLR      STAT4,$01,NOPS    DISPLAY TRANSIENT ?
LDAA      DIST
BNE       NOPS              YES, TIMED OUT ?
JSR      CLTR

NOPS        BRCLR      STAT2,$08,NDU    DISPLAY UPDATE REQUIRED ?
JSR      MOD              YES, DO IT
BCLR      STAT2,$08        AND CLEAR FLAG

NDU         BRCLR      PORTD,Y,$20,FULON  STANDBY ?

NOTSNZ     BRSET      STAT4,$10,NNT2    STANDBY, ALARM ARMED ?
NTJ2       JMP        NT2

NNT2       BRCLR      STAT5,$80,NWA    YES, WEEKDAY ALARM ONLY ?
LDAA      DOW              YES
CMPA      #4              SATURDAY OR
BHI       NT2J            SUNDAY ?
NWA        LDAA      AOUR    NO, COMPARE ALARM HOURS
CMPA      OUR             WITH TIME

```

Application Note

Freescale Semiconductor, Inc.

```

BNE          NT2J          SAME ?
LDAA        AMIN          YES, COMPARE ALARM MINUTES
CMPA        MIN           WITH TIME
BNE          NT2J          SAME ?
LDAA        SEC           ONLY ALLOW WAKE-UP IN FIRST SECOND
BNE          NT2          TO PREVENT SWITCH-OFF LOCKOUT
ONAG        BCLR          PORTD,Y,$20 YES, SWITCH ON,
JSR          DEL500       WAIT 500ms,
BCLR          PORTA,Y,$10 DEMUTE
JSR          P5170        AND TUNE (5170 & 5157)

FULON       BRCLR          STAT4,$02,FLN SLEEP TIMER RUNNING ?
LDAA        SLEPT         YES
BNE          FLN          TIME TO FINISH ?
BCLR          STAT4,$02   YES, CLEAR FLAG,
BSET          PORTD,Y,$20 SWITCH OFF
BSET          PORTA,Y,$10 AND MUTE

*****
*                               *
*           Idle loop (cont.).   *
*                               *
*****

FLN         BRCLR          STAT4,$80,NT1 14B FLAG HIGH ?
BRSET        STAT2,$80,NT2 YES, BIT AGREES ?
BSET         STAT2,$80   NO, SET BIT
CLR          REARET
LDAA        #25          LOCK OUT RETURN
STAA        DIST         FOR 3 SECONDS
BSET        STAT4,$01   SET DISPLAY TRANSIENT FLAG
BSET        PORTA,Y,$10 MUTE
JSR         DBNC         WAIT 150 ms
JSR         RETUNE2      AND RETUNE
BRCLR       STAT4,$80,NWWS PI CODE NOT IN EON LIST ?
JSR         DEL500       WAIT 500ms
*           BRCLR          PORTE,Y,$10,SOK SIGNAL OK ?
*           LDAA          #2
*           STAA          REARET
*           BRA           NT1
SOK         JSR           DEL500         WAIT 500ms
BRSET        STAT3,S08,TPOK TP OK?
LDAA        #5
STAA        REARET
BRA         NT1
TPOK        LDAA          PI            YES, CHECK PI CODE
CMPA        PION
BNE         PINOK1
LDAA        PI+1
CMPA        PION+1       AGAINST PI (EON)
BEQ         NT2          IF OK STAY SWITCHED
PINOK1     LDAA          #3
STAA        REARET

NT1        BRCLR          STAT2,$80,NT2 14B FLAG LOW, BIT AGREES ?
BCLR        STAT4,$80   MAKE SURE 14B CANCELLED
BSET        PORTA,Y,$10 MUTE
JSR         DBNC         WAIT 150 ms
NWWS       BCLR          STAT2,$80     CLEAR FLAG
LDAA        LED          SELECTED PROG.
JSR         RETUNE2      AND RETURN TO ORIGINAL PROGRAM

NT2        JSR           KBD            READ KEYBOARD
JSR         KEYP         EXECUTE KEY
BRCLR       STAT3,$20,NSRO SHAFT ROTATION PENDING ?
BCLR        STAT3,$20   YES, CLEAR FLAG
BRSET       STAT3,$10,ANTI DIRECTION ?
JSR         PINC2       CLOCKWISE, INCREMENT
BRA         NSRO
ANTI       JSR           PDEC2         ANTI-CLOCKWIRE, DECREMENT
NSRO      BRCLR          STAT3,$40,NRDSP UPDATE DATE ?
JSR         MJDAT       YES, CONVERT FROM MJD

```

```

*****
*                               *
*           Idle loop (cont.).   *
*                               *

```

```

* Retune if band or SW bank inputs changed. *
*
*****
NRDSP  LDY          #$1000
        BRCLR     STAT,$80,BTO      JUST POWERED UP ?
        BRCLR     PORTA,Y,$01,L5    NO, A0 LOW ?
        BRSET     STAT6,$04,CG6     NO, HIGH, BIT AGREES ?
        BSET      STAT6,$04         NO, MAKE IT HIGH
        BRSET     STAT6,$08,BTO     BAND ONE ?
        BSET      STAT3,$80         YES, SHAFT INTERRUPTS
        BRA       CHE               AND NOTHING ELSE TO DO

L5      BRCLR     STAT6,$04,CG6     YES, A0 LOW, BUT AGREES ?
        BCLR      STAT6,$04         NO, MAKE IT LOW
        BRSET     STAT6,$08,BTO     BAND ZERO ?
        BCLR      STAT3,$80         YES, RDS INTERRUPTS
        BRA       CHE               AND NOTHING ELSE TO DO

CG6     BRCLR     PORTA,Y,$02,L6     A1 LOW ?
        BRSET     STAT6,$08,CHE     NO, HIGH, BIT AGREES ?
        BSET      STAT6,$08         NO, MAKE IT HIGH
        BRA       BTO

L6      BRCLR     STAT6,$08,CHE     YES, A1 LOW, BIT AGREES ?
        BCLR      STAT6,$08         NO, MAKE IT LOW
        BRSET     STAT6,$04,BTO     BAND ZERO ?
        BCLR      STAT3,$80         YES, RDS INTERRUPTS
        BRA       BTO

CHE     BRSET     STAT6,$0C,BD3     BAND 3 ?
        BRA       OK6

BD3    CE6      BRCLR     PORTE,Y,$40,E6L  NO, E6 LOW ?
        BRSET     STAT6,$01,OK6     NO, HIGH, BIT AGREES ?
        BSET      STAT6,$01         NO, MAKE IT HIGH
        BRA       BTO

E6L    BRCLR     STAT6,$01,OK6     YES, E6 LOW, BIT AGREES ?
        BCLR      STAT6,$01         NO, MAKE IT LOW

BTO     BSET      STAT,$80          SET POWER-UP FLAG,
        LDAA      #10
        STAA      BCTO              INITIALISE
        BSET      STAT5,$01         AND START BAND-CHANGE TIMEOUT

*****
*
*           Idle loop (cont.).
*
*****

OK6     BRCLR     STAT5,$01,ARI     TIMEOUT RUNNING?
        DEC       BCTO              YES, DECREMENT COUNT
        BNE       ARI               FINISHED ?
        BCLR      STAT5,$01         YES, CLEAR FLAG
        BSR       RCLP              AND RECALL LAST USED PROG. No.
        BRCLR     STAT6,$0C,ARI     BAND 0 ?
        BSET      STAT3,$80         NO, SHAFT INTERRUPTS

ARI     BRSET     STAT3,$0C,TATP     TA=TP=1 ?
        BSET      PORTA,Y,$20
        BRA       IOOK

TATP    BCLR      PORTA,7,$20       YES, A5 LOW

IOOK    BRSET     STAT5,$08,MSH     M/S=1 ?
        BSET      PORTA,Y,$40
        BRA       IDLJ

MSH     BCLR      PORTA,Y,$40       YES, A6 LOW

IDLJ    JMP       IDLE

RCLP    BSET      PORTA,Y,$10       MUTE
        LDAB      #120
        JSR       READ1             GET STORED PROG. No.
        STAA      LED

```

Application Note

```

JMP          RETUNE2          PROGRAM 145170/57

*****
*
*   Shaft rotation interrupts.
*
*****

SHAFT        BRSET           PORTE,Y,$20,SEM      IRQ,SHAFT I/O HIGH (E5) ?
             BCLR           STAT3,$10           NO, CLEAR DIRECTION BIT
             BRA            TEM
SEM          BSET           STAT3,$10           YES, SET DIRECTION BIT
TEM         BSET           STAT3,$20           SET FLAG TO INDICATE ROTATION
             RTI

SHAFTX       BRSET           PORTE,Y,$10,XEM     XIRQ, SHAFT I/O HIGH (E4) ?
             BCLR           STAT3,$10           NO, CLEAR DIRECTION BIT
             BRA            YEM
XEM         BSET           STAT3,$10           YES, SET DIRECTION BIT
YEM        BSET           STAT3,$20           SET FLAG TO INDICATE ROTATION
             RTI

*****
*
*   Keyboard routine.
*
*****

KBD         CLR            W1
             LDY            #$1000
             LDX            #7
KEY1        LDAB           W1
             ADDB           #$04              SELECT COLUMN
             STAB           W1
             LDAB           PORTD,Y
             ANDB           #$20              PRESERVE OTHER PORTD DATA
             ADDB           W1
             STAB           PORTD,Y
             LDAA           PORTE,Y
             BITA           #$0F
             BNE            L1
             DEX
             BNE            KEY1
             CLR            KEY
             BRA            EXIT
L1          LDAB           W1
             LSLB
             LSLB
             LDAA           PORTE,Y
             ANDA           #$0F
             ABA
             CMPA           KEY
             BEQ            EXIT
             STAA           KEY
             CLR            KOUNT
EXIT        INC            KOUNT
             LDAA           KOUNT
             BRCLR          STAT,$40,NRML     REPEATING ?
             LDAB           PSNP
             BEQ            NOTCH
             CMPA           #8
             BRA            GON2
NOTCH       CMPA           #16
             BRA            GON2
NRML       CMPA           #3
             BLO            KCLC
             BEQ            GOON
             CMPA           #47
GON2       BHI            GOON2
             LDAA           KEY
             BEQ            RKEY
             CLC
             RTS
GOON2      LDAA           KEY
             CMPA           #$54
             BEQ            GOON3

```

Freescale Semiconductor, Inc.



```

        CMPA      #$58          INC.PROG.
        BEQ      GOON3
        CMPA      #$52          SLEEP
        BNE      DNT2          IF NOT A REPEAT KEY, DO NOTHING
GOON3   BSET      STAT,$40      SET REPEAT FLAG
        CLR      KOUNT
GOON    LDAA      KEY
        BEQ      RKEY          SOMETHING TO DO ?
        SEC
        RTS
RKEY    BCLR      STAT,$20      NO, CLEAR DONE FLAG
DNT2    BCLR      STAT,$40      CLEAR REPEAT FLAG
        CLR      KOUNT        CLEAR COUNTER
KCLC    CLC
DNT     RTS

```

```

*****
*
*           Execute key.
*
*****

```

```

KEYP    BCC      DNT          ANYTHING TO DO ?
KEYP2   LDAA      KEY        YES, GET KEY
        CMPA      #$54          DEC. PROG. (M)
        BEQ      RPT
        CMPA      #$58          INC. PROG. (S)
        BEQ      RPT
        CMPA      #$52          SLEEP
        BEQ      RPT
BRSET   STAT,$20,DNT        NOT A REPEAT KEY, FLAG SET ?

```

```

RPT     CLRB
RJ      LDX      #CTAB
        ABX
        LDAA      0,X        FETCH KEYCODE
        CMPA      KEY        THIS ONE ?
        BEQ      PJ         YES
        CMPA      LAST       NO, LAST CHANCE ?
        BEQ      DNT        YES, ABORT
        ADDB      #4         NO TRY THE NEXT KEY
        BRA      RJ
PJ      BSET      STAT,$20
        JSR      1,X
        JMP      P5170

```

```

*****
*
*           Keyboard jump table.
*
*****

```

```

CTAB    FCB      $11          0
        JMP      DIGIT
        FCB      $21          1
        JMP      DIGIT
        FCB      $22          2
        JMP      DIGIT
        FCB      $24          3
        JMP      DIGIT
        FCB      $31          4
        JMP      DIGIT
        FCB      $32          5
        JMP      DIGIT
        FCB      $34          6
        JMP      DIGIT
        FCB      $41          7
        JMP      DIGIT
        FCB      $42          8
        JMP      DIGIT
        FCB      $44          9
        JMP      DIGIT
        FCB      $48          ALARM
        JMP      ALARM
        FCB      $38          STORE/SET
        JMP      SAVE

```



Application Note

Freescale Semiconductor, Inc.

```

FCB          $18          ON/OFF
JMP          ONOFF
FCB          $14          CLEAR/STEP
JMP          CLEAR
FCB          $12          MODE (PROG./FREQ.)
JMP          MODE
FCB          $52          SLEEP TIMER START
JMP          SLEEP
FCB          $54          DEC. PROG./FREQ./CHAR.
JMP          PDEC
FCB          $58          INC. PROG./FREQ./CHAR.
JMP          PINC
FCB          $61          RDS DISPLAYS
JMP          RTDSP
FCB          $62          TRAFFIC ENABLE (TOGGLE)
JMP          TPEN
FCB          $64          MW STEP 9/10kHz (TOGGLE)
JMP          T910
FCB          $51          COLON CONTROL
JMP          TFCC
LAST FCB          $68          TA TEST
      JMP          TEST

*****
*                               *
*           Alarm key.          *
*                               *
*****

ALARM  BRCLR      STAT4,$08,ADON  ALARM DISPLAY ON ?
      BRCLR      STAT4,$10,ALOF  YES, ALARM ON ?
      BCLR       STAT4,$10      YES, SWITCH OFF
ALOF   BRA        UDCNT
      BSET      STAT4,$10      NO, SWITCH ON
      BRA        UDCNT

ADON   JSR        CLTR          NO, ENABLE ALARM DISPLAY
      BSET      STAT4,$08      ALARM DISPLAY FLAG
UDCNT  BCLR      STAT4,$20      CANCEL SET-UP
      LDAA     #25            3 SECONDS TIMEOUT
      STAA     DIST
ABOA   BSET      STAT4,$01      SET DISPLAY TRANSIENT FLAG
      RTS

*****
*                               *
*           On/off key.        *
*                               *
*****

ONOFF  JSR        CLTR          CLEAR DISPLAY TRANSIENTS
      BCLR      STAT4,$82      CANCEL SLEEP TIMER & TA SWITCH FLAG
      BCLR      STAT5,$40      CANCEL STORE MODE

SODM   BRCLR     PORTD,Y,$20,ALRON  ON ?
      BCLR     PORTD,Y,$20      NO, SWITCH ON
      JSR      DEL500          WAIT 500ms
      BCLR     PORTA,Y,$10      AND DEMUTE
RTS

ALRON  BSET      PORTD,Y,$20      YES, SWITCH OFF
      BSET     PORTA,Y,$10      AND MUTE
      RTS

*****
*                               *
*           PS name clear.     *
*                               *
*****

PSC    LDX        #PSN
      LDAA     #$FF
CPSL   STAA     0,X
      INX
      CPX      #PSN+8
      BNE     CPSL
      RTS

```

```

*****
*
*           TP.
*
*****

TPEN      BRSET      PORTD,Y,$20,HIGH      STANDBY ?
          BRSET      STAT,$01,NS1      NO, NORMAL MODE ?
          BRSET      STAT5,$20,TAEH     NO, FREQ. MODE, NVM DISABLE FLAG SET ?
          BSET       STAT5,$20
          RTS
TAEH      BCLR       STAT5,$20         YES, CLEAR IT
HIGH      RTS

NS1       BRCLR      STAT4,$04,TPOF     NORMAL MODE, TRAFFIC ON ?
          BCLR       STAT4,$04         YES, DISABLE
          RTS
TPOF      BSET       STAT4,$04         NO, ENABLE
          RTS

*****
*
*           Sleep timer.
*
*****

SLEEP     BRSET      STAT5,$04,DECS     ALREADY SLEEP DISPLAY ?
          BRSET      STAT4,$02,STR     NO, SLEEP TIMER ALREADY RUNNING ?
INSLP     LDAA       #60                NO, INITIALISE SLEEP TIMER
SLEP      STAA       SLEPT
          BSET       STAT4,$02         START SLEEP TIMER
STR        JSR       CLTR              YES, CLEAR DISPLAY TRANSIENTS
          BSET      STAT5,$04         SLEEP DISPLAY
          BRA       SLPTOK            NO DECREMENT IF FIRST TIME
DECS      LDAA       SLEPT             DECREMENT SLEEP TIMER
          SUBA      #5
          STAA      SLEPT
          BMI       INSLP

SLPTOK    LDAA       #25
          STAA      DIST
          BSET      STAT4,$01         START DISPLAY TRANSIENT
          BRSET     PORTD,Y,$20,SODM   ALREADY ON ?
          BCLR     PORTA,Y,$10        YES, JUST DEMUTE
          RTS

*****
*
*           Number entry routine.
*
*****

DIGIT     BRSET      PORTD,Y,$20,AB03   STANDBY ?
          JSR       CLTR              NO, CLEAR DISPLAY TRANSIENTS
          LSRB
          LSRB
          BRSET     STAT,$01,SKP       STATION MODE ?
          BRSET     STAT5,$40,SKP     NO, STORE MODE ?
          BSET      STAT5,$10         NO, SET RETUNE FLAG (FREQUENCY MODE)
          BLCP      STAT5,$20         AND CLEAR TA INHIBIT BIT (NVM)
          STAB      W3
          BRCLR    STAT,$04,SHIFT     CLEAR Q ?
          BCLR     STAT,$04         YES, CLEAR FLAG
          JSR      CLQ               AND CLEAR Q
SHIFT      BSR       DR1              W1: MSD, W2: LSD
          LDX      W1
AGS        LDAA      1,X              MOVE ALL DIGITS
          STAA     1,X                UP ONE PLACE
          INX
          CPX      W2
          BNE      AGS                DONE ?
          LDAA     W3                 YES, RECOVER NEW DIGIT
          STAA     0,X                AND PUT IT IN LSD
          RTS

```

Application Note

```

SKP      BSET      PORTA,Y,$10      MUTE
        TBA
        STAA
        JMP      RETUNE

*****
*
*   Save pointers & 500ms delay.
*
*****

DR1      LDX      #RQ              STORE POINTERS
        STX      W1
        LDAB     #5
        ABX
        STX      W2
ABO3     RTS

DEL500   LDX      #255
        JSR      SKDB
        LDX      #255
        JMP      SKDB

*****
*
*   Increment key (& knob).
*
*****

PINC2    BRSET    STAT4,$20,ALSU1    ALARM SET-UP ?
        BRSET    STAT4,$08,TOG57    NO, ALARM DISPLAY ?
        BRSET    PORTD,Y,$20,DMI    NO,STANDBY ?
        LDAB     PSNP
        BNE      PSN0              NO,PS EDIT MODE ?
        JMP      UP                NO, STEP UP

PINC     BRSET    STAT4,$20,ALSU1    ALARM SET-UP ?
TOG57J   BRSET    STAT4,#08,TOG57    NO, ALARM DISPLAY ?

        BRSET    PORTD,Y,$20,DMI    NO, STANDBY ?
        BRSET    STAT,$01,NACS      NO, FREQ. MODE ?
        JMP      UP                YES, STEP UP

*****
*
*   Alarm inc. (hours/minutes).
*
*****

ALSU1    BRSET    STAT4,$40,IHR      YES, SET-UP HOURS ?
        LDAA     AMIN              NO, MINUTES
        CMPA     #59
        BHS     TOO
        INC      AMIN
        BRA     T5S
TOOH     CLR      AMIN
        BRA     T5S
IHR      LDAA     AOUR
        CMPA     #23
        BLO     HTOH
        CLR      AOUR
        BRA     T5S
HTOH     INC      AOUR
T5S      LDAA     #80              10 SECOND TIMEOUT
        STAA     DIST
        BSET    STAT4,$01          SET DISPLAY TRANSIENT FLAG
        BCLR    PORTA,Y,$10       DEMUTE
DMI      RTS

NACS     LDAB     PSNP
        BEQ     CONTI              NO, PS EDIT MODE ?

```

Freescale Semiconductor, Inc.


```

*****
*
* P-S Edit inc. (ASCII) and 5/7 day toggle *
*
*****

PSN0      LDX          #PSN-1
          ABX
          LDAA        0,X          YES
          INCA        INCREMENT ASCII VALUE
          CMPA        #$20        SPACE
          BLS         MAK20       LESS OR EQUAL ?
          CMPA        #$2E        NO, .
          BLS         MAK2E       LESS OR EQUAL ?
          CMPA        #$30        NO, 0
          BLO         MAK30       LESS ?
          CMPA        #$39        NO, 9
          BLS         CNTB        LESS OR EQUAL ?
          CMPA        #$41        NO, A
          BLO         MAK41       LESS ?
          CMPA        #$5A        NO, Z
          BLS         CNTB        LESS OR EQUAL ?
          CMPA        #$61        NO, a
          BLO         MAK61       LESS ?
          CMPA        #$7A        NO, z
          BLS         CNTB        LESS OR EQUAL ?
          LDAA        #$20        MAKE SPACE
          BRA         CNTB
          LDAA        #$2E        MAKE .
          BRA         CNTB
          LDAA        #$30        MAKE 0
          BRA         CNTB
          LDAA        #$41        MAKE A
          BRA         CNTB
          LDAA        #$61        MAKE a
          STAA        0,X
          LDAA        #80
          JMP         OUTCH

TOG57     BRCLR      STAT4,$10,DMI  ALARM ARMED ?
          BRCLR      STAT5,$80,A7  YES, 7-DAY ALARM ?
          BCLR       STAT5,$80     NO, MAKE IT 7 DAY
          BRA        T5S

A7        BSET       STAT5,$80     YES, MAKE IT 5 DAY
          BRA        T5S

*****
*
* Program number increment. *
*
*****

CONTI     BSET       PORTA,Y,$10    MUTE
          BSET       STAT2,$08     PROG. No. INCREMENT, UPDATE DISPLAY
          LDAA        LED
          BRSET      STAT2,$80,IOK  IF SWITCHED TO TA DON'T INCREMENT
          INCA        NEXT PROG.
          CMPA        #9           TOO HIGH ?
          BLS         IOK
          CLRA        YES, BACK TO ZERO
          STAA        LED
          JMP         RETUNE

IOK

*****
*
* Decrement key (& knob). *
*
*****

PDEC2     BRSET      STAT4,$20,ALSU2  ALARM SET-UP ?
          BRSET      STAT4,$08,TOG57  NO, ALARM DISPLAY ?
          BRSET      PORTD,Y,$20,DMD  NO, STANDBY ?
          LDAB        PSNP
          BNE        PSN1           NO, PS EDIT MODE ?
          JMP         DOWN          NO, STEP DOWN

```

Application Note

```

PDEC      BRSET      STAT4,$20,ALSU2      ALARM SET-UP ?
          BRSET      STAT4,$08,TOG57      NO, ALARM DISPLAY ?
          BRSET      PORTD,Y,$20,DMD      NO, STANDBY ?
          BRSET      STAT,$01,NACS2      NO, FREQ. MODE ?
          JMP         DOWN                YES, STEP DOWN

*****
*
*      Alarm dec. (hours/minutes). *
*
*****

ALSU2     BRSET      STAT4,$40,IHRD      YES, SET-UP HOURS ?
          TST        AMIN                NO, MINUTES
          BEQ        MZ
          DEC        AMIN
          BRA        T5SD

MZ        LDAA       #59
          STAA       AMIN
          BRA        T5SD

IHRD      TST        AOUR
          BNE        HZ
          LDAA       #24
          STAA       AOUR

HZ        DEC        AOUR

T5SD      LDAA       #80                10 SECOND TIMEOUT
          STAA       DIST
          BSET      STAT4,$01          SET DISPLAY TRANSIENT FLAG
          BCLR     PORTA,Y,$10        DEMUTE

DMD       RTS

NACS2     LDAB       PSNP
          BEQ        CONTD              PS EDIT CHARACTER CHANGE ?

*****
*
*      P-S Edit dec. (ASCII). *
*
*****

PSN1      LDX        #PSN-1
          ABX
          LDAA       0,X                YES
          DECA      DECREMENT ASCII VALUE
          CMPA      #$20                SPACE
          BLS      MKE7A                LESS OR EQUAL ?
          CMPA      #$2E                NO, .
          BLS      MKE20                LESS OR EQUAL ?
          CMPA      #$30                NO, 0
          BLO      MKE2E                LESS ?
          CMPA      #$39                NO, 9
          BLS      CNTS                LESS OR EQUAL ?
          CMPA      #$41                NO, A
          BLO      MKE39                LESS ?
          CMPA      #$5A                NO, Z
          BLS      CNTS                LESS OR EQUAL ?
          CMPA      #$61                NO, a
          BLO      MKE5A                LESS ?
          CMPA      #$7A                NO, z
          BLS      CNTS                LESS OR EQUAL ?
          LDAA      #$20                MAKE SPACE

MKE20     LDAA      #$20
          BRA      CNTS

MKE2E     LDAA      #$2E                MAKE .
          BRA      CNTS

MKE5A     LDAA      #$5A                MAKE Z
          BRA      CNTS

MKE7A     LDAA      #$7A                MAKE z
          BRA      CNTS

MKE39     LDAA      #$39                MAKE A
          STAA      0,X
          LDAA      #80

OUTCH     STAA      DIST
          BSET      STAT4,$01          SET DISPLAY TRANSIENT FLAG
          BCLR     STAT4,$08          NOT ALARM DISPLAY MODE
          RTS
    
```

Freescale Semiconductor, Inc.



```

*****
*
*   Program number decrement. *
*
*****

CONTD   BSET      PORTA,Y,$10      MUTE
        LDAA      LED              PROG. No. DECREMENT
        BRSET     STAT2,$80,RETUNE IF SWITCHED TO TA DON'T DECREMENT
PNM1    DECA
        BPL       SK2P             DECREMENT PROGRAM NUMBER
        LDAA      #9               TOO FAR ?
SK2P    STAA      LED              SAVE NEW PROGRAM NUMBER
RETUNE  LDAB      #120             CHANGE PROGRAM NUMBER IN NVM
        JSR       WRITE1
        PULA
        BRCLR    STAT4,$80,RETUNE2 TA SWITCHED ?
        BCLR     STAT4,$80        YES, MANUAL RETURN FROM TA
        LDAA      #9
        STAA     REARET
        RTS

RETUNE2 JSR       DOIT              NEW PROGRAM
        JSR       P5170
        LDX       #64              WAIT 100ms
        JSR       SKDB
        BCLR     PORTA,Y,$10      DEMUTE
        BCLR     STAT2,$02        KILL ANY PENDING RDS GROUP
        BCLR     STAT3,$01        AND INHIBIT FM PS-NAME CLEARING
        BCLR     STAT,$10         RE-ENABLE RDS DATA CLEARING
        RTS

FOK     LDAB      #10
        MUL
        ADDB     #$5C
        STAB     SMEM
        ADCA     #$26
        STAA     SMEM+1
        JMP      NEW

*****
*
*   Tune to TA (using EEPROM data)*
*
*****

TASW    CLRB
TPIC    ADDB      #10
        JSR      READ1             FIND PI
        INCB
        CMPA     PION             MSB OK ?
        BNE     TNP
        DECB
        JSR      READ1
        CMPA     PION+1           LSB OK ?
        BNE     TNP
        SUBB     #12              YES, FOUND IT
        JSR      READ1
        PSHA
        ANDA     #$80             NVM INHIBIT FLAG SET ?
        BEQ     TASOK
        LDAA     #8              NVM INHIBIT MESSAGE
        BRA     ABTA
TASOK   PULA
        STAA     SMEM+1
        JSR     NEWSUB2
        JMP     NEW

TNP     CMPB     #252             TRY NEXT RECORD
        BLO     TPIC
        PSHA
        LDAA     #7
ABTA    STAA     REARET
        PULA

```

Application Note

Freescale Semiconductor, Inc.

```

BCLR          STAT4,$80          PI MATCH NOT FOUND, FORGET IT
RTS

*****
*
*      Program store/recall.
*
*****

DOIT          BRSET          STAT2,$80,TASW
              LDAB          #12
              MUL
              BRSET          STAT5,$40,STORE
              JMP           RECALL

*****
*
* NVW write, sub-address in X.
*
*****

STORE        BCLR          SMEM+1,$80
              BRCLR        STAT5,$20,SKTA          TA NVM INHIBIT FLAG SET ?
              BSET          SMEM+1,$80
SKTA         LDAA          SMEM+1          BINARY FREQUENCY MSB
              JSR           WRITE1
              LDAA          SMEM          BINARY FREQUENCY LSB
              JSR           WRITE1
              LDAA          PSN
              CMPA          #$A0          PS NAME OK ?
              BEQ           PSNOK
              CMPA          #$FF          PERHAPS, TRY FF
PSNOK        BNE           PSOK
              LDAA          #$FF
              JSR           WRITE1
              LDAA          DISP+10
              JSR           WRITE1
              LDAA          DISP+11
              JSR           WRITE1
              LDAA          DISP+12
              JSR           WRITE1
              LDAA          DISP+13
              JSR           WRITE1
              LDAA          DISP+14
              JSR           WRITE1
              LDAA          DISP+15
              JSR           WRITE1
              LDAA          #$20
              JSR           WRITE1
              LDAA          #$00          DUMMY PI CODE
              JSR           WRITE1
              LDAA          #$00
              BRA           FINST

PSOK         JRS           WRITE1
              LDAA          PSN+1
              JSR           WRITE1
              LDAA          PSN+2
              JSR           WRITE1
              LDAA          PSN+3
              JSR           WRITE1
              LDAA          PSN+4
              JSR           WRITE1
              LDAA          PSN+5
              JSR           WRITE1
              LDAA          PSN+6
              JSR           WRITE1
              LDAA          PSN+7
              JSR           WRITE1
              LDAA          PI          PI CODE
              JSR           WRITE1
              LDAA          PI+1
FINST        JSR           WRITE1
              BCLR          STAT5,$40          CLEAR STORE MODE
              RTS
    
```



```

*****
*
*   NVW read, sub-address in X.
*
*****

```

```

RECALL   BSR      NEWSUB
         JMP      NEW

NEWSUB   JSR      READ1
         STAA     SMEM+1
         BCLR    STAT5,$20
         BRCLR   SMEM+1,$80,NEWSUB2
         BSET    STAT5,$20

NEWSUB2  JSR      READ1
         CMPA    #$FF
         BNE    NOTFF2
         LDAA    #$26           $04
         STAA    SMEM+1
         LDAA    #$5C           $2E

NOTFF2   STAA    SMEM
         JSR     READ1
         STAA    PSN
         JSR     READ1
         STAA    PSN+1
         JSR     READ1
         STAA    PSN+2
         JSR     READ1
         STAA    PSN+3
         JSR     READ1
         STAA    PSN+4
         JSR     READ1
         STAA    PSN+5
         JSR     READ1
         STAA    PSN+6
         JSR     READ1
         STAA    PSN+7
         RTS

```

```

*****
*
*   NVW read & write one byte.
*
*****

```

```

READ1   JSR      GETAD
         LDAA    0,X
         INCB
         RTS

WRITE1  LDY      #$1000
         BSET   PPROG,Y,$16      SET EELAT, ERASE & BYTE ERASE BITS
         BSR    WBYTE            ERASE BYTE
         JSR    DBOUNC           WAIT 15 ms
         BSET   PPROG,Y,$02      SET EELAT TO WRITE BYTE
         DECB

WBYTE   JSR      GETAD
         STAA    0,X            LATCH DATA
         BSET   PPROG,Y,$01      SET EEPGM BIT TO START PROGRAMMING
         JSR    DBOUNC           WAIT 15 ms
         CLR    PPROG,Y         STOP
         INCB
         RTS

GETAD   PSHA
         PSHB
         JSR    BAND            GET BAND
         LDX    #$B618          EEPROM START ADDRESS
         TBA
         CMPA   #1             FM ?
         BLS    FMB
         LDAB   #122           NO, AM
         ABX
         CMPA   #2             MW ?
         BEQ    FMB

```

Application Note

Freescale Semiconductor, Inc.

```

ABX          NO, SW
BRCLR        PORTE,Y,$40,SWB2    SECOND BANK ?
ABX          YES
SWB2
*           BRCLR        PORTE,Y,$80,FMB    SECOND PAIR OF BANKS ?
*           ABX          YES
*           ABX
FMB         PULB
           PULA
           ABX
           RTS

*****
*           *
*           RDS displays.           *
*           *
*****

RTDSP       BRSET        PORTD,Y,$20,SRT    STANDBY ?
BRSET        STAT5,$02,NOTRT    ALREADY RDS DISPLAY ?
BRCLR        STAT2,$04,NORT    ALREADY RT DISPLAY ?

NOTRT       BSET        STAT5,$02          SET RDS DISPLAY FLAG
LDAA         RTDIS          YES, MOVE ON
INCA
CMPA        #26
BEQ         NOTRT
STAA        RTDIS
LDAA        #100
STAA        DIST
BSET        STAT4,$01          RE-START TRANSIENT TIMEOUT
RTS

NORT        JSR         CLTR
BSET        STAT2,$04          SET RT DISPLAY FLAG
LDAA        #9
STAA        DISP1
LDAA        #1
STAA        DISP2
RTS

*****
*           *
*           Increment and decrement routines.           *
*           *
*****

UP          BSR         LDXR
IF          INC         SMEM          NO, INCREMENT LSB
BNE        TT1         TT1          DID IT WRAP ROUND
INC        SMEM+1      YES, INCREMENT MSB

TT1        DECB
BNE        IF          ALL DONE ?
BRA        NEWJ

DOWN       BSR         LDXR
DF         TST         SMEM          NO, IS LSB ZERO ?
BNE        TT2         TT2          IF NOT LEAVE MSD
DEC        SMEM+1      DECREMENT MSB
TT2        DECB        SMEM          DECREMENT LSB
BNE        DF          ALL DONE ?

NEWJ       JSR         NEW
JSR        P5170
BCLR       PORTA,Y,$10    DEMUTE
RTS

LDXR       BRCLR       STAT6,$08,LDXR2    AM ?
BSET       STAT2,$40    YES, CLEAR PS NAME
BRA        NFMB

LDXR2      BSET       STAT3,$01          NO, FM, ENABLE PS NAME CLEARING
NFMB       JSR        BAND              GET BAND
TBA
LDAB       #1
BRCLR     STAT,$02,SRT    SINGLE STEP (1,5,10 kHz FOR MW,SW,FM)
CMPA      #3             LARGE STEPS SELECTED ?
                                YES, BAND 3 (SW) ?

```

```

BEQ          SRT
LDAB         #5          NO, x5 STEP (50 kHz FOR FM)
CMPA        #2          MW ?
BNE         SRT
LDAB         #9          YES, 9kHz
BRCLR       STAT6,$40,SRT OR SHOULD IT BE 10kHz
INCB
SRT          YES
RTS

*****
*
*           TA test.
*
*****

TEST        BRSET       PORTD,Y,$20,AOB    STANDBY ?
           LDD         #C5B1             CLYDE 1
           STD         PION
           BRSET       STAT4,$04,NABT     TA SWITCHING ENABLED ?
           LDAA        #1                NO, SET RETURN REASON
           STAA        REARET

AOB
NABT        BSET        STAT4,$80        YES, DO IT
           RTS

*****
*
*           Store key.
*
*****

SAVE        BRCLR       STAT4,$08,NAME    ALARM DISPAY ?
           BRCLR       STAT4,$10,NTB2     YES, ALARM ARMED ?
           BRSET       STAT4,$20,AISM     YES, ALREADY SET-UP MODE ?
           BSET        STAT4,$60         NO, ENTER SET-UP MODE, HOURS

A5SD        LDAA        #80
           BRA         SDT

AISM        BRSET       STAT4,$40,MSM     YES, SET-UP HOURS ?
           BCLR        STAT4,$20         NO, CANCEL SET-UP
           BRA         A5SD

MSM         BCLR        STAT4,$40         YES, MAKE IT MINUTES
           BRA         A5SD

NAME        BRSET       PORTD,Y,$20,NTB2  STANDBY ?
           BRSET       STAT,$01,NFM       NO, FREQUENCY MODE ?
           BRSET       STAT5,$40,ASM     YES, STORE MODE ?
           BSET        STAT5,$40         NO, ENTER STORE MODE
           RTS

ASM         LDAA        LED
           JMP         DOIT              SAVE

NFM         LDAA        PSNP              NOT FREQUENCY MODE
           BNE        SKPCLR             SET
           JSR        CLTR               UP
SKPCLR      INC         PSNP              PS-NAME CHANGE MODE
           LDAA        PSNP
           CMPA       #8
           BLS        NTB3
           CLR        PSNP

NTB3        LDAA        #80
           SDT        DIST
           BSET       STAT4,$01          SET DISPLAY TRANSIENT FLAG
NTB2        RTS

*****
*
*   PROG, the displayed number is added to
*   the IF offset, converted to binary and
*   stored in SMEM & SMEM+1.
*
*   NEW takes binary working frequency
*   in SMEM & SMEM+1 converts it to BCD and
*   subtracts the IF offset.
*
*****

```

Application Note

```

PROG      BRSET      STAT,$01,NEW      STATION MODE ?
          JSR        IFO              P < IF OFFSET
          JSR        ADB              Q < FREQ + IF

          JSR        BAND
          BNE        ONE              BAND 3 (SW) ?
          JSR        ADD              YES, DIVIDE BY 5, Q < 2 X (FREQ + IF)
          LDX        #5

LPP       LDAA       RQ-1,X          MOVE ALL DIGITS
          STAA       RQ,X            IN Q DOWN ONE
          DEX
          BNE        LPP              PLACE TO DEVIDE
                                      BY 10 (Q < Q/5)

ONE       JSR        BCON             CONVERT Q TO BINARY

NEW      JSR        DCON             CONVERT TO BCD IN Q

          JSR        BAND
          BNE        STIF             BAND 3 (SW) ?
          STX        NUM1             YES
          LDX        #RP
          JSR        ADD              P < 2Q
          LDX        #RP
          STX        NUM1
          LDX        #RQ
          JSR        ADD              Q < 3Q
          LDX        #RQ
          JSR        ADD              Q < 5Q

STIF     JSR        IFO              P < IF OFFSET
          BSET      STAT,$04
          JMP        SUB              Q < (RATIO X STEP) -IF

*****
*
* The IF offset is selected according to *
* the required band and placed in "RP." *
*
*****

IPO      BSR        BAND             FIND BAND
          BRSET     PORTA,Y,$04,NOTN NEGATIVE FM IF ?
          CMPB      #1               YES
          BHI       NOTN             BUT IS IT FM ?
          LDAB      #4               YES, FIFTH IS FROM TABLE

NOTN     LDAA       #6

LP6      MUL        #1FS             TIMES 6
          LDX
          ABX
          LDY       #RP
          LDAA      0,X              TRANSFER
          STAA      0,Y              INTO RP
          INX
          INY
          CPY       #RP+6
          BLO      LP6              DONE ?
          LDY       #$1000           RE-INITIALISE Y
          LDX       #RP              SET-UP POINTERS
          STX       NUM2
          LDX       #RQ
          STX       NUM1

IFS      FCB        0,0,1,0,7,0     10.70 MHz FM OSC HIGH
          FCB        0,0,1,0,7,0     10.70 MHz FM OSC HIGH
          FCB        0,0,0,4,5,5     455 kHz SW/MW
          FCB        0,1,0,7,0,0     10.70 MHz SW (EXT/5 FOR 5157)
          FCB        9,9,8,9,3,0     -10.70 MHz FM OSC LOW

BAND     LDAB       PORTA,Y          GET BAND
          ANDB      #$03
          LDX       #RQ
          STX       NUM2
          CMPB      #3
          RTS              BAND 3 (SW, /5) ?
    
```

Freescale Semiconductor, Inc.



```

*****
*
*   Mode change & clear routines.*
*
*****

MODE      BRSET      PORTD,Y,$20,CLP      STANDBY ?
          JSR        CLTR
          JSR        PROG
SKIP      BRCLR     STAT,$01,SK      SEND DISPLAYED FREQUENCY
          BCLR      STAT,$01        FREQUENCY MODE ?
          RTS
                                     NO, SET TO FREQUENCY MODE

SK        BCLR      STAT5,$40        FREQ. MODE, CLEAR STORE MODE
          BRCLR     STAT5,$10,NNTR   NEW FREQUENCY ENTERED ?
          BSET      PORTA,Y,$10     YES, MUTE
          JSR        DBNC            WAIT 15ms
          JSR        P5170
          LDX       #64
          JSR        SKDB            WAIT 100ms
          BCLR      PORTA,Y,$10     DE-MUTE
          BCLR      STAT2,$02       AND KILL ANY PENDING RDS GROUP
          BCLR      STAT5,$10       CLEAR RETUNE FLAG
          RTS

NNTR      BSET      STAT,$01        NO, RETURN TO STATION MODE
          BCLR      STAT5,$40       CANCEL STORE MODE
          RTS

CLEAR     BRSET      PORTD,Y,$20,CLP  STANDBY ?
          BRSET     STAT,$01,SM      NO, STATION MODE ?
          BSET      STAT5,$10       FREQUENCY CHANGED
          CLAL      CLQ              NO, CLEAR Q
          SM        LDAA            PSNP
          BEQ       SPCC            PSC
          JSR        JSR            CLTR
          SPCC      BRSET     STAT,$02,KHZ  CLEAR DISPLAY TRANSIENTS
          BSET      STAT,$02        9 (MW), 50 (FM) kHz STEPS
          RTS
          BCLR      STAT,$02        1 (MW), 10 (FM) kHz STEPS
          CLP      RTS

CLQ       LDX       #RQ              CLEAR RQ
          CLRAS    LDAA            #06      CLEAR 6 BYTES
          CR        STAA            COUNT   STARTING AT X
          CLR       CLR            0,X
          INX      DEC             COUNT
          DEC      BNE            CR        DONE ?
          RTS

CLTR      BCLR      STAT4,$01        CLEAR DISPLAY TRANSIENT FLAG
          CLTR2    BCLR      STAT2,$04   CANCEL RT DISPLAY
          CLR       CLR            RTDIS
          BCLR      STAT4,$28        NOT ALARM (DISPLAY OR SET-UP)
          BCLR      STAT5,$06       NOT RT OR SLEEP DISPLAY
          CLR       PSNP            NOT PS-EDIT
          RTS

```

```

*****
*
*   BCD to binary conversion. No, in "RQ" is *
*   converted to binary in SMEM & SMEM+1.   *
*
*****

```

```

BCON      CLR       SMEM              CLEAR WORKING
          CLR       SMEM+1          FREQUENCY LOCATIONS
          LDX      #0
L2        LDAA     SMEM              LS BYTE
          LSLA    2xLSB
          STAA    W1                SAVE 2xLSB
          ROL     SMEM+1           2xMS BYTE
          LDAA    SMEM+1
          STAA    W2                SAVE 2xMSB

```

Application Note

```

LDAA      W1          2xLSB
LSLA      4xLSB
ROL       SMEM+1     4xMSB
LSLA      8xLSB
ROL       SMEM+1     8xMSB
ADDA      W1          10xLSB
STAA      SMEM
LDAA      SMEM+1
ADCA      W2
STAA      SMEM+1
ADCA      W2          10xMSB
STAA      SMEM+1
INX
LDAA      RQ,X       FETCH
ADDA      SMEM       NEXT
STAA      SMEM       DIGIT
LDAA      #0         AND
ADCA      SMEM+1     (CLRA CLEARS THE C BIT)
STAA      SMEM+1     ADD IT TO WORKING
CPX       #5         FREQUENCY
BNE      L2          DONE ?
RTS
    
```

```

*****
*
*      Clear NVM - not used.
*
*****
    
```

```

CLRNVW    CLR        COUNT
CLOP      LDAA       #$FF
          LDAB       COUNT
          JSR        WRITE1
          INC        COUNT
          BNE       CLOP
          CLRA
          LDAB       #120          CLEAR MAX. PROG. No.
          JMP       WRITE1
    
```

```

*****
*
*      Addition and subtraction of BCD numbers.
*
*****
    
```

```

SUB        STX        W5          ANSWER POINTER
COM2       LDX        NUM2        9S COMPLIMENT
COMP      LDAB       #$06        SECOND NUMBER
LOOP3     LDAA       #$09
          SUBA      5,X          SUBTRACT FROM 9
          STAA     5,X          AND PUT IT BACK
          DEX
          DECB
          BNE      LOOP3
          CLR      CARRY        SET CARRY TO ONE
          INC     CARRY        BEFORE ADDING
          BRA     AD           ADD FIRST NUMBER

ADD        CLR        CARRY
AD         STX        W5          ANSWER POINTER
          LDAB     #$06
          LDX     NUM1        1st No. POINTER
          STX     W3          2nd No. POINTER
          LDX     NUM2
          STX     W4
          LDX     W3
          LDAA     5,X
          DEX
          STX     W3
          LDX     W4
          ADDA    5,X          ADD
          DEX
          STX     W4
          ADDA    CARRY        SET ON ADDITION OVERFLOW
          CLR     CARRY        OR POS. RESULT SUBTRACTION
          BSR     ADJ         DECIMAL ADJUST
    
```

```

LDX      W5
STAA     5,X          SAVE ANSWER
DEX
STX      W5
DECB
BNE      LOOP        DONE ?
RTS

AJ       SUBA        #10      YES, SUBTRACT 10
          INC         CARRY    AND RECORD CARRY
ADJ      CMPA        #10
          BHS         AJ       10 OR MORE ?
          RTS         NO

*****
*
*   Current binary divide ratio in SMEM &
*   SMEM+1 is converted to decimal in RQ.
*
*****

DCON     LDAA        SMEM+1    TRANSFER CURRENT
          STAA        W2        FREQUENCY DIVIDE
          LDAA        SMEM      RATIO INTO
          STAA        W1        WORKING AREA
DCON2    LDX         #RR        CLEAR
          STX         NUM1
          JSR         CLRAS      RR
          INC         RR+5      RR <- 1
          JSR         CLQ        CLEAR RQ
          LDAA        #14       14 BITS TO CONVERT
          STAA        W6
LOOP2    LSR         W2        MOVE OUT
          ROR         W1        FIRST (LS) BIT
          BCC         NXT       ZERO
          LDX         #RQ        ONE, ADD
          STX         NUM2      CURRENT VALUE
          BSR         ADD        OF RR
NXT      LDX         #RR        ADD RR
          STX         NUM2      TO
          BSR         ADD        ITSELF
          DEC         W6        ALL
          BNE         LOOP2     DONE ?
          RTS

*****
*
*           Delay (X x 1.5mS).
*
*****

DBNC     LDX         #100       150mS
          BRA         SKDB
DBOUNC   LDX         #10
          SKDB         W6        APPROX 15mS WITH A 8.388 MHz XTAL
          DLP         #FF       X x 1.5mS
          BRN         "         PAUSE
          BRN         "         256X12
          DEX
          BNE         DLOOP     CYCLES
          DEC         W6+1
          BNE         DLP
ABO      RTS

*****
*
*   Serial output routine to the MC145170.
*
*****

P5170    BCLR        PORTB,Y,$01  CLOCK LOW
          BCLR        PORTB,Y,$10  LE LOW
          LDAA        #0           CLEAR
          BSR         SQU8I        CONTROL REGISTER
          BSET        PORTB,Y,$10  LATCH IT

```

Application Note

```

BCLR      PORTB,Y,$10      LE LOW
LDAA      SMEM+1
ANDA     #$7F
BSR      SQU8I             SEND MSBYTE
LDAA      SMEM             AND LSBYTE OF
BSR      SQU8I             NEW FREQUENCY
BSET      PORTB,Y,$10     LATCH IT

BCLR      PORTB,Y,$10     LE LOW
LDAA      #$03
BSR      SQU7I             REFERENCE
LDAA      #$20
BSR      SQU8I             800 = 8MHz/10kHz
BSET      PORTB,Y,$10     LATCH IT
    
```

```

*****
*
*   Serial output routine to the MC145157. *
*
*****
    
```

P5157

```

LDAA      SMEM             TRANSFER SMEM AND
LSLA      MEM+1           MEM+1 TO TEMPORARY
STAA      W4              LOCATIONS AND MOVE
LDAA      SMEM+1         UP ONE BIT TO INCLUDE
ROLA      THE 5157 CONTROL BIT.
BSR      SQU7            SEND MSBYTE (7 BITS)
LDAA      W4             AND LSBYTE OF
BSR      SQU8            NEW FREQUENCY
BSET      PORTB,Y,$08    LATCH
BCLR      PORTB,Y,$08    IT
LDAA      #$4E           SEND 15 BIT (14+1)
BSR      SQU7            REFERENCE
LDAA      #$21           DIVIDE RATIO
BSR      SQU8
BSET      PORTB,Y,$08    LATCH IT
BCLR      PORTB,Y,$08    ALL LOW (5157/70 SWITCHED OFF)
RTS
    
```

```

*****
*
*   Subroutines for the MC145157/170. *
*
*****
    
```

```

SQU8I     LDAB      #8             SEND 8 BITS
          BRA       S1I
SQU7I     LSLA      #7             MOVE OUT MS BIT
          LDAB      #7             AND SEND OTHER 7
S1I       LSLA      #7             MOVE I BIT INTO "C"
          BCC      S2I             ZERO ?
          BSET     PORTB,Y,$02     NO
S21       BSET     PORTB,Y,$01     CLOCK
          BCLR    PORTB,Y,$01     IT
          BCLR    PORTB,Y,$02
          DECB
          BNE     S1I             ANY MORE ?
          RTS
SQU8      LDAB      #8             SEND 8 BITS
          BRA       S1
SQU7      LSLA      #7             MOVE OUT MS BIT
          LDAB      #7             AND SEND OTHER 7
S1        LSLA      #7             MOVE 1 BIT INTO "C"
          BCC      S2             ZERO ?
          BSET     PORTB,Y,$02     NO
S2        BCLR    PORTB,Y,$01     CLOCK
          BSET     PORTB,Y,$01     IT
          BCLR    PORTB,Y,$02
          DECB
          BNE     S1             ANY MORE ?
          RTS
    
```

```

*****
*
*   Toggle 9/10 kHz  step (MW). *
*
*****

T910  BRSET      STAT6,$40,CBH
      BSET      STAT6,$40
      RTS
CBH   BCLR      STAT6,$40
      RTS

*****
*
*   LINK batch files (RLE.BAT & RDE.LD) and PCBUG11 Vectors. *
*
*   ILD11 RADE.O FNCE.O RDSE.O -MKUF E32.MAP -G RDE -O RDE.OUT *
*   IHX RDE.OUT -O RDE.O *
*   TYPE E32.MAP *
*
*   section .RAM1 BSS origin 0x0000 *
*   section .RAM2 BSS origin 0x0100 *
*   section .RAM3 BSS origin 0x0200 *           E32 *
*   section .ROM1 origin 0xD000 *           $9000 *
*   section .ROM2 origin 0xE000 *           $9c00 *
*   section .ROM3 origin 0xF000 *           $A000 *
*   section .VECT origin 0xBFC1 *           - *
*   section .VECT2 origin 0xFFD6 *           ($FFD6) *
*
*****

*
SECTION      .VECT
*
*   JMP      START      SCI
*   JMP      START      SPI
*   JMP      START      PULSE ACCUMULATOR EDGE
*   JMP      START      " " OVER
*   JMP      START      TIMER OVER
*   JMP      START      " IC4/OC5
*   JMP      START      " OC4
*   JMP      START      " OC3
*   JMP      START      " OC2
*   JMP      START      " OC1
*   JMP      START      " IC3
*   JMP      START      " IC2
*   JMP      START      " IC1
*   JMP      TINTB      RTI
*   JMP      SDATA      IRQ
*   JMP      SHAF7X     NOT USED, XIRQ USED BY PCbug11
*   JMP      START      SWI
*   JMP      START      ILLEGAL OP CODE
*   JMP      START      COP
*   JMP      START      CLOCK MONITOR
*   JMP      START      RESET

*****
*
*   MC68HC11E32 Vectors. *
*
*****

*
SECTION      .VECT2
ORG          $FFD6

FDB      START      SCI
FDB      START      SPI
FDB      START      PULSE ACCUMULATOR EDGE
FDB      START      " " OVER
FDB      START      TIMER OVER
FDB      START      " IC4/OC5
FDB      START      " OC4
FDB      START      " OC3
FDB      START      " OC2
FDB      START      " OC1
FDB      START      " IC3
FDB      START      " IC2

```

Application Note

```

FDB      START      "      ICL
FDB      TINTB     RTI
FDB      SDATA     IRQ
FDB      SHAF TX   XIRQ
FDB      START     SWI
FDB      START     ILLEGAL OP CODE
FDB      START     COP
FDB      START     CLOCK MONITOR
FDB      START     RESET

```

END

Section synopsis

```

174)      .RAM1
256)      .RAM2
109)      .RAM3
2889)     .ROM1
42)       .VECT2

```

Symbol table

.RAM1	1	00000000	CONTD	4	000005df	INSLP	4	000003fe	NNTR	4	00000968	RECALL	4	00000702	
.RAM2	2	00000000	CONTI	4	00000529	IOK	4	0000053c	NO2D	4	000000c6	RETUNE	4	000005f0	
.RAM3	3	00000000	COUNT	1	0000009a	IOOK	4	0000022e	NOPS	4	000000d1	RETUNE2	4	00000603	
.ROM1	4	00000000	CPSL	4	000003cc	IRQ	4	00000006	NORT	4	000007c0	RJ	4	0000030a	
.VECT2	5	00000000	CR	4	0000099a	ITMP1	1	00000069	NOTCH	4	000002bc	RKEY	4	000002ea	
A5SD	4	00000847	CTAB	4	00000325	KBD	4	0000026f	NOTFF2	4	00000723	RP	1	0000007c	
A7	4	00000524	DAT	1	0000004b	KCLC	4	000002f3	NOTN	4	000008e0	RPT	4	00000309	
ABO	4	00000aa7	DBNC	4	00000a8e	KEY	1	00000096	NOTRT	4	000007ac	RQ	1	00000076	
ABO3	4	00000470	DBOUNC	4	00000a93	KEY1	4	00000279	NOTSNZ	4	000000e0	RR	1	00000082	
ABOA	4	000003a3	DCON	4	00000a58	KEYP	4	000002f5	NRDSP	4	0000019b	RT	3	00000028	
ABTA	4	0000065c	DCON2	E	4	00000a60	KEYP2	4	000002f7	NRML	4	000002c0	RTDIS	1	000000a3
AD	4	00000a24	DECS	E	4	0000040d	KHZ	4	0000098f	NS1	4	000003ea	RTDSP	4	0000079f
ADD	4	00000a1f	DEL500	4	00000471	KOUNT	1	00000097	NSRO	4	00000194	S1	4	00000b26	
ADJ	4	00000a53	DF	4	000007e0	L1	4	00000298	NT1	4	00000165	S1I	4	00000b08	
ADON	4	00000393	DI	1	000000a4	L2	4	000009bf	NT2	4	0000017b	S2	4	00000b2d	
AGS	4	0000044e	DIG2	1	00000098	L5	4	000001b8	NT2J	4	000000e4	S2I	4	00000b0f	
AISM	4	0000084b	DIGIT	4	00000426	L6	4	000001d6	NTB2	4	00000889	SAVE	4	00000838	
AJ	4	00000a4e	DISP	3	00000000	LAST	4	0000037d	NTB3	4	00000882	SCHAN	1	000000a5	
ALARM	4	00000381	DISP1	1	00000074	LDRX	4	000007f9	NUM1	1	0000009b	SCNT	1	000000ad	
ALOF	4	0000038e	DISP2	1	00000075	LDXR2	4	00000802	NUM2	1	0000009d	SDATA	I	0	00000000
ALRON	4	000003be	DISPP	3	00000010	LED	1	0000009f	NWA	4	000000f1	SDT	4	00000884	
ALSU1	4	000004a5	DIST	1	00000047	LEV	1	00000067	NWWS	4	00000173	SEC	1	0000006f	
ALSU2	4	00000569	DLOOP	4	00000a9b	LOOP	4	00000a2e	NXT	4	00000a81	SEM	4	00000257	
AMIN	1	00000072	DLP	4	00000a98	LOOP2	4	00000a72	OK6	4	0000020b	SHAFT	E	4	0000024d
ANTI	4	00000191	DMD	4	00000594	LOOP3	4	00000a0d	ONAG	4	00000101	SHAF TX	4	0000025e	
AOB	4	00000833	DMI	4	000004d2	LP6	4	000008eb	ONE	4	000008a6	SHIFT	4	0000044a	
AOUR	1	00000073	DNT	4	000002f4	LPP	4	0000089f	ONOFF	4	000003a4	SK	4	00000946	
ARI	4	00000220	DNT2	4	000002ed	M8	4	00000079	OUR	1	00000071	SK2P	4	000005ee	
ASM	4	0000086a	DOIT	4	00000663	MAK20	4	000004fe	OUTCH	4	000005d6	SKDB	4	00000a96	
BAND	4	00000926	DOM	1	00000044	MAK2E	4	00000502	P	1	00000015	SKIP	4	0000093e	
BCON	4	000009b6	DOW	1	00000046	MAK30	4	00000506	P5157	4	00000ada	SKP	4	0000045c	
BCTO	1	000000ac	DOWN	4	000007de	MAK41	4	0000050a	P5170	4	00000aa8	SKPCLR	4	00000876	
BD3	4	000001ec	DR1	4	00000466	MAK61	4	0000050e	PDEC	4	00000555	SKSM	4	00000964	
BIT	1	00000068	E6L	4	000001fa	MIN	1	00000070	PDEC2	4	00000541	SKTA	4	0000067b	
BMJD	1	00000000	EON	2	00000000	MJD	1	00000030	PI	1	00000061	SLEEP	4	000003f6	
BTO	4	00000201	EXIT	4	000002ab	MJDAT	I	0	00000000	PIN	1	00000065	SLEP	4	00000400
CARRY	1	00000099	FINST	4	000006fb	MKE20	4	000005c0	PINC	4	00000491	SLEPT	1	00000048	
CBCD	I	0	00000000	FLN	4	00000122	MKE2E	4	000005c4	PINC2	4	0000047d	SLPTOK	4	00000415
CBH	4	00000b45	FMB	4	0000079b	MKE39	4	000005d0	PINOK1	4	00000161	SM	4	0000097d	
CE6	4	000001ec	FOK	4	0000061d	MKE5A	4	000005c8	PION	1	00000063	SMEM	1	000000a0	
CG6	4	000001c8	FULON	4	0000010f	MKE7A	4	000005cc	PJ	4	0000031d	SODM	4	000003b2	
CHE	4	000001e6	GETAD	4	00000780	MNTH	1	00000042	PNM1	4	000005e9	SOK	4	00000148	
CLAL	4	0000097b	GON2	4	000002c8	MOD	I	0	00000000	PROC	0	00000000	SPCC	4	00000984
CLEAR	4	0000096f	GOON	4	000002e4	MODE	4	00000933	PROG	4	0000088a	SQU7	4	00000b23	
CLOCK	I	0	00000000	GOON2	4	000002d0	MSH	4	00000238	PSC	4	000003c7	SQU7I	4	00000b05
CLOOP	4	0000005a	GOON3	4	000002de	MSM	4	00000854	PSN	3	00000020	SQU8	4	00000b1f	
CLOP	4	000009f5	GROUP	1	00000057	MZ	4	00000577	PSN0	4	000004d7	SQU8I	4	00000b01	
CLP	4	00000992	H2L	4	00000032	NABT	4	00000834	PSN1	4	00000599	SRT	4	00000820	
CLQ	4	00000993	HIGH	4	000003e9	NACS	4	000004d3	PSNOK	4	00000690	START	4	00000009	
CLRAS	4	00000996	HTOH	4	000004c4	NACS2	4	00000595	PSNP	1	0000004a	STAT	1	000000a6	
CLREON	I	0	00000000	HZ	4	00000586	NAME	4	00000859	PSOK	4	000006c7	STAT2	1	000000a7
CLRNVM	4	000009f2	IDLE	4	000000ac	NDU	4	000000db	PTY	1	0000005f	STAT3	1	000000a8	



CLTR	E	4	000009a3	IDLJ	4	0000023c	NEW	E	4	000008a9	PTYCMP	1	00000060	STAT4	1	000000a9	
CLTR2		4	000009a6	IF	4	000007d1	NEWJ		4	000007ee	Q	1	00000003	STAT5	1	000000aa	
CNTB		4	00000510	IFO	4	000008d3	NEWSUB		4	00000707	R	1	00000027	STAT6	1	000000ab	
CNTS		4	000005d2	IFS	4	00000908	NEWSUB2		4	00000716	RCLP	4	0000023f	STIF	4	000008ca	
COM2		4	00000a09	IHR	4	000004b9	NFM		4	0000086f	RDSTO	1	00000049	STORE	4	00000671	
COMP		4	00000a0b	IHRD	4	0000057d	NFMB		4	00000805	READ1	4	00000756	STR	4	00000405	
CONF		1	0000006c	INITD	I	0	00000000	NNT2	4	000000e7	REARET	1	000000a2	STRST	4	00000000	
SUB		4	00000a07	TATP	4	0000022a	TMPGRP		1	0000004f	TPOF	4	000003f2	W4	1	0000008e	
SWB2		4	0000079b	TBH	4	000000be	TMQ		1	0000000c	TPOK	4	00000155	W5	1	00000090	
SYN		1	0000006a	TEM	4	0000025a	TMRB		4	00000003	TT1	4	000007d9	W6	1	00000092	
T5S		4	000004c7	TEST	4	00000821	TNP		4	00000655	TT2	4	000007e8	W7	1	00000094	
T5SD		4	00000589	TFCC	I	0	00000000	TOG57	4	00000517	UDCNT	4	00000399	WAIT	I	0	00000000
T910		4	00000b3d	TH32	1	0000006d	TOG57J		4	00000495	UP	4	000007cf	WBYTE	4	0000076f	
TAEH		4	000003e6	TH8	1	0000006e	TOOH		4	000004b4	W1	1	00000088	WRITE1	4	0000075d	
TASOK		4	0000064c	TINTB	I	0	00000000	TPEN	4	000003d5	W2	1	0000008a	XEM	4	00000268	
TASW		4	0000062b	TMP	1	0000001e	TPIC		4	0000062c	W3	1	0000008c	YEM	4	0000026b	
TATP		4	0000022a														

Application Note

How to Reach Us:

Home Page:

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor
 Technical Information Center, CH370
 1300 N. Alma School Road
 Chandler, Arizona 85224
 +1-800-521-6274 or +1-480-768-2130
 support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
 Technical Information Center
 Schatzbogen 7
 81829 Muenchen, Germany
 +44 1296 380 456 (English)
 +46 8 52200080 (English)
 +49 89 92103 559 (German)
 +33 1 69 35 48 48 (French)
 support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
 Headquarters
 ARCO Tower 15F
 1-8-1, Shimo-Meguro, Meguro-ku,
 Tokyo 153-0064
 Japan
 0120 191014 or +81 3 5437 9125
 support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
 Technical Information Center
 2 Dai King Street
 Tai Po Industrial Estate
 Tai Po, N.T., Hong Kong
 +800 2666 8080
 support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
 P.O. Box 5405
 Denver, Colorado 80217
 1-800-441-2447 or 303-675-2140
 Fax: 303-675-2150
 LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

