

Using the Pulse Width Modulation with the MCF521x ColdFire[®] Microcontroller

by: Paolo Alcantára and Lech Olmedo
RTAC Americas

1 Introduction

This document is a quick reference to configure the pulse width modulation (PWM) module for the MCF521x microcontroller (MCU). Basic knowledge about the functional description and configuration options gives the user a better understanding on how the PWM module works. Some examples are included which are intended to be modified to suit the specific needs for any application.

2 MCF521x Pulse Width Modulation Features

The PWM module generates a synchronous series of pulses having a programmable period and duty cycle. With a suitable low-pass filter, the PWM can be used as a digital-to-analog converter.

Contents

1	Introduction	1
2	MCF521x Pulse Width Modulation Features	1
2.1	Description	2
3	Pulse Width Modulation Explanation	2
3.1	Clock Source	3
3.2	Scaled Clock	3
3.3	Center-Aligned	3
3.4	Left-Aligned	4
4	Case Studies	5
4.1	Example: Case study for the PWM Module	5
4.2	Example: Configuring PWM Module	5
4.3	Left-Aligned with Scaled Clock	7
4.4	Center-Aligned with Scaled Clock	8
5	Register Configuration	8
5.1	Port Assignment Register	8
5.2	PWM Clock Select Register	9
5.3	PWM Clock Select Register	9
5.4	PWM Scale [A,B] Registers	10
6	Configuration Summary	10
7	Configuration Notes	10
8	Conclusion	11
8.1	Considerations and References	11

2.1 Description

The main features of PWM module are:

- Double-buffered period and duty cycle
- Left-aligned or center-aligned outputs
- Eight independent PWM channels using 8-bit period register or four PWM channels using 16-bit period register.
- Byte-wide registers provide programmable duty cycle and period control
- Four programmable clock sources

3 Pulse Width Modulation Explanation

The example code shows how the PWM works employing 8 different PWM signals through the M5213EVB board. Half of these signals are displayed on 4 LEDs and the others can be corroborated using an oscilloscope. This demonstrates how to configure the PWM module in an easy way and allows you to include it very quickly in your projects.

A PWM signal has a frequency and a duty cycle. In most applications, the frequency is fixed while the duty cycle varies. [Figure 1](#) illustrates a PWM signal.




Figure 1. PWM Signal

A general purpose timer (GPT) using output compare mode can also implement a PWM signal. However, the PWM module is more precise with frequency and duty cycle.

A dedicated period and duty register exist for each channel and are double buffered. So if a change occurs in these registers, the change does not take effect until one of the following events occur:

- The effective period ends
- The counter resets to zero
- The channel is disabled

Additionally, the PWM module can generate four types of signals:

- Center-aligned with clock

- Center-aligned with scaled clock
- Left-aligned with clock
- Left-aligned with scaled clock

3.1 Clock Source

Each PWM channel can be associated with a clock generator: simple clock A, simple clock B, scaled clock A and scaled clock B. This distinction allows more flexibility in PWM module between channels. [Table 1](#) shows clock source options per channels.

Table 1. Source Clock and Associated PWM Channel

Source Clock	PWM channels
Clock A or Scaled Clock A	0, 1, 4, 5
Clock B or Scaled Clock B	2, 3, 6, 7

3.2 Scaled Clock

The PWM channel with a scaled clock first receives the simple clock as its clock source. Then, the generated reference is prescaled with another register. A block diagram showing the difference between the simple clocks and scaled clocks is in [Figure 2](#).




Figure 2. Difference Between Simple Clock and Scaled Clock

3.3 Center-Aligned

This feature can be applied to any channel. A center-aligned signal is handled by a counter and its ability to go up and down. Signal can start each period at high or low digital value. Each period can be divided in four states explained in [Figure 3](#).




Figure 3. Center-Aligned Signal

The steps 1–4 in Figure 3 are explained below:

1. The counter operates as an up/down counter in center-aligned mode and is set to up-counter at the beginning.
 2. When the PWM counter matches the duty register, the output flip-flop changes state causing the PWM also to change state from low to high (or high to low depending on the PPOL bit).
 3. A match between the PWM counter and period register changes the counter direction from an up-count to a down-count.
 4. When the counter decrements and matches the duty register again, the PWM output channel changes state.
1. When the PWM counter reaches 0x00, the counter changes from a down-count to an up-count and loads the double-buffered period and duty cycle values.

3.4 Left-Aligned

The feature is fully independent of the other channels. A left-aligned signal is handled by a counter and its capability to only count up depending on some registers. The signal can start each period at high or low digital value. Each period can be divided in two states as shown in Figure 4.




Figure 4. Left-Aligned Signal

The 8-bit counter is configured as an up-counter only.

1. A match between PWM counter and period register resets the counter and a change in output PWM state. A load is performed from the double buffer period and duty register.
2. When PWM counter matches the duty register, the output PWM changes state from low to high (or low to high depending on the PPOL bit).

4 Case Studies

4.1 Example: Case study for the PWM Module

This example uses eight PWM channels in 8-bit mode. All channels share the same clock source (simple clock or scaled clock).

There are two ways to calculate frequency for all channels:

- Using equations from [Table 2](#).
- Using the spreadsheet showed in [Figure 6](#) and [Figure 5](#).

With this approach, period ($PWMPER_n$) and duty cycle ($PWMDTY_n$) are the only differences between each PWM channel (without considering polarity and channel alignment).

After configuring each PWM channel, the last step is to enable the desired channels. After this, the PWM are fully independent and do not need any more configuration. Although, the PWM frequency and duty cycle can be changed on the go and are reflected on the next PWM period.

4.2 Example: Configuring PWM Module

[Table 2](#) shows all equation to be applied for each PWM signal type.

Table 2. PWM Equations

Equations	Description
$f_n = \frac{f_{SYS/2}}{2 * PCK[A,B] * PWMSCLA * PWMPER_n}$	Left-aligned with scaled clock [A,B]
$f_n = \frac{f_{SYS/2}}{4 * PCK[A,B] * PWMSCLA * PWMPER_n}$	Center-aligned with scaled clock [A,B]
$f_n = \frac{f_{SYS/2}}{PCK[A,B] * PWMPER_n}$	Left-aligned with clock [A,B]
$f_n = \frac{f_{SYS/2}}{2 * PCK[A,B] * PWMPER_n}$	Center-aligned with clock [A,B]
$duty = \left 1 - PWMPOL[PPOL_n] - \frac{PWMDTY_n}{PWMPER_n} \right * 100\%$	Duty cycle for all PWM type signals.
PCK[A,B] = 2n; n = [0,7] fSYS = Core internal frequency PWMSCLA = [0,255] PWMPER = [0,255]	Some considerations about PWM equations

Additional to this equation, a spreadsheet (PWMparameterCalculator.xls), showed in [Figure 6](#) and [Figure 5](#), contains an easy way to generate a desired frequency using these parameters:

- Desired frequency to be output through pin.
- $f_{SYS/2}$ —Core internal frequency divided by two.
- PERIOD—PWMPER_n register. Recommended value is 200 to achieve good duty cycle resolution. (Refer to the duty cycle equation in [Table 2](#).)

The spreadsheet calculates the four possible PWM signal types and the obtained frequency with these parameters. Not all frequencies can be synthesized in all types of signals, so frequencies usually have to use a scaled clock instead of a simple clock. It is your responsibility to choose the results (as SCLA) that are below 256 because the register 8-bits wide. For example, in [Figure 5](#) the following are used:

- $f_{SYS/2} = 40,000,000$ Hz
- Desired frequency = 30 Hz
- Period = 200 (to have a more exact duty cycle)

Variable	Value	Unit	Comments
fsys/2	40000000	Hz	Constant
desired frequency	30	Hz	Variable
PERIOD	200	N/A	Constant

Figure 5. Parameters to Calculate PWM Signal

After entering 40 MHz as the clock source, 30 Hz as the desired PWM, and 200 as PERIOD into the spreadsheet (PWMparameterCalculator.xls), it will show the different PWM frequencies with the provided information.

Left Aligned				Center Aligned				
7								
8								
9	Using Clock			Using Clock				
10		PCKA	obtained frequency		PCKA	obtained frequency		
11		1	150000		1	75000		
12		2	75000		2	37500		
13		4	37500		4	18750		
14		8	18750		8	9375		
15		16	9375		16	4687.5		
16		32	4687.5		32	2343.75		
17		64	2343.75		64	1171.875		
18		128	1171.875		128	585.9375		
19								
20	Using Scaled Clock			Using Scaled Clock				
21	subproduct	PCKA	SCLA	obtained frequency	subproduct	PCKA	SCLA	obtained frequency
22	2500	1	2500	30	1250	1	1250	30
23	2500	2	1250	30	1250	2	625	30
24	2500	4	625	30	1250	4	313	29.95207668
25	2500	8	313	29.95207668	1250	8	156	30.04807692
26	2500	16	156	30.04807692	1250	16	78	30.04807692
27	2500	32	78	30.04807692	1250	32	39	30.04807692
28	2500	64	39	30.04807692	1250	64	20	29.296875
29	2500	128	20	29.296875	1250	128	10	29.296875

Figure 6. Resulting Values in the Spreadsheet

You now should select which PCKA and SCLA values can be used according to the following rules:

- PCKA allowed values are: 1, 2, 4, 8, 16, 32, 64 and 128. These values are fixed on the spreadsheet.
- SCLA must be less than 256. Therefore, in this example you can only choose between 156, 78, 39 or 20 for left-aligned and 156, 78, 39, 20 or 10 for center-aligned.
- Within these SCLA values, you should select the obtained frequency row closest to the desired frequency.

The final parameters that could be used with the same results are shown in [Table 3](#) and [Table 4](#).

4.3 Left-Aligned with Scaled Clock

Table 3. Left-Aligned with Scaled Clock

	PERIOD ¹	PCKA ²	SCLA	Desired freq	Obtained Freq ³
Option 1	200	4	156	30 Hz	30.04807 Hz
Option 2	200	5	78	30 Hz	30.04807 Hz
Option 3	200	6	39	30 Hz	30.04807 Hz

¹ Using PCKA and SCLA, PWM channels affected are 0, 1, 4, 5, according to [Table 1](#). It is your responsibility to use the appropriate PWMPER_n (PWMPER1 for channel 1, for example).

² PCKA values that appear on the spreadsheet are modified by 2n. Therefore, PCKA only accepts n values.

³ If the obtained frequency is not close enough to the desired frequency, you must change PERIOD by trial and error until the difference between obtained and desired frequency is adequate.

4.4 Center-Aligned with Scaled Clock

Table 4. Center-Aligned with Scaled Clock

	PERIOD ¹	PCKA ²	SCLA	Desired Freq	Obtained Freq ³
Option 1	200	3	156	30 Hz	30.04807 Hz
Option 2	200	4	78	30 Hz	30.04807 Hz
Option 3	200	5	39	30 Hz	30.04807 Hz

¹ Using PCKA and SCLA, PWM channels affected are 0, 1, 4, 5, according to Table 1. It is your responsibility to use the appropriate PWMPER n (PWMPER1 for channel 1, for example).

² PCKA values that appear on the spreadsheet are modified by $2n$. Therefore, PCKA only accepts n values.

³ If the obtained frequency is not close enough to the desired frequency, you must change PERIOD by trial and error until the difference between obtained and desired frequency is adequate.

The above example uses a period of 200. If the desired duty cycle is 50%, PWMDTY n must be 100 (n refers to channel number) and PWMPOL[PPOL] must be set, according to PWM equation from Table 2. With a period of 200, you can select a precise duty cycle (0.5% resolution).

5 Register Configuration

This section shows the register configuration that affect the entire PWM channels and the code lines used. This section is meant to merely illustrate how the registers are configured.

5.1 Port Assignment Register

The following code lines configure the PTCPAR (Figure 7) and PTDPAR (Figure 8), to assign the PWM function to the GPIO pins.

```

/* associate odd PWM channels to a pin */
MCF_GPIO_PTDPAR = 0
    | MCF_GPIO_PTDPAR_PTDPAR0 /* PWM channel 1 */
    | MCF_GPIO_PTDPAR_PTDPAR1 /* PWM channel 3 */
    | MCF_GPIO_PTDPAR_PTDPAR2 /* PWM channel 5 */
    | MCF_GPIO_PTDPAR_PTDPAR3; /* PWM channel 7 */

/* associate even PWM channels to a pin (reflected in EVB LEDs) */
MCF_GPIO_PTCPAR = 0
    | MCF_GPIO_PTCPAR_TIN0_PWM0 /* PWM channel 0 */
    | MCF_GPIO_PTCPAR_TIN1_PWM2 /* PWM channel 2 */
    | MCF_GPIO_PTCPAR_TIN2_PWM4 /* PWM channel 4 */
    | MCF_GPIO_PTCPAR_TIN3_PWM6; /* PWM channel 6 */

```


IPSBAR
Offsets: 0x10_0057 (PTCPAR) Access: User read/write




Figure 7. Port TC Pin Assignment Register Configuration

IPSBAR 0x10_0058 (PTDPAR) Access: User read/write
Offsets:




Figure 8. Port TD Pin Assignment Register Configuration

5.2 PWM Clock Select Register

The next code lines configure the PWMCLK.

```
/* Associate every channel with a source clock */
/* A, or B, SA or SB depending the channel */
MCF_PWM_PWMCLK = u8Clock;
```

Address: 0x001B_0002 (PWMCLK) Access: User Read/Write




Figure 9. PWM Clock Select Register

5.3 PWM Clock Select Register

The program uses this code to write the values to the PWMPRCLK:

```
/* change the prescaler of the clock source for every channel */
MCF_PWM_PWMPRCLK = 0
    | MCF_PWM_PWMPRCLK_PCKA(BUSCLK_16)
    | MCF_PWM_PWMPRCLK_PCKB(BUSCLK_16);
```



Figure 10. PWM Clock select register

5.4 PWM Scale [A,B] Registers

On the next code lines, the scaled clock register is configured according to [Figure 11](#) and [Figure 12](#).

```
/* set scaled value for scaled clock, if are activated */
MCF_PWM_PWMSCLA = u8ScaledValue;
MCF_PWM_PWMSCLB = u8ScaledValue;
```




Figure 11. PWM Scaled Register A




Figure 12. PWM Scaled Register B

6 Configuration Summary

The following steps are needed to configure the pulse width modulator module:

1. Configure PWM pins as their primary function in the pin assignment registers.
2. Associate each PWM channel with a clock source in the PWMCLK register.
3. Configure PWMPRCLK. If a scaled clock is selected, the PWMSCLA or PWMSCLB registers must be configured as well.
4. For every PWM channel, these registers must be filled:
 - PWMPER: set PWM period (see period equation above).
 - PWMDTY: set duty cycle (see duty cycle equation above).
 - PWMPOL: set channel polarity bit (start each period at high or low).
 - PWMCAE: set channel alignment bit (left or center alignment).
 - PWME: enable each channel using respective bit.

7 Configuration Notes

The following details must be considered when configuring the PWM:

- PWMPRCLK[PCKA] and PWMPRCLK[PCKB] affect all PWM channels.
- PWMSCLA and PWMSCLB affect only PWM channels linked to scaled clocks A or B.

8 Conclusion

The PWM module is a versatile module with eight channels in 8-bit mode or four channels in 16-bit mode. With a combination of clock source and prescaler, you can calculate precise PWM frequencies and duty cycles. After configuration, the module is fully independent and if a change in frequency or duty cycle is needed, a simple write in configuration registers is reflected at the next PWM period.

8.1 Considerations and References

Find the latest software updates and configuration files for the MCF521x devices on the Freescale Semiconductor website: <http://www.freescale.com>

This application note applies to:

- MCF5211, MCF5212, and MCF5213 devices
- M5213EVB Development Board employed with the PWM software demo

For more information on the pulse width modulation module refer to the *MCF5213 ColdFire Integrated Microcontroller Reference Manual*.

The PWMSoftwareDemo software was developed in CodeWarrior for Coldfire v6.3.

Download the source files for PWMSoftwareDemo software (PWMSoftwareDemo.zip) from <http://www.freescale.com>. Inside you'll find source code and a spreadsheet to easily calculate different PWM parameters.

How to Reach Us:**Home Page:**

www.freescale.com

Web Support:

<http://www.freescale.com/support>

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.
Technical Information Center, EL516
2100 East Elliot Road
Tempe, Arizona 85284
+1-800-521-6274 or +1-480-768-2130
www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-compliant and/or non-Pb-free counterparts. For further information, see <http://www.freescale.com> or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to <http://www.freescale.com/epp>.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org
© Freescale Semiconductor, Inc. 2007. All rights reserved.