

Hello World!

i.MX25 PDK Windows Embedded CE 6.0

Application Note

Document Number: 924-76350

Document Revision: 2009.12

Contents

Installation and Setup.....	3
Creating a New Application.....	4
Choosing a Method for Running the Application	7
Method 1: Running the Application using a KITL-Enabled OS	8
Method 2: Running the Application using a KITL-Disabled OS.....	9
Removing an Application from a Workspace.....	10
Modifying the Application to Create Your Own Projects	10

This document shows you how to create a simple demonstration application for the i.MX25 PDK for Windows Embedded CE 6.0, using the Platform Builder wizard. You also use this basic approach to create your own applications for Windows Embedded CE 6.0 platforms.

How to Reach Us:**Home Page:**

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor
Technical Information Center, CH370
1300 N. Alma School Road
Chandler, Arizona 85224
1-800-521-6274 or +1-480-768-2130
support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064, Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor China Ltd.
Exchange Building 23F
No. 118 Jianguo Road
Chaoyang District
Beijing 100022
China
+86 010 5879 8000
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-521-6274 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. Microsoft and Windows are registered trademarks of Microsoft Corporation. ARM is the registered trademark of ARM Limited.

© Freescale Semiconductor, Inc. 2007- 2010. All rights reserved.

Installation and Setup

In order to set up the application, you will need to install the following first:

- Installation of the trial version of Platform Builder
- Installation of updates to Platform Builder
- Installation of the respective BSP

Install Platform Builder

To install Windows Embedded CE™ 6.0, use these steps:

1. Install Visual Studio 2005 and also install the Visual Studio Service Pack 1.
2. Insert the Windows Embedded CE 6.0 installation disk and click next on the opening window to begin the installation, see [Figure 1](#).
3. Follow the installer instruction until the setup section. On the setup section assure that the ARM4I™ platform is selected on the “CE 6.0 Operation System” section, as shown in [Figure 2](#), and click **Next**.
4. Follow the installation wizard until the installation is complete.

Install the Updates to Platform Builder

You need to install the updates to Platform Builder, as these are required by the i.MX25 Windows Embedded CE 6.0 SDK.

Install the Corresponding BSP for Windows Embedded CE 6.0

You may find the respective BSP on the CD-ROM's board or download it from the following URL:

<http://www.freescale.com/imx25PDK>

To install the SDK, use these steps:

1. Download the BSP from the web site, run the `"*.msi"` file.
2. Follow the instructions in the installation wizard.

NOTE

To avoid installation conflicts, first make sure all previous BSP versions have been removed from the platform builder.

Figure 1 Start Menu of the Windows Embedded CE 6.0 Disk





Figure 2 Custom Setup Options



Creating a New Application

Platform Builder provides a wizard application that you can use to easily create a simple application for Windows Embedded CE 6.0.

To create a Hello World application, use these steps:

1. Open a Platform Builder's Workspace for the BSP currently installed. This provides a sample solution that can be used for this example.
2. In the Catalog panel, select and add the Console Window option from the Windows Embedded CE 6.0 catalog, which can be found in the following location (see [Figure 3](#)):
CoreOS > CEBASE > Shell and User Interface > Shell > Command Shell folder
3. Build a run-time OS image with Platform Builder, using the procedures in the Platform Builder documentation. For information, see the "Building a Run-Time Image" topic in the corresponding BSP's *Windows Embedded CE 6.0 User's Guide*.
4. When you have built a run-time OS image in the workspace, set up the project by clicking **Subprojects** > **Add New Subproject** (see [Figure 4](#)). The New Project or File screen is displayed.
5. Click the Projects tab, and then select **WCE Application** (see [Figure 5](#)).
6. In the Project name field, enter a name for the project, such as "HelloWorld".

By default, the project folder will be placed in:

WINCE600\Pbworkspaces\<workspace_name>\

Figure 3 Adding a Console Window to the Project





Figure 4 Creating a New Project



<project_name>. To change this location, click the button in the Location field and select a new location. Click **Next**.

7. For this demo, select **A typical “Hello World! application**, and then click **Finish** (see Figure 6).

The new project is added to the workspace. To confirm the project, expand the Subprojects tree and view the added project name (see Figure 7).

The wizard creates all of the necessary files to compile the application, and also sets the .exe file to run under Windows Embedded CE 6.0.

8. To compile and create the .exe file for the application, right-click on the project folder at the solution’s view.
9. Select **Build or Rebuild** (see Figure 8).

When the application is compiled, Platform Builder creates a new run-time image with the <app name>.exe file included in it.

For example, if the application is named **HelloWorld**, a file named HelloWorld.exe is added to the run-time image. The file is placed by default in the following folder:

```
\WINCE600\
OSDesign\<workspace>\RelDir\
3DS_ARMV4I_Release
```

10. When the application is compiled and the new run-time image with the application is created, download the run-time image to the board.

For instructions, see the *Windows Embedded CE 6.0 User’s Guide*.

11. Once the OS image is loaded in the board, reset the board.
12. Enter the EBOOT menu (see Figure 9).
13. Use the steps in the next section to select the correct method for running the application. There are two methods; the one you select will depend on whether KITL is already enabled.

Figure 5 Selecting the Project and Name




Figure 6 Selecting the Console Application Type




Figure 7 Verifying the Addition of the Project to the Workspace



Figure 8 Compiling and Building the Application





Figure 9 EBOOT Menu




Choosing a Method for Running the Application

There are two methods for running the Hello World application on the board. The method you choose depends on whether the KITL (Kernel Independent Transport Layer) option is enabled for the run-time image. Use the following instructions to determine whether the KITL option is enabled.

1. In Platform Builder, click **Project > Properties**.
2. On the Build Options tab, locate **Enable KITL** (no IMGNOKITL=1) (see [Figure 10](#)):
 - If KITL is selected, go to **Method 1** to run the application.
 - If KITL is NOT selected, go to **Method 2** to run the application.
3. Click **OK**.

Figure 10 Verifying OS Image Build Options



Method 1: Running the Application using a KITL-Enabled OS

1. Ensure that your board has Ethernet connectivity with Platform Builder on your host PC.

To verify the connection, use the procedure described in the corresponding BSP's *Windows Embedded CE 6.0 User's Guide*.
2. At the EBOOT menu, confirm that **P) KITL passive mode** is set to **Disabled**.
3. Launch the OS image from the EBOOT menu by pressing **L**.
4. With the workspace open in Platform Builder, select **Target > Attach Device**.
5. This activates the Platform Builder debug options, and establishes the KITL connection with the board.
6. When the OS image has booted up, in Platform Builder select **Target > Run Programs**.

The Run Program window is displayed.
7. Select your application and click **Run** (see Figure 11).

In the board, a window with the message "Hello World!" message is displayed (see Figure 12).

Figure 11 Running the Sample Program in Platform Builder




Figure 12 Sample Program Output in 3-Stack board



Method 2: Running the Application using a KITL-Disabled OS


1. In the EBOOT menu, press **L** to launch the OS image. Confirm that **P) KITL passive mode** is set to **Enabled**.
2. Using the hand-held pointer, calibrate the touch panel and tap the screen to enter the Windows CE desktop
3. On the Windows Embedded CE 6.0 desktop, select the Windows logo in the lower left corner.
4. Select **Run**. (See Figure 13)
5. The **Run** program window will appear and open the **Keyboard Input Panel**. Type the name of your application, such as **HelloWorld** (the typed entry will not be case sensitive, see Figure 14).

In the PDK board, a window with the message “Hello World!” message is displayed.

Figure 13 Running an Application on Windows Embedded CE 6.0



Figure 14 Running HelloWorld.exe Application from Desktop




Modifying the Application to Create Your Own Projects

1. Edit the .cpp file, which is located in the Source Files folder of your project tree, in the following location (see [Figure 15](#)):

Workspace File > Solution Explorer,
(Subprojects > <app name> > source files)
2. Follow the steps in this Application Note to run your application.

Figure 15 Hello World Application Source Files



Removing an Application from a Workspace

1. In your workspace File View tab, expand the Project tree.
2. Right-click on the project folder, and then click **Remove**.

The .exe file will be removed from your application the next time you build an OS Run-Time Image (see [Figure 16](#)).
3. To remove all of the related files, open Windows Explorer and then remove the Application folder from:

\PATH:>/WINCE600\OSDesigns\<workspace_name>\

Figure 16 Removing an Application from a Workspace

